

Disassembled Handbook for TRS-80

Richcraft Engineering Ltd.
Drawer 1065
Chautauqua, New York 14722

Copyright © 1980

"TRS-80 is A Registered Trademark of TANDY CORP."

VOLUME I

| CHAPTER | SUBJECT | PAGE |
|---------|---|------|
| i | - Foreword | 3 |
| ii | - Introduction | 4 |
| 1. | - Decoding Level II ROM Function CALL Locations | 6 |
| 2. | - Integer, Single & Double Precision Arithmetic | 13 |
| 3. | - Using ROM Trig, Exponent, Log, et al Subroutines | 23 |
| 4. | - Ancillary Level II ROM Subroutines | 29 |
| 5. | - Level II BASIC ROM CALL Addresses-Alphabetical | 35 |
| 6. | - Level II ROM Hex Code | 37 |
| 7. | - Multi-Base Number Conversion Program | 53 |
| 8. | - Print All Zeros With A Slash (Source/Object Code) | 56 |
| 9. | - Self-Test Questions | 58 |
| 10. | - Bibliography and Self-Test Answers | 65 |

- NOTICE -

TRS-80 is a trademark of the Tandy Corporation. The users of the CALLED Level II ROM subroutines presented herein, must of necessity have purchased Level II BASIC and thereby paid the royalties due the copyright owners. All data in this handbook is purely instructional in nature and serves as a supplement to the original documentation provided by Radio Shack/Microsoft and Zilog. Richcraft's absolute refusal to provide copies or extracts of the original documentation assures the copyright owners that all users must purchase Level II ROM from Radio Shack, thereby paying royalties due. Furthermore, a considerable number of Level II ROM memory locations have been blanked out to render the program useless to those who have not purchased the original copyrighted program.

Copyright (c) 1980 by Richcraft Engineering Ltd.

Third Printing: March 1, 1980

All rights reserved. Printed in the United States of America. No part of this publication may be reproduced, stored in any retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of the publisher.

Published by Richcraft Engineering Ltd.
Drawer 1065
Chautauqua, New York 14722

(716) 753 2654

- FOREWORD -

This handbook started out as a collection of lectures prepared as "fill-routines" by the author while on the tour circuit promoting his new book, "The Gunnplexer Cookbook - A 10 GHz Microwave Primer." It is a rather long jump (at least in frequency and wave-length) from the 1.77 MHz clock of the TRS-80 to the 10250 MHz band where the Gunnplexer operates, but surprisingly the microwave buff and computer buff have more in common than meets the eye; i.e., a need to communicate whether it be by simple fm voice modulation or ASCII digital data link.

It was both gratifying and surprising to find that microwave radio amateurs had as much interest in TRS-80 assembly language programing as did computer hobbyists in setting up low-cost microwave digital data links. Ours is indeed a very small world with most all things interrelated.

This handbook is NOT for the beginning assembly language programmer who should certainly learn the fundamentals of the art before attempting to use the shortcuts and "tight code" programming made possible by using the myriad excellent Level II ROM subroutines presented. The moderately experienced assembly language programmer who understands the difference between his/her JPs and JRs, SETs and RESets, and BITs and bytes will find that utilizing Level II ROM subroutines opens up an entirely new vista to the wonderful world of assembly language programming. Many dull but demanding rote subroutines may now be accomplished often with a single CALL compared with previous multi-line/multi-page programming that had to be entered a line at a time. Programmers arise. Cast off the yoke of ignorance and START HAVING FUN writing assembly language programs that run 300+ times faster than BASIC in less than 1/10th memory. With practice, you (and the author) will soon be writing assembly language programs as quickly and with as little effort as those written in BASIC, Fortran, Cobol, or Pascal.

ACKNOWLEDGMENTS:

Without the generous aid and assistance of both Nancy A. Courtney and Margaret C. Merz this handbook would have never come to pass. Their encouragement, hard work, and persistent insistence that we keep at it are gratefully appreciated.

ADDITIONAL THANK YOUS: to the late Charles Tandy for his courage and investment in making the TRS-80 a happening; to Mumford Micro for a 3 speed clock; to Western I/O for an IBM Selectric printer that never quits; to Apparat for NEWDOS+, to Shrayner for Electric Pencil; to Microsoft for the world's most extensively used BASIC; and lastly to Radio Shack, who inspite of other short comings build the WORLD'S MOST COST EFFECTIVE MICROCOMPUTER. Thank you each and every one.

- INTRODUCTION -

Disassembled machine code of any variety WITHOUT comments is worth about as much as a TRS-80 without electric power. Constants, address table entry points, and data lists are translated into utter meaningless/misleading garbage by the disassembler program. Disassembled Level II ROM prints out EX AF,AF' from memory locations 005AH, 1479H, 1619H, 18BAH, 18BCH, etc., etc., when in actuality none of the alternate register pairs are ever used in this ROM's BASIC program.

Decoding and making any sense out of any object code program is impossible if one does not at least have a clue to the program's intended function. Fortunately we know exactly what Level II ROM's functions and capabilities are, so what appeared to be an impossible decoding problem is reduced to only an extremely difficult one. So difficult in fact, that even Radio Shack's computer division in Fort Worth, Texas does not fully understand this excellent "Tight Code" written by Microsoft's Paul Allen and Bill Gates. An example that proves this point is the Radio Shack book, "TRS-80 Assembly Language Programming," #62-2006, that was introduced mid-year 1979 has virtually no references to Level II ROM subroutines of any variety. This is incredible and truly theater of the absurd. It is either criminal negligence on Radio Shack's part, or just plain stupidity. Always hoping for the best, we shall presume the latter.

The level of difficulty in decoding the TRS-80 ROM may be measured by the fact that after 2 years of worldwide use by over 200,000 computer buffs ranging from beginners to advanced programmers with years of experience, the Level II ROM entry points for virtually ALL the BASIC functions and related subroutines have never been published with comments, or disclosed by anyone, anywhere, EXCEPT to a very limited audience by a genius named Andrew Hildebrand, located in the southwestern wilderness of the US.

This handbook is dedicated to Mr. Hildebrand's genius, to his persistence in unraveling a very tangled web, and to him personally for this very considerable accomplishment. The author's only contribution is this handbook which will hopefully remove the shroud of mystery from a previous "black hole" by attempting to make the subject understandable to hobbyists, high school and college students, and even computer science professors, many of whom do not have the slightest idea of how to efficiently utilize the myriad Level II ROM subroutines in TRS-80 assembly language programming. This handbook will also assist users in decoding the majority of ROM subroutines in ALL Microsoft BASIC's including those used by Apple, Pet, KIM, Heathkit, et al microcomputer systems.

Each section of this handbook is hopefully self-explanatory. The Level II ROM hex code presented in Chapter 6, though very

lengthy, is included as a necessary reference. The self-test questions & answers in Chapters 9 & 10 allow you to check your progress after each Chapter. The limited first edition of this handbook was bound and glued with a cloth backing, but even so would not stay together under repeated usage. As such, this second edition is being delivered in loose leaf binder format.

SUMMARY:

Chapter 1 illustrates how the majority of the ROM functions' CALL locations are decoded.

Chapter 2 includes three source/object code programs and text illustrating the use of simple ROM " + - * / " integer, single precision, and double precision arithmetic subroutines.

Chapter 3 describes how to use the trigonometric, exponent, log, CINT, CSNG, CDBL, et al, functions in concert with the RAM accumulator and CDBL store, plus a demonstration program.

Chapter 4 covers a number of the more useful and important Level II ROM ancillary subroutines; Chapter 5 is a summary of virtually all BASIC function CALL addresses.

Chapter 6 is the PARTIAL Level II ROM code in hexadecimal.

Chapter 7 presents and explains an extremely useful number conversion program that is virtually a must for the serious assembly language programmer working with the TRS-80. It is written in BASIC for comprehension/modification and covers:

- DECIMAL TO BINARY ENTER D
- BINARY TO DECIMAL ENTER B
- HEXADECIMAL TO BINARY ENTER HB
- DECIMAL TO HAXADECIMAL ENTER DH
- HEXADECIMAL TO DECIMAL ENTER HD
- SPLIT TRS-80 TO DECIMAL ENTER SP
- DECIMAL TO SPLIT HEXADECIMAL ENTER DS
- SPLIT HEXADECIMAL TO DECIMAL ENTER SD

The first 5 conversions are obvious ones. The 6th, SPLIT TRS-80 TO DECIMAL, is unique in that it takes decimal values displayed via the TRS-80 PEEK command from 2 adjacent memory locations (two INPUTS required), then converts them to hex, reverses the 2 hex numbers as the Z-80 stores LSB first and MSB second, then converts the 4 digit hex number to decimal, and displays it on video. This conversion is a real time saver when extracting addresses (0 to 65535) from ROM or RAM.

Chapter 8 is a useful print all zeros with a slash program.

Chapter 9 includes self-test questions for Chapters 1 - 8.

Chapter 10 is a bibliography and answers to the self-test.

- CHAPTER 1 -

DECODING LEVEL II ROM FUNCTION CALL LOCATIONS

INTRODUCTION:

During the past two years, the Level II BASIC written by Microsoft originally for the TRS-80 has become the world standard de facto BASIC used by virtually every significant microcomputer manufacturer. As of January 1980, the number of microcomputers delivered to end users with Level II or modest variations of Level II BASIC is estimated to exceed 300,000 plus. With the number of BASICs in the marketplace counted in the dozens including: Hewlett-Packard BASIC, General Electric BASIC, and even monolithic IBM's "VS BASIC," there must be a number of good reasons for the near universal adoption of Microsoft's BASIC.

1. It is cheap? Answer: no, in actuality the license to use this BASIC is incredibly expensive. Heathkit does not charge hobbyists \$100. a copy just for the program for fun and games.

2. Is it efficient? Answer: you bet it is. Previous BASICs the author has studied required 22K to 32K memory to minimally perform the same fuctions, if indeed as many.

3. It is cost-effective? Answer: even at the high licensing price it is VERY cost-effective when one considers the trade-offs between available program memory remaining with the inherent 64K maximum imposed by most all 8 bit microprocessors of the current generation. Some of the other BASICs mentioned above only leave the user about 18K of useful RAM when a disk operating system and extended disk BASIC program is added. This is ridiculous in a 64K MEM system.

Let's now take a look at the prodigious functions and their CALL locations in this marvel of "tight code" programming written by Paul Allen and Bill Gates. We doubt if there was any intentional encrypting involved when the program was written as encryption takes memory and memory costs money either directly or indirectly as pointed out above. The main reason it has been difficult to decode the Level II ROM was brought about primarily by its compactness; i.e., nothing wasted, nothing unused, and no easily deciphered pointers telling the code breaker, "here I am, use me."

LEVEL II ROM FUNCTION NAME LOCATIONS:

Are the easiest to find of all. Only a retarded 3rd grader would overlook them at memory locations 5712 through 6172. Figure 1 is an excruciatingly simple BASIC program that will display these names and their location on video for you. The first letter of each name's MSB is masked by subtracting 128 to obtain its ASCII equivalent. Figure 2 is a print out of this program. Remember, the numbers are the name's location, NOT the CALL location.

```

10 ' MICROSOFT BASIC FUNCTIONS' NAME LIST IN LEVEL II ROM
15 '
20 CLS:FORN=5712TO6175:Y=PEEK(N):IFY>127THENY=Y-128:M=N
25 Z=N+1:IFPEEK(Z)>127THENPRINTCHR$(Y);"=";ELSEGOTO35
30 PRINTM,:GOTO40
35 PRINTCHR$(Y);
40 NEXT

```

Figure 1

| | | | |
|-----------------|----------------|---------------|---------------|
| END = 5712 | FOR = 5715 | RESET = 5718 | SET = 5723 |
| CLS = 5726 | CMD = 5729 | RANDOM = 5732 | NEXT = 5738 |
| DATA = 5742 | INPUT = 5746 | DIM = 5751 | READ = 5754 |
| LET = 5758 | GOTO = 5761 | RUN = 5765 | IF = 5768 |
| RESTORE = 5770 | GOSUB = 5777 | RETURN = 5782 | REM = 5788 |
| STOP = 5791 | ELSE = 5795 | TRON = 5799 | TROFF = 5803 |
| DEFSTR = 5808 | DEFINT = 5814 | DEFSNG = 5820 | DEFDBL = 5826 |
| LINE = 5832 | EDIT = 5836 | ERROR = 5840 | RESUME = 5845 |
| OUT = 5851 | ON = 5854 | OPEN = 5856 | FIELD = 5860 |
| GET = 5865 | PUT = 5868 | CLOSE = 5871 | LOAD = 5876 |
| MERGE = 5880 | NAME = 5885 | KILL = 5889 | LSET = 5893 |
| RSET = 5897 | SAVE = 5901 | SYSTEM = 5905 | LPRINT = 5911 |
| DEF = 5917 | POKE = 5920 | PRINT = 5924 | CONT = 5929 |
| LIST = 5933 | LLIST = 5937 | DELETE = 5942 | AUTO = 5948 |
| CLEAR = 5952 | CLOAD = 5957 | CSAVE = 5962 | NEW = 5967 |
| TAB(= 5970 | TO = 5974 | FN = 5976 | USING = 5978 |
| VARPTR = 5983 | USR = 5989 | ERL = 5992 | ERR = 5995 |
| STRING\$ = 5998 | INSTR = 6005 | POINT = 6010 | TIME\$ = 6015 |
| MEM = 6020 | INKEY\$ = 6023 | THEN = 6029 | NOT = 6033 |
| STEP = 6036 | + = 6040 | - = 6041 | * = 6042 |
| / = 6043 | ↑ = 6044 | AND = 6045 | OR = 6048 |
| > = 6050 | = = 6051 | < = 6052 | SGN = 6053 |
| INT = 6056 | ABS = 6059 | FRE = 6062 | INP = 6065 |
| POS = 6068 | SQR = 6071 | RND = 6074 | LOG = 6077 |
| EXP = 6080 | COS = 6083 | SIN = 6086 | TAN = 6089 |
| ATN = 6092 | PEEK = 6095 | CVI = 6099 | CVS = 6102 |
| CVD = 6105 | EOF = 6108 | LOC = 6111 | LOF = 6114 |
| MKI\$ = 6117 | MKS\$ = 6121 | MKD\$ = 6125 | CINT = 6129 |
| CSNG = 6133 | CDBL = 6137 | FIX = 6141 | LEN = 6144 |
| STR\$ = 6147 | VAL = 6151 | ASC = 6154 | CHR\$ = 6157 |
| LEFT\$ = 6161 | RIGHT\$ = 6166 | MID\$ = 6172 | |

Figure 2

MATCHING BASIC FUNCTIONS WITH ROM CALL ADDRESSES:

Now the decoding game becomes somewhat more interesting. Not difficult yet, because no tricky encipherment was used. We should remember that encoding costs memory and memory = money. One does not have to search very far in memory for the location of each BASIC function's CALL address

These addresses are split into two groups. The first group begins a few bytes after the end of the function name list at MEM location 6178 and runs through 6351. This group covers all functions from END through 'less than.' The second group begins at MEM location 5640 and runs through 5711. This group includes all BASIC functions from SGN through the end of the function list, MID\$.

With the exception of those BASIC functions from TAB to 'less than,' all CALL locations are stored in MEM using the standard Zilog Z-80 format (the genius of Federico Faggin, Z-80 creator appears again), with the LSB (least significant byte) first, and the MSB (most significant byte) second, in the following memory location. Figure 3 illustrates a little BASIC program that will display the BASIC function, an = sign, then the MEM location of the stored CALL address for this specific function and lastly the CALL address in standard TRS-80 "PEEK" format.

```

10 ' PROGRAM TO MATCH BASIC FUNCTIONS WITH CALL ADDRESSES
15 '
20 CLS:PRINT"FUNCT=ADDRESS      LSB-MSB          FUNCT=ADDRESS      LSB-MSB"
25 A=6176:FORX=5712TO6175:Y=PEEK(X):IFY>127THENY=Y-128
30 Z=X+1:IFPEEK(Z)>127THENPRINTCHR$(Y);"=";ELSEGOTO45
35 A=A+2:IFA=6352THENA=5640
40 PRINTA,PEEK(A);"-";PEEK(A+1),:GOTO50
45 PRINTCHR$(Y);
50 NEXT
55 END

```

- Figure 3 -

Figure 4 is a printout of Figure 3's program output using those addresses whose LSB/MSB are directly translatable to CALL addresses. The other functions' CALL addresses are fully covered in Chapter 5. Figure 5 is a printout of Level II ROM MEM locations 1600H through 18FFH to illustrate how Level II ROM BASIC function CALL locations are determined.

| FUNCT=ADDRESS | LSB-MSB | FUNCT=ADDRESS | LSB-MSB |
|----------------|----------|----------------|----------|
| END = 6178 | 174 - 29 | FOR = 6180 | 161 - 28 |
| RESET = 6182 | 56 - 1 | SET = 6184 | 53 - 1 |
| CLS = 6186 | 201 - 1 | CMD = 6188 | 115 - 65 |
| RANDOM = 6190 | 211 - 1 | NEXT = 6192 | 182 - 34 |
| DATA = 6194 | 5 - 31 | INPUT = 6196 | 154 - 33 |
| DIM = 6198 | 8 - 38 | READ = 6200 | 239 - 33 |
| LET = 6202 | 33 - 31 | GOTO = 6204 | 194 - 30 |
| RUN = 6206 | 163 - 30 | IF = 6208 | 57 - 32 |
| RESTORE = 6210 | 145 - 29 | GOSUB = 6212 | 177 - 30 |
| RETURN = 6214 | 222 - 30 | REM = 6216 | 7 - 31 |
| STOP = 6218 | 169 - 29 | ELSE = 6220 | 7 - 31 |
| TRON = 6222 | 247 - 29 | TROFF = 6224 | 248 - 29 |
| DEFSTR = 6226 | 0 - 30 | DEFINT = 6228 | 3 - 30 |
| DEFSNG = 6230 | 6 - 30 | DEFDBL = 6232 | 9 - 30 |
| LINE = 6234 | 163 - 65 | EDIT = 6236 | 96 - 46 |
| ERROR = 6238 | 244 - 31 | RESUME = 6240 | 175 - 31 |
| OUT = 6242 | 251 - 42 | ON = 6244 | 108 - 31 |
| OPEN = 6246 | 121 - 65 | FIELD = 6248 | 124 - 65 |
| GET = 6250 | 127 - 65 | PUT = 6252 | 130 - 65 |
| CLOSE = 6254 | 133 - 65 | LOAD = 6256 | 136 - 65 |
| MERGE = 6258 | 139 - 65 | NAME = 6260 | 142 - 65 |
| KILL = 6262 | 145 - 65 | LSET = 6264 | 151 - 65 |
| RSET = 6266 | 154 - 65 | SAVE = 6268 | 160 - 65 |
| SYSTEM = 6270 | 178 - 2 | LPRINT = 6272 | 103 - 32 |
| DEF = 6274 | 91 - 65 | POKE = 6276 | 177 - 44 |
| PRINT = 6278 | 111 - 32 | CONT = 6280 | 228 - 29 |
| LIST = 6282 | 46 - 43 | LLIST = 6284 | 41 - 43 |
| DELETE = 6286 | 198 - 43 | AUTO = 6288 | 8 - 32 |
| CLEAR = 6290 | 122 - 30 | CLOAD = 6292 | 31 - 44 |
| CSAVE = 6294 | 245 - 43 | NEW = 6296 | 73 - 27 |
| INT = 5642 | 55 - 11 | ABS = 5644 | 119 - 9 |
| FRE = 5646 | 212 - 39 | INP = 5648 | 239 - 42 |
| POS = 5650 | 245 - 39 | SQR = 5652 | 231 - 19 |
| RND = 5654 | 201 - 20 | LOG = 5656 | 9 - 8 |
| EXP = 5658 | 57 - 20 | COS = 5660 | 65 - 21 |
| SIN = 5662 | 71 - 21 | TAN = 5664 | 168 - 21 |
| ATN = 5666 | 189 - 21 | PEEK = 5668 | 170 - 44 |
| CVI = 5670 | 82 - 65 | CVS = 5672 | 88 - 65 |
| CVD = 5674 | 94 - 65 | EOF = 5676 | 97 - 65 |
| LOC = 5678 | 100 - 65 | LOF = 5680 | 103 - 65 |
| MKI\$ = 5682 | 106 - 65 | MKS\$ = 5684 | 109 - 65 |
| MKD\$ = 5686 | 112 - 65 | CINT = 5688 | 127 - 10 |
| CSNG = 5690 | 177 - 10 | CDBL = 5692 | 219 - 10 |
| FIX = 5694 | 38 - 11 | LEN = 5696 | 3 - 42 |
| STR\$ = 5698 | 54 - 40 | VAL = 5700 | 197 - 42 |
| ASC = 5702 | 15 - 42 | CHR\$ = 5704 | 31 - 42 |
| LEFT\$ = 5706 | 97 - 42 | RIGHT\$ = 5708 | 145 - 42 |
| MID\$ = 5710 | 154 - 42 | | |

Figure 4

Function=Call Address MEM Location Call-Address

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|----------------------|
| 1600 | 6CAA | AA7F | 0000 | 0081 | 8A09 | 370B | 7709 | D427 |7..... |
| 1610 | EF2A | F527 | E713 | C914 | 0908 | 3914 | 4115 | 4715 | .*.'.....9.A.G. |
| 1620 | A815 | BD15 | AA2C | 5241 | 5841 | 5E41 | 6141 | 6441 |,RAXA.A.A.A |
| 1630 | 6741 | 6A41 | 6D41 | 7041 | 7F0A | B10A | DB0A | 260B | .A.A.A.A.....&. |
| 1640 | 032A | 3628 | C52A | 0F2A | 1F2A | 612A | 912A | 9A2A | .*6(*.*.*.*.*.* |
| 1650 | C54E | 44C6 | 4F52 | D245 | 5345 | 54D3 | 4554 | C34C | .ND.OR.ESET.ET.L |
| 1660 | 53C3 | 4D44 | D241 | 4E44 | 4F4D | CE45 | 5854 | C441 | S.MD.ANDOM.EXT.A |
| 1670 | 5441 | C94E | 5055 | 54C4 | 494D | D245 | 4144 | CC45 | TA.NPUT.IM.EAD.E |
| 1680 | 54C7 | 4F54 | 4FD2 | 554E | C946 | D245 | 5354 | 4F52 | T.OTO.UN.F.ESTOR |
| 1690 | 45C7 | 4F53 | 5542 | D245 | 5455 | 524E | D245 | 4DD3 | E.OSUB.ETURN.EM. |
| 16A0 | 544F | 50C5 | 4C53 | 45D4 | 524F | 4ED4 | 524F | 4646 | TOP.LSE.RON.ROFF |
| 16B0 | C445 | 4653 | 5452 | C445 | 4649 | 4E54 | C445 | 4653 | .EFSTR.EFINT.EFS |
| 16C0 | 4E47 | C445 | 4644 | 424C | CC49 | 4E45 | C544 | 4954 | NG.EFDBL.INE.DIT |
| 16D0 | C552 | 524F | 52D2 | 4553 | 554D | 45CF | 5554 | CF4E | .RROR.ESUME.UT.N |
| 16E0 | CF50 | 454E | C649 | 454C | 44C7 | 4554 | D055 | 54C3 | .PEN.IELD.ET.UT. |
| 16F0 | 4C4F | 5345 | CC4F | 4144 | CD45 | 5247 | 45CE | 414D | LOSE.OAD.ERGE.AM |
| 1700 | 45CB | 494C | 4CCC | 5345 | 54D2 | 5345 | 54D3 | 4156 | E.ILL.SET.SET.AV |
| 1710 | 45D3 | 5953 | 5445 | 4DCC | 5052 | 494E | 54C4 | 4546 | E.YSTEM.PRINT.EF |
| 1720 | D04F | 4B45 | D052 | 494E | 54C3 | 4F4E | 54CC | 4953 | .OKE.RINT.ONT.IS |
| 1730 | 54CC | 4C49 | 5354 | C445 | 4C45 | 5445 | C155 | 544F | T.LIST.ELETE.UTO |
| 1740 | C34C | 4541 | 52C3 | 4C4F | 4144 | C353 | 4156 | 45CE | .LEAR.LOAD.SAVE. |
| 1750 | 4557 | D441 | 4228 | D44F | C64E | D553 | 494E | 47D6 | EW.AB(.O.N.SING. |
| 1760 | 4152 | 5054 | 52D5 | 5352 | C552 | 4CC5 | 5252 | D354 | ARPTR.SR.RL.RR.T |
| 1770 | 5249 | 4E47 | 24C9 | 4E53 | 5452 | D04F | 494E | 54D4 | RING\$.NSTR.OINT. |
| 1780 | 494D | 4524 | CD45 | 4DC9 | 4E4B | 4559 | 24D4 | 4845 | IME\$.EM.NKEY\$.HE |
| 1790 | 4ECE | 4F54 | D354 | 4550 | ABAD | AAAF | DBC1 | 4E44 | N.OT.TEP.....ND |
| 17A0 | CF52 | BEBD | BCD3 | 474E | C94E | 54C1 | 4253 | C652 | .R.....GN.NT.BS.R |
| 17B0 | 45C9 | 4E50 | D04F | 53D3 | 5152 | D24E | 44CC | 4F47 | E.NP.OS.QR.ND.OG |
| 17C0 | C558 | 50C3 | 4F53 | D349 | 4ED4 | 414E | C154 | 4ED0 | .XP.OS.IN.AN.TN. |
| 17D0 | 4545 | 4BC3 | 5649 | C356 | 53C3 | 5644 | C54F | 46CC | EEK.VI.VS.VD.OF. |
| 17E0 | 4F43 | CC4F | 46CD | 4B49 | 24CD | 4B53 | 24CD | 4B44 | OC.OF.KI\$.KS\$.KD |
| 17F0 | 24C3 | 494E | 54C3 | 534E | 47C3 | 4442 | 4CC6 | 4958 | \$.INT.SNG.DBL.IX |
| 1800 | CC45 | 4ED3 | 5452 | 24D6 | 414C | C153 | 43C3 | 4852 | .EN.TR\$.AL.SC.HR |
| 1810 | 24CC | 4546 | 5424 | D249 | 4748 | 5424 | CD49 | 4424 | \$.EFT\$.IGHT\$.ID\$ |
| 1820 | A780 | AE1D | A11C | 3801 | 3501 | C901 | 7341 | D301 |8.5.....A.. |
| 1830 | B622 | 051F | 9A21 | 0826 | EF21 | 211F | C21E | A31E | ."....!.&!!!..... |
| 1840 | 3920 | 911D | B11E | DE1E | 071F | A91D | 071F | F71D | 9..... |
| 1850 | F81D | 001E | 031E | 061E | 091E | A341 | 602E | F41F |A..... |
| 1860 | AF1F | FB2A | 6C1F | 7941 | 7C41 | 7F41 | 8241 | 8541 | ...*...A.A.A.A.A |
| 1870 | 8841 | 8B41 | 8E41 | 9141 | 9741 | 9A41 | A041 | B202 | .A.A.A.A.A.A.A.. |
| 1880 | 6720 | 5B41 | B12C | 6F20 | E41D | 2E2B | 292B | C62B | ...A.,.....+)+.+ |
| 1890 | 0820 | 7A1E | 1F2C | F52B | 491B | 7979 | 7C7C | 7F50 |,+I.....P |
| 18A0 | 46DB | 0A00 | 007F | 0AF4 | 0AB1 | 0A77 | 0C70 | 0CA1 | F..... |
| 18B0 | 0DE5 | 0D78 | 0A16 | 0713 | 0747 | 08A2 | 080C | 0AD2 |G..... |
| 18C0 | 0BC7 | 0BF2 | 0B90 | 2439 | 0A4E | 4653 | 4E52 | 474F |\$9.NFSNRGO |
| 18D0 | 4446 | 434F | 564F | 4D55 | 4C42 | 5344 | 442F | 3049 | DFCOVOMULBSDD/OI |
| 18E0 | 4454 | 4D4F | 534C | 5353 | 5443 | 4E4E | 5252 | 5755 | DTMOSLSSTCNNRRWU |
| 18F0 | 454D | 4F46 | 444C | 33D6 | 006F | 7CDE | 0067 | 78DE | EMOFDL3..... |

Figure 5

CONVERTING BASIC FUNCTION CALL ADDRESSES TO HEX AND DECIMAL:

Converting the BASIC function CALL addresses printed out in Figure 4 to hexadecimal and decimal is certainly simple, but nevertheless a tedious job whether done with a calculator or using Disk BASIC's &H function. There is a considerably easier way to do it.

The Mult-Base Number Conversion Program presented in Chapter 6 makes the conversion of the CALL locations to hexadecimal and decimal a real pleasure instead of a rote chore. This program may be easily modified to take the LSB and MSB from Figure 3's program output and automatically generate the CALL's decimal and hexadecimal location, but for simplicity's sake let's run through Chapter 6's standard number conversion routine for generating the CALL address for the first function shown in Figure 4, which is END.

Load the conversion program. We will use the program's SPLIT DECIMAL TO DECIMAL routine so press 'SP' ENTER. Figure 4 shows that END's CALL location is LSB = 174 and MSB = 29. The program will display "DECIMAL ?" Press 174 then ENTER. After a moment, the 174 will disappear and "DECIMAL ?" will again be displayed on video. Now, press 29 then ENTER. Faster than a speeding bullet, HEXADECIMAL 1DAE will be displayed on video followed by DECIMAL 7598 a second or two later. Aha, it really does work.

The conversion program's logic and flow is as follows:

1. Convert '174' to hexadecimal and store it.
2. Convert '29' to hexadecimal and store it.
3. Reverse the 2 hexadecimal numbers so it will read MSB/LSB.
4. Display the hexadecimal number on video.
5. Convert the hexadecimal number to decimal.
6. Display the decimal number on video.

Figure 6 is an exact printout of Figure 4's BASIC function CALL addresses in both hexadecimal and decimal. Those CALL addresses above 12288 are of course for coupling to DOS/Disk. So far, so good. Now let's JP to Chapter 2 and get some experience using Level II ROM's subroutines with integer, single precision, and double precision arithmetic. We will initially only be doing 3rd grade add, subtract, multiply, and divide, but we will be doing it with only a few CALLs instead of lines/pages of assembly language programming.

Please disregard the "curse you Red Baron," comments in Chapters 2 and 3. They were put in for reviewers/publishers who were given only a single chapter of this handbook.

MATCHING BASIC FUNCTIONS WITH MEM CALL LOCATIONS

| FUNCTION | HEX | DECIMAL | FUNCTION | HEX | DECIMAL |
|----------|------|---------|----------|------|---------|
| END | 1DAE | 7598 | FOR | 1CA1 | 7329 |
| RESET | 0138 | 312 | SET | 0135 | 309 |
| CLS | 01C9 | 457 | CMD | 4173 | 16755 |
| RANDOM | 01D3 | 467 | NEXT | 22B6 | 8886 |
| DATA | 1F05 | 7941 | INPUT | 219A | 8602 |
| DIM | 2608 | 9736 | READ | 21EF | 8687 |
| LET | 1F21 | 7969 | GOTO | 1EC2 | 7874 |
| RUN | 1EA3 | 7843 | IF | 2039 | 8249 |
| RESTORE | 1D91 | 7569 | GOSUB | 1EB1 | 7857 |
| RETURN | 1EDE | 7902 | REM | 1F07 | 7943 |
| STOP | 1DA9 | 7593 | ELSE | 1F07 | 7943 |
| TRON | 1DF7 | 7671 | TROFF | 1DF8 | 7672 |
| DEFSTR | 1E00 | 7680 | DEFINT | 1E03 | 7683 |
| DEFSNG | 1E06 | 7686 | DEFDBL | 1E09 | 7689 |
| LINE | 41A3 | 16803 | EDIT | 2E60 | 11872 |
| ERROR | 1FF4 | 8180 | RESUME | 1FAF | 8111 |
| OUT | 2AFB | 11003 | ON | 1F6C | 8044 |
| OPEN | 4179 | 16761 | FIELD | 417C | 16764 |
| GET | 417F | 16767 | PUT | 4182 | 16770 |
| CLOSE | 4185 | 16773 | LOAD | 4188 | 16776 |
| MERGE | 418B | 16779 | NAME | 418E | 16782 |
| KILL | 4191 | 16785 | LSET | 4197 | 16791 |
| RSET | 419A | 16794 | SAVE | 41A0 | 16800 |
| SYSTEM | 02B2 | 690 | LPRINT | 2067 | 8295 |
| DEF | 415B | 16731 | POKE | 2CB1 | 11441 |
| PRINT | 206F | 8303 | CONT | 1DE4 | 7652 |
| LIST | 2B2E | 11054 | LLIST | 2B29 | 11049 |
| DELETE | 2BC6 | 11206 | AUTO | 2008 | 8200 |
| CLEAR | 1E7A | 7802 | CLOAD | 2C1F | 11295 |
| CSAVE | 2BF5 | 11253 | NEW | 1B49 | 6985 |
| INT | 0B37 | 2871 | ABS | 0977 | 2423 |
| FRE | 27D4 | 10196 | INP | 2AEF | 10991 |
| POS | 27F5 | 10229 | SQR | 13E7 | 5095 |
| RND | 14C9 | 5321 | LOG | 0809 | 2057 |
| EXP | 1439 | 5177 | COS | 1541 | 5441 |
| SIN | 1547 | 5447 | TAN | 15A8 | 5544 |
| ATN | 15BD | 5565 | PEEK | 2CAA | 11434 |
| CVI | 4152 | 16722 | CVS | 4158 | 16728 |
| CVD | 415E | 16734 | EOF | 4161 | 16737 |
| LOC | 4164 | 16740 | LOF | 4167 | 16743 |
| MKI\$ | 416A | 16746 | MKS\$ | 416D | 16749 |
| MKD\$ | 4170 | 16752 | CINT | 0A7F | 2687 |
| CSNG | 0AB1 | 2737 | CDBL | 0ADB | 2779 |
| FIX | 0B26 | 2854 | LEN | 2A03 | 10755 |
| STR\$ | 2836 | 10294 | VAL | 2AC5 | 10949 |
| ASC | 2A0F | 10767 | CHR\$ | 2A1F | 10783 |
| LEFT\$ | 2A61 | 10849 | RIGHT\$ | 2A91 | 10897 |
| MID\$ | 2A9A | 10906 | | | |

- CHAPTER 2 -

INTEGER, SINGLE, AND DOUBLE PRECISION ARITHMETIC

INTRODUCTION:

After one has recovered from the shock of learning the fundamentals of assembly language programming it is ridiculous to "re-invent the wheel" by writing dozens of lines or pages of source code to perform simple single and double precision arithmetic calculations when these routines already exist in Level II ROM and may be accessed with a single call.

Assembly language programming with its resulting source code programs running 300+ times faster than BASIC and requiring on the average only 1/10th as much memory to perform the same functions as BASIC is really the ne plus ultra for the serious amateur programmer who wishes to advance beyond the inherent limitations of BASIC, Fortran, Cobol, Pascal or any of the high level computer languages. Prior to the "TRS-80 Disassembled Handbook," would be assembly language programmers were forced to learn by rote those assembly language subroutines for ALL the functions that were already extant in the Level II ROM because no one had ever figured out exactly how to access all these subroutines; i.e., break the beautifully "TIGHT CODE" code written by Microsoft's Paul Allen and Bill Gates.

Would be assembly programmers arise. The Level II ROM code has now been broken. As every cryptographer knows, every lock has a key. It is just that some locks take a bit longer to pick than others, (ask N.S.A. or MI.5 about this). For some perverse reason, (probably money and the Chinese secrecy syndrome), neither Radio Shack or Microsoft have been willing to come forward and tell the 200,000+ TRS-80 users how to use the myriad Level II ROM subroutines in assembly language programs. This point is best illustrated by Radio Shack's book, "TRS-80 Assembly Language Programming," introduced in mid-1979 which either for stupidity or duplicity or both leads the would be assembly language programmer into T-Bug (surely the height of backwardness/retrogression), and then goes on with multi-line demonstration programs covering keyboard scan, video display, fill, move, muladd, mulsub, compare, mul16, div16, etc. that could be accomplished with only a few lines of assembly language programming IF the extant Level II ROM subroutines had been used. Let us be kind though, and presume that Radio Shack had not the slightest idea what Level II ROM contained, and if they did, had not the slightest idea on how to find it and use it. If such is not the case, they surely stand guilty of gross negligence and malice aforethought before the 200,000+ TRS-80 user community. If you have mastered Level II BASIC, and can at least read and write the English language at the 5th grade level, you should have great fun with this totally NEW approach to assembly language programming. By mastering Level II BASIC you have demonstrated that you have the skills and persistence to become an advanced

assembly language programmer with only a few weeks study rather than what heretofore took many months or years. The supposed "experts" in the field of assembly language programming have created an aura and mystique about the subject which is totally undeserved and seeks only to promote their own self esteem. "Bull roar," as the philosopher said. Let us take a brief look at how very simple assembly language programming can be by illustrating our point with a few simple arithmetic programs that almost exclusively use Level II ROM subroutines.

FUNDAMENTALS OF LEVEL II ROM ARITHMETIC:

ROM arithmetic subroutines are virtually identical to those you would HAVE TO write were they not NOW available to the assembly language programmer. This is true whether we are discussing integer, single precision, double precision, addition, subtraction, multiplication, division, as well as ALL the trigonometric, exponential, and log functions too. In fact, it is true for all Level II ROM functions which are nothing more than binary bytes we may manipulate as long as we know where they are located. Let's get on with the primer for + - * and /.

ROM (read-only-memory) means just what it says, READ-ONLY. Since it may be only read from, Level II ROM uses the RAM memory from 14302 to 17129 for all its housekeeping chores. The keyboard, from 14336 to 15360 is not really RAM at all, but a simple key/switch matrix which the rest of the system thinks is RAM. Video memory occupies memory locations 15360 to 16383. Except for memory locations 14302 to 14336, all the non-disk Level II RAM housekeeping chores are done between 16384 and 17129. Three RAM memory locations are of particular interest while discussing arithmetic + - * / subroutines. They are the ACCUMulator, CDBL store (or "CS" abbreviation), and NT (number type). Arithmetic numbers stashed in RAM use the following conventions: integer = LSB first and MSB second using two's complement format, and single and double precision numbers = normalized exponential format with 129 added to the exponent and the high bit of the MSB reflecting the + or - sign of the number. Do not concern yourself with these number formats as our Level II ROM will handle all the conversions necessary if we use them properly. The ACCUM occupies memory locations 411DH through 4124H (8 bytes) and CDBL store occupies 4127H through 412EH, also 8 bytes. We must concern ourselves with NT (number type) as it will "blow" our whole subroutine if we try to perform arithmetic operations with dissimilar number types; i.e., add an integer to a double precision number, etc. Do not fret though, ROM lets us use its CINT, CSNG, CDBL functions with only a single CALL to make the numbers we are using compatible.

CINT = CALL 0A7FH CSNG = CALL 0AB1H CDBL = CALL 0ADBH

The 3 programs in this chapter provide these functions in each routine, so it takes real effort to foul them up if you abide by each number types minimal rules.

The NT (number type) single byte storage in RAM is located at 40AFH. NT (40AFH) = 2 for an integer number, = 3 for a string, = 4 for a single precision number, and = 8 for a double precision number. To change these numbers to ASCII and display them on video, simply ADD 30H to the contents of MEM location 40AFH and output to the video display as follows:

```
LD      A, (40AFH)      ;NT location
ADD     A,30H           ;convert to ASCII
CALL    032AH           ;display on video
```

INTEGER ARITHMETIC + - * / :

Fig. 7 is the source code and Fig. 8 is the object code of the demonstration program that will allow you to add, subtract, multiply, or divide integers strictly using the ROM subroutines. Fast? You bet it is. As soon as you press ENTER you'll have the answer. Remember, your Model I TRS-80 with its clock running at approximately 1,774,000 cycles per second is no slow poke. Instead of of BASIC's "slowsville," you are now conversing with your Z-80 microprocessor directly, IN ITS OWN LANGUAGE. With no intrepeter (BASIC) required, it will zap along at what appears to be the speed of light. All this integer program does is to place the first number you input into the DE register, the second number you input into the HL register, and then CALL whatever + - * / operation you requested. This simple program is completely straightforward except for line 330's PUSH HL and line 400's POP DE. The stack begins at RAM memory location 4288H when operating in the SYSTEM mode. What we are doing here is "saving" the first integer number in the stack by PUSHing HL in line 330. The program then uses the HL register in obtaining the second number you input in line 340. The POP DE in line 400 merely takes the previous HL value from the stack and places it into the DE register. The stack could care less where its contents go as it is just a sophisticated FILO (first-in-last-out) memory created and controlled by your Z-80/ROM (unless you choose to modify its location with the LD SP (stack pointer) opcode and operand instruction. Remember, integer arithmetic is nothing more than placing the 'F'irst number in the DE register, the 'S'econd number in the HL register, and specifying which + - * / operation you desire with the following CALLS:

```
ADD      = CALL 0BD2H      SUBTRACT = CALL 0BD7H
MULTIPLY = CALL 0BF2H      DIVIDE    = CALL 2490H
```

The result of any of these operations is always placed in the ACCUM. To display the result on video, merely:

```
CALL     0FBDH           ;convert ACCUM to ASCII string
CALL     28A7H           ;display ASCII string on video
```

Do not forget the Opcode, 'ADD HL,(register pair)' for integer adds up to 65535. Integers are simplesville, indeed.

SINGLE PRECISION ARITHMETIC + - * / :

Is very similar to integer arithmetic, except ROM now wants the 'F'irst number in registers BC and DE, and the 'S'econd number in the ACCUM. The desired operation is performed by:

| | | | |
|----------|--------------|----------|--------------|
| ADD | = CALL 0716H | SUBTRACT | = CALL 0713H |
| MULTIPLY | = CALL 0847H | DIVIDE | = CALL 08A2H |

For memory storage, we again use the stack as shown in lines 340 & 350 PUSH instructions, and lines 420 & 430 POP same. Figs. 9 & 10 are the source code and object code for the single precision arithmetic demonstration program.

DOUBLE PRECISION ARITHMETIC + - * / :

Is not significantly different from either integer or single precision arithmetic subroutines, except now ROM wants the 'F'irst number in the ACCUM and the 'S'econd number in the CDBL store RAM location. Desired operation is performed by:

| | | | |
|----------|--------------|----------|--------------|
| ADD | = CALL 077CH | SUBTRACT | = CALL 0C70H |
| MULTIPLY | = CALL 0DA1H | DIVIDE | = CALL 0DE5H |

Figs. 11 & 12 are the source and object code for the double precision arithmetic demonstration program.

SUMMARY:

Each of these source code programs may be input by the user in about 5 minutes time using the EXCELLENT Radio Shack Editor/Assembler that was written by Zilog's President and in-house-genius, Federico Faggin, and his staff. Previous assembly language teaching programs required months of study and page upon page of source code to accomplish all the double precision arithmetic routines. Now the average TRS-80 buff can master the subject in a matter of hours.

00100 ;
00110
00120 ;

USING LEVEL II ROM SUBROUTINES + - * /

00130
00140 W4UCH EQU 7D00H
00150 ORG W4UCH
00160 BEGIN LD A,4FH
00170 CALL 032AH
00180 LD A,3FH
00190 CALL 032AH
00200 LD A,20H
00210 CALL 032AH
00220 CALL 049H
00230 CALL 032AH
00240 LD (FUNCT),A
00250 LD A,0DH
00260 CALL 032AH
00270 LD A,46H
00280 CALL 032AH
00290 CALL 1BB3H
00300 RST 10H
00310 CALL 0E6CH
00320 CALL 0A7FH
00330 PUSH HL
00340 LD A,53H
00350 CALL 032AH
00360 CALL 1BB3H
00370 RST 10H
00380 CALL 0E6CH
00390 CALL 0A7FH
00400 POP DE
00410 LD A,(FUNCT)
00420 CP 2BH
00430 JR Z,ADD
00440 CP 2DH
00450 JR Z,SUB
00460 CP 2AH
00470 JR Z,MULT
00480 CP 2FH
00490 JR Z,DIVIDE
00500 VIDEO LD A,3DH
00510 CALL 032AH
00520 LD A,20H
00530 CALL 032AH
00540 CALL 0FBDH
00550 CALL 28A7H
00560 LD A,0DH
00570 CALL 032AH
00580 JR BEGIN
00590 ADD CALL 0BD2H
00600 JR VIDEO
00610 SUB CALL 0BC7H
00620 JR VIDEO
00630 MULT CALL 0BF2H
00640 JR VIDEO
00650 DIVIDE CALL 2490H
00660 JR VIDEO
00670 FUNCT DEFB
00680 END W4UCH

;= 32000 DECIMAL
;PROGRAM WILL START HERE
;"O" OPERATION DESIRED
;DISPLAY "O" ON VIDEO
;= ASCII ?
;DO IT - ON VIDEO
;= ASCII SPACE
;DO IT - ON VIDEO
;KYBD INPUT + - * /
;DISPLAY FUNCTION
;STASH DESIRED OPERATION
;0DH = SKIP A LINE
;DO IT - ON VIDEO
;"F" = FIRST NUMBER
;DO IT - ON VIDEO
;KYBD/VIDEO INPUT ROUTINE
;SCAN \$ SET "C" FLAG
;ASCII-ACCUM RET MIN
;CONVERT TO INTEGER
;SAVE INTEGER IN STACK
;"S" = 2ND NUMBER
;DISPLAY "S" ON VIDEO
;KYBD/VIDEO INPUT ROUTINE
;SCAN \$ SET "C" FLAG
;ASCII\$ TO ACCUM RET MIN
;CONVERT TO INTEGER
;PREVIOUS HL TO DE REG
;RECALL + - * / FROM MEM
;IS IT + ?
;IF SO GOTO ADD
;IS IT - ?
;IF SO GOTO SUBTRACT
;IS IT * ?
;IF SO GOTO MULTIPLY
;IS IT / ?
;IF SO GOTO DIVIDE
;3DH IS ASCII = SIGN
;DO IT - ON VIDEO
;= ASCII SPACE
;DO IT - ON VIDEO
;CONV ACCUM TO STRING
;DISPLAY STRING ON VIDEO
;= SKIP A LINE
;DO IT - ON VIDEO
;REPEAT ROUTINE
;ADD DE + HL
;OUTPUT RESULT
;SUBTRACT DE - HL
;OUTPUT RESULT
;MULTIPLY DE * HL
;OUTPUT RESULT
;DIVIDE DE / HL
;OUTPUT RESULT
;SAVE BYTE-STASH FUNCTION
;AMATEUR RADIO CALL LTRS

| | | | | |
|-------------|-------|--------|------|-----------|
| 7D00 | 00130 | | | |
| 7D00 | 00140 | W4UCH | EQU | 7D00H |
| 7D00 | 00150 | | ORG | W4UCH |
| 7D00 3E4F | 00160 | BEGIN | LD | A,4FH |
| 7D02 CD2A03 | 00170 | | CALL | 032AH |
| 7D05 3E3F | 00180 | | LD | A,3FH |
| 7D07 CD2A03 | 00190 | | CALL | 032AH |
| 7D0A 3E20 | 00200 | | LD | A,20H |
| 7D0C CD2A03 | 00210 | | CALL | 032AH |
| 7D0F CD4900 | 00220 | | CALL | 049H |
| 7D12 CD2A03 | 00230 | | CALL | 032AH |
| 7D15 327B7D | 00240 | | LD | (FUNCT),A |
| 7D18 3E0D | 00250 | | LD | A,0DH |
| 7D1A CD2A03 | 00260 | | CALL | 032AH |
| 7D1D 3E46 | 00270 | | LD | A,46H |
| 7D1F CD2A03 | 00280 | | CALL | 032AH |
| 7D22 CDB31B | 00290 | | CALL | 1BB3H |
| 7D25 D7 | 00300 | | RST | 10H |
| 7D26 CD6C0E | 00310 | | CALL | 0E6CH |
| 7D29 CD7F0A | 00320 | | CALL | 0A7FH |
| 7D2C E5 | 00330 | | PUSH | HL |
| 7D2D 3E53 | 00340 | | LD | A,53H |
| 7D2F CD2A03 | 00350 | | CALL | 032AH |
| 7D32 CDB31B | 00360 | | CALL | 1BB3H |
| 7D35 D7 | 00370 | | RST | 10H |
| 7D36 CD6C0E | 00380 | | CALL | 0E6CH |
| 7D39 CD7F0A | 00390 | | CALL | 0A7FH |
| 7D3C D1 | 00400 | | POP | DE |
| 7D3D 3A7B7D | 00410 | | LD | A,(FUNCT) |
| 7D40 FE2B | 00420 | | CP | 2BH |
| 7D42 2823 | 00430 | | JR | Z,ADD |
| 7D44 FE2D | 00440 | | CP | 2DH |
| 7D46 2824 | 00450 | | JR | Z,SUB |
| 7D48 FE2A | 00460 | | CP | 2AH |
| 7D4A 2825 | 00470 | | JR | Z,MULT |
| 7D4C FE2F | 00480 | | CP | 2FH |
| 7D4E 2826 | 00490 | | JR | Z,DIVIDE |
| 7D50 3E3D | 00500 | VIDEO | LD | A,3DH |
| 7D52 CD2A03 | 00510 | | CALL | 032AH |
| 7D55 3E20 | 00520 | | LD | A,20H |
| 7D57 CD2A03 | 00530 | | CALL | 032AH |
| 7D5A CDBD0F | 00540 | | CALL | 0FBDH |
| 7D5D CDA728 | 00550 | | CALL | 28A7H |
| 7D60 3E0D | 00560 | | LD | A,0DH |
| 7D62 CD2A03 | 00570 | | CALL | 032AH |
| 7D65 1899 | 00580 | | JR | BEGIN |
| 7D67 CDD20B | 00590 | ADD | CALL | 0BD2H |
| 7D6A 18E4 | 00600 | | JR | VIDEO |
| 7D6C CDC70B | 00610 | SUB | CALL | 0BC7H |
| 7D6F 18DF | 00620 | | JR | VIDEO |
| 7D71 CDF20B | 00630 | MULT | CALL | 0BF2H |
| 7D74 18DA | 00640 | | JR | VIDEO |
| 7D76 CD9024 | 00650 | DIVIDE | CALL | 2490H |
| 7D79 18D5 | 00660 | | JR | VIDEO |
| 7D7B 00 | 00670 | FUNCT | DEFB | 0 |
| 7D00 | 00680 | | END | W4UCH |

00110

00120 ; USING LEVEL II ROM SUBROUTINES + - * / BY W4UCH

00130

| | | | | |
|-------|--------|------|-----------|---------------------------|
| 00140 | W4UCH | EQU | 7D00H | ;= 32000 DECIMAL |
| 00150 | | ORG | W4UCH | ;PROGRAM WILL START HERE |
| 00160 | BEGIN | LD | A,4FH | ;"O" OPERATION DESIRED |
| 00170 | | CALL | 032AH | ;DISPLAY "O" ON VIDEO |
| 00180 | | LD | A,3FH | ;= ASCII ? |
| 00190 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00200 | | LD | A,20H | ;= ASCII SPACE |
| 00210 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00220 | | CALL | 049H | ;KYBD INPUT + - * / |
| 00230 | | CALL | 032AH | ;DISPLAY FUNCTION |
| 00240 | | LD | (FUNCT),A | ;STASH DESIRED OPERATION |
| 00250 | | LD | A,0DH | ;0DH = SKIP A LINE |
| 00260 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00270 | | LD | A,46H | ;"F" = FIRST NUMBER |
| 00280 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00290 | | CALL | 1BB3H | ;KYBD/VIDEO INPUT ROUTINE |
| 00300 | | RST | 10H | ;SCAN \$ SET "C" FLAG |
| 00310 | | CALL | 0E6CH | ;ASCII-ACCUM RET MIN |
| 00320 | | CALL | 0AB1H | ;CONV SINGLE PRECISION |
| 00330 | | CALL | 09BFH | ;LOAD BCDE FROM ACCUM |
| 00340 | | PUSH | BC | ;STORE IN STACK |
| 00350 | | PUSH | DE | ;STORE IN STACK |
| 00360 | | LD | A,53H | ;"S" = 2ND NUMBER |
| 00370 | | CALL | 032AH | ;DISPLAY "S" ON VIDEO |
| 00380 | | CALL | 1BB3H | ;KYBD/VIDEO INPUT ROUTINE |
| 00390 | | RST | 10H | ;SCAN \$ SET "C" FLAG |
| 00400 | | CALL | 0E6CH | ;ASCII\$ TO ACCUM RET MIN |
| 00410 | | CALL | 0AB1H | ;CONV TO SINGLE PRECISION |
| 00420 | | POP | DE | ;RESTORE DE REGISTER |
| 00430 | | POP | BC | ;RESTORE BC REGISTER |
| 00440 | | LD | A,(FUNCT) | ;RECALL + - * / FROM MEM |
| 00450 | | CP | 2BH | ;IS IT + ? |
| 00460 | | JR | Z,ADD | ;IF SO GOTO ADD |
| 00470 | | CP | 2DH | ;IS IT - ? |
| 00480 | | JR | Z,SUB | ;IF SO GOTO SUBTRACT |
| 00490 | | CP | 2AH | ;IS IT * ? |
| 00500 | | JR | Z,MULT | ;IF SO GOTO MULTIPLY |
| 00510 | | CP | 2FH | ;IS IT / ? |
| 00520 | | JR | Z,DIVIDE | ;IF SO GOTO DIVIDE |
| 00530 | VIDEO | LD | A,3DH | ;3DH IS ASCII = SIGN |
| 00540 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00550 | | LD | A,20H | ;= ASCII SPACE |
| 00560 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00570 | | CALL | 0FBDH | ;CONV ACCUM TO STRING |
| 00580 | | CALL | 28A7H | ;DISPLAY STRING ON VIDEO |
| 00590 | | LD | A,0DH | ;= SKIP A LINE |
| 00600 | | CALL | 032AH | ;DO IT - ON VIDEO |
| 00610 | | JR | BEGIN | ;REPEAT ROUTINE |
| 00620 | ADD | CALL | 0716H | ;ADD BCDE REGS TO ACCUM |
| 00630 | | JR | VIDEO | ;OUTPUT RESULT |
| 00640 | SUB | CALL | 0713H | ;SUB ACCUM FM BCDE REGS |
| 00650 | | JR | VIDEO | ;OUTPUT RESULT |
| 00660 | MULT | CALL | 0847H | ;MULT ACCUM * BCDE REGS |
| 00670 | | JR | VIDEO | ;OUTPUT RESULT |
| 00680 | DIVIDE | CALL | 08A2H | ;DIV ACCUM INTO BCDE REGS |
| 00690 | | JR | VIDEO | ;OUTPUT RESULT |
| 00700 | FUNCT | DEFB | | ;SAVE BYTE-STASH FUNCTION |
| 00710 | | END | W4UCH | ;EL FIN = EL PRIMERO |

| | | | |
|-------------|--------------|------|-----------|
| | 00130 ; | | |
| 7D00 | 00140 W4UCH | EQU | 7D00H |
| 7D00 | 00150 | ORG | W4UCH |
| 7D00 3E4F | 00160 BEGIN | LD | A,4FH |
| 7D02 CD2A03 | 00170 | CALL | 032AH |
| 7D05 3E3F | 00180 | LD | A,3FH |
| 7D07 CD2A03 | 00190 | CALL | 032AH |
| 7D0A 3E20 | 00200 | LD | A,20H |
| 7D0C CD2A03 | 00210 | CALL | 032AH |
| 7D0F CD4900 | 00220 | CALL | 049H |
| 7D12 CD2A03 | 00230 | CALL | 032AH |
| 7D15 32807D | 00240 | LD | (FUNCT),A |
| 7D18 3E0D | 00250 | LD | A,0DH |
| 7D1A CD2A03 | 00260 | CALL | 032AH |
| 7D1D 3E46 | 00270 | LD | A,46H |
| 7D1F CD2A03 | 00280 | CALL | 032AH |
| 7D22 CDB31B | 00290 | CALL | 1B73H |
| 7D25 D7 | 00300 | RST | 10H |
| 7D26 CD6C0E | 00310 | CALL | 0E6CH |
| 7D29 CDB10A | 00320 | CALL | 0AB1H |
| 7D2C CDBF09 | 00330 | CALL | 09BFH |
| 7D2F C5 | 00340 | PUSH | BC |
| 7D30 D5 | 00350 | PUSH | DE |
| 7D31 3E53 | 00360 | LD | A,53H |
| 7D33 CD2A03 | 00370 | CALL | 032AH |
| 7D36 CDB31B | 00380 | CALL | 1BB3H |
| 7D39 D7 | 00390 | RST | 10H |
| 7D3A CD6C0E | 00400 | CALL | 0E6CH |
| 7D3D CDB10A | 00410 | CALL | 0AB1H |
| 7D40 D1 | 00420 | POP | DE |
| 7D41 C1 | 00430 | POP | BC |
| 7D42 3A807D | 00440 | LD | A,(FUNCT) |
| 7D45 FE2B | 00450 | CP | 2BH |
| 7D47 2823 | 00460 | JR | Z,ADD |
| 7D49 FE2D | 00470 | CP | 2DH |
| 7D4B 2824 | 00480 | JR | Z,SUB |
| 7D4D FE2A | 00490 | CP | 2AH |
| 7D4F 2825 | 00500 | JR | Z,MULT |
| 7D51 FE2F | 00510 | CP | 2FH |
| 7D53 2826 | 00520 | JR | Z,DIVIDE |
| 7D55 3E3D | 00530 VIDEO | LD | A,3DH |
| 7D57 CD2A03 | 00540 | CALL | 032AH |
| 7D5A 3E20 | 00550 | LD | A,20H |
| 7D5C CD2A03 | 00560 | CALL | 032AH |
| 7D5F CDBD0F | 00570 | CALL | 0FBDH |
| 7D62 CDA728 | 00580 | CALL | 28A7H |
| 7D65 3E0D | 00590 | LD | A,0DH |
| 7D67 CD2A03 | 00600 | CALL | 032AH |
| 7D6A 1894 | 00610 | JR | BEGIN |
| 7D6C CD1607 | 00620 ADD | CALL | 0716H |
| 7D6F 18E4 | 00630 | JR | VIDEO |
| 7D71 CD1307 | 00640 SUB | CALL | 0713H |
| 7D74 18DF | 00650 | JR | VIDEO |
| 7D76 CD4708 | 00660 MULT | CALL | 0847H |
| 7D79 18DA | 00670 | JR | VIDEO |
| 7D7B CDA208 | 00680 DIVIDE | CALL | 08A2H |
| 7D7E 18D5 | 00690 | JR | VIDEO |
| 7D80 00 | 00700 FUNCT | DEFB | 0 |
| 7D00 | 00710 | END | W4UCH |

```

00100 ;      DOUBLE PRECISION DEMONSTRATION PROGRAM
00110
00120 ;      USING LEVEL II ROM SUBROUTINES + - * /
00130
00140 W4UCH EQU      7D00H      ;= 32000 DECIMAL
00150      ORG      W4UCH      ;PROGRAM WILL START HERE
00160 BEGIN LD      A,4FH      ;"O" OPERATION DESIRED
00170      CALL     032AH      ;DISPLAY "O" ON VIDEO
00180      LD      A,3FH      ;= ASCII ?
00190      CALL     032AH      ;DO IT - ON VIDEO
00200      LD      A,20H      ;= ASCII SPACE
00210      CALL     032AH      ;DO IT - ON VIDEO
00220      CALL     049H      ;KYBD INPUT + - * /
00230      CALL     032AH      ;DISPLAY FUNCTION
00240      LD      (FUNCT),A    ;STASH DESIRED OPERATION
00250      LD      A,0DH      ;0DH = SKIP A LINE
00260      CALL     032AH      ;DO IT - ON VIDEO
00270      LD      A,46H      ;"F" = FIRST NUMBER
00280      CALL     032AH      ;DO IT - ON VIDEO
00290      CALL     1BB3H      ;KYBD/VIDEO INPUT ROUTINE
00300      RST      10H      ;SCAN $ SET "C" FLAG
00310      CALL     0E65H      ;ASCII$ TO ACCUM RET CDBL
00320      LD      DE,411DH    ;MOVE FROM ACCUM RAM MEM
00330      LD      HL,TACCUM    ;TO TEMPORARY ACCUM STASH
00340      LD      B,8         ;NUMBER OF BYTES TO MOVE
00350      CALL     09D7H      ;MOVE IT - SUBROUTINE
00360      LD      A,53H      ;"S" = 2ND NUMBER
00370      CALL     032AH      ;DISPLAY "S" ON VIDEO
00380      CALL     1BB3H      ;KYBD/VIDEO INPUT ROUTINE
00390      RST      10H      ;SCAN $ SET "C" FLAG
00400      CALL     0E65H      ;ASCII$ TO ACCUM RET CDBL
00410      CALL     09FCH      ;TRANSFER ACCUM TO CDBL
00420      LD      DE,TACCUM    ;MOVE ACCUM FROM STASH TO
00430      LD      HL,411DH    ;PERMANENT RAM LOCATION
00440      LD      B,8         ;NUMBER OF BYTES TO MOVE
00450      CALL     09D7H      ;MOVE IT - RIGHT NOW
00460      LD      A,(FUNCT)    ;RECALL + - * / FROM MEM
00470      CP      2BH      ;IS IT + ?
00480      JR      Z,ADD      ;IF SO GOTO ADD
00490      CP      2DH      ;IS IT - ?
00500      JR      Z,SUB      ;IF SO GOTO SUBTRACT
00510      CP      2AH      ;IS IT * ?
00520      JR      Z,MULT     ;IF SO GOTO MULTIPLY
00530      CP      2FH      ;IS IT / ?
00540      JR      Z,DIVIDE   ;IF SO GOTO DIVIDE
00550 VIDEO LD      A,3DH      ;3DH IS ASCII = SIGN
00560      CALL     032AH      ;DO IT - ON VIDEO
00570      LD      A,20H      ;= ASCII SPACE
00580      CALL     032AH      ;DO IT - ON VIDEO
00590      CALL     0FBDH      ;CONV ACCUM TO STRING
00600      CALL     28A7H      ;DISPLAY STRING ON VIDEO
00610      LD      A,0DH      ;= SKIP A LINE
00620      CALL     032AH      ;DO IT - ON VIDEO
00630      JR      BEGIN      ;REPEAT ROUTINE
00640 ADD    CALL     0C77H      ;ADD ACCUM TO CDBL
00650      JR      VIDEO      ;OUTPUT RESULT
00660 SUB    CALL     0C70H      ;SUBTRACT CDBL FROM ACCUM
00670      JR      VIDEO      ;OUTPUT RESULT
00680 MULT   CALL     0DA1H      ;MULTIPLY ACCUM * CDBL
00690      JR      VIDEO      ;OUTPUT RESULT
00700 DIVIDE CALL     0DE5H      ;DIVIDE ACCUM BY CDBL
00710      JR      VIDEO      ;OUTPUT RESULT
00720 FUNCT  DEFB          ;SAVE BYTE-STASH FUNCTION
00730 TACCUM DEFS      8       ;TEMPORARY ACCUM STASH
00740      END      W4UCH      ;AMATEUR RADIO CALL LTRS

```

```

00120 ;DOUBLE PRECISION - PAGE 22 -
00130 ;
00140 W4UCH EQU 7D00H
00150 ORG W4UCH
00160 BEGIN LD A,4FH
00170 CALL 032AH
00180 LD A,3FH
00190 CALL 032AH
00200 LD A,20H
00210 CALL 032AH
00220 CALL 049H
00230 CALL 032AH
00240 LD (FUNCT),A
00250 LD A,0DH
00260 CALL 032AH
00270 LD A,46H
00280 CALL 032AH
00290 CALL 1BB3H
00300 RST 10H
00310 CALL 0E65H
00320 LD DE,411DH
00330 LD HL,TACCUM
00340 LD B,8
00350 CALL 09D7H
00360 LD A,53H
00370 CALL 032AH
00380 CALL 1BB3H
00390 RST 10H
00400 CALL 0E65H
00410 CALL 09FCH
00420 LD DE,TACCUM
00430 LD HL,411DH
00440 LD B,8
00450 CALL 09D7H
00460 LD A,(FUNCT)
00470 CP 2BH
00480 JR Z,ADD
00490 CP 2DH
00500 JR Z,SUB
00510 CP 2AH
00520 JR Z,MULT
00530 CP 2FH
00540 JR Z,DIVIDE
00550 VIDEO LD A,3DH
00560 CALL 032AH
00570 LD A,20H
00580 CALL 032AH
00590 CALL 0FBDH
00600 CALL 28A7H
00610 LD A,0DH
00620 CALL 032AH
00630 JR BEGIN
00640 ADD CALL 0C77H
00650 JR VIDEO
00660 SUB CALL 0C70H
00670 JR VIDEO
00680 MULT CALL 0DA1H
00690 JR VIDEO
00700 DIVIDE CALL 0DE5H
00710 JR VIDEO
00720 FUNCT DEFB 0
00730 TACCUM DEFB 8
00740 END W4UCH
7D00
7D00
7D00 3E4F
7D02 CD2A03
7D05 3E3F
7D07 CD2A03
7D0A 3E20
7D0C CD2A03
7D0F CD4900
7D12 CD2A03
7D15 328C7D
7D18 3E0D
7D1A CD2A03
7D1D 3E46
7D1F CD2A03
7D22 CDB31B
7D25 D7
7D26 CD650E
7D29 111D41
7D2C 218D7D
7D2F 0608
7D31 CDD709
7D34 3E53
7D36 CD2A03
7D39 CDB31B
7D3C D7
7D3D CD650E
7D40 CDFC09
7D43 118D7D
7D46 211D41
7D49 0608
7D4B CDD709
7D4E 3A8C7D
7D51 FE2B
7D53 2823
7D55 FE2D
7D57 2824
7D59 FE2A
7D5B 2825
7D5D FE2F
7D5F 2826
7D61 3E3D
7D63 CD2A03
7D66 3E20
7D68 CD2A03
7D6B CDBD0F
7D6E CDA728
7D71 3E0D
7D73 CD2A03
7D76 1888
7D78 CD770C
7D7B 18E4
7D7D CD700C
7D80 18DF
7D82 CDA10D
7D85 18DA
7D87 CDE50D
7D8A 18D5
7D8C 00
0008
7D00

```

- CHAPTER 3 -USING LEVEL II ROM SUBROUTINES
IN ADVANCED ASSEMBLY LANGUAGE PROGRAMMING

- TRIGONOMETRIC, LOG, EXPONENT, ET AL FUNCTIONS -

(notes from a lecture)

Here is an interesting test program for the advanced assembly language programmer. It allows the user to access and test many of the myriad arithmetic/trigonometric subroutines that are extant in the excellent TRS-80 Level II ROM that was written by Microsoft's Bill Gates and Paul Allen.

The beginning assembly language programmer should certainly be taught and learn the how, why, and wherefores of writing fundamental arithmetic/trig functions by him/her self, but once these techniques have been mastered as part of the learning process, it is certainly inefficient, time wasting, and rather ridiculous to re-invent the wheel by duplicating in assembly language those subroutines already extant in the Level II ROM.

Table 1 lists those functions and their addresses that may be accessed and tested by this mini-program that only occupies 144 bytes of high memory and may be entered using the TRS-80 Editor/Assembler in about 5 minutes.

Figure 13 is a print-out of the test program's source code and Figure 14 a listing of the program's object code. As may be easily seen, the majority of this program is written using Level II ROM subroutines. Were these subroutines not used in this particular assembly language test program, it would require approximately 10 times as much program memory and occupy 550 rather than 55 assembly language program lines.

PROGRAM FLOW:

The comments included with the source code program delineate each line's function. There is no need to duplicate or expand upon the comments here as they are largely self-explanatory. This program operates equally well with non-disk Level II, DOS 2.1, DOS 2.2 and NEWDOS+. Program operation is as follows:

1. Load the program under the SYSTEM or DOS command. Give it any name you wish. We like the program name DISCOV, for discovery, since that is what the program is all about. After loading is complete, type in /32000 to activate the program (with disk you must first load BASIC, then type SYSTEM, ENTER, and then type in /32000 ENTER, if you loaded the program in DOS).

2. The letter 'N' ? will appear on video. The program is asking you for a number to work on. Any number up to 16 digits is alright depending on the function you wish to test. Let us start out with a simple example by entering the number 10000, a nice round easily visualized number, ENTER.
3. The numbers '2' '10000' will appear on the next line of the video display. The '2' is the number 'type' brilliantly calculated by the Level II ROM. Since we are dealing only with numbers in this Chapter we will blithely skip over strings et al for the time being. The number types are as follows: 2 = integer, 4 = single precision, and 8 = double precision. Table 1 lists those operations that can be performed on a number for a given number type; i.e., it is against the rules to take the square root SQR of an integer. We must first change to single precision.
4. On the following line of the video display you will see 'C ? '. The program is asking you what type of CONVERSION you wish. Let's enter 2737 which = CSNG, change our number from an integer to single precision, ENTER. The next line will show, '4' '1000'. We now have a single precision number to work with, so let's now try taking its square root by typing in 5095 = SQR, then ENTER. ZAP... ...the next line shows '100'. Ah, the miracle of modern computer science at work. It sure was easier than writing a complete stand alone assembly language square root subroutine. Let's try it again. Type in 5095 ENTER. Again the line below displays the square root. This time the numeral 10.
5. Stick around as this is only the beginning. To insert a new number to try your program on merely type in 32000 ENTER. This brilliantly brings us back to where we started by displaying 'N ?'. Is 32000 a subroutine? Sure it is. You wrote it. Our assembly language program does not discriminate between ROM or RAM. It could care less.
6. We could go on and on converting numbers like deriving the natural LOG of any number and then restoring it with the EXP command, and/or deriving the TANGent of a number, then its arc tangent ATN, and then the TANGent againad infinitum. You may escape this conversion routine any time you wish by typing 6681 ENTER which will take you back to BASIC with a READY displayed. All you need do to return to your conversion routine is type SYSTEM then ENTER and type /32000 then ENTER.

This lecture covers only a few of the subroutines extant in Level II BASIC ROM that are illustrated in Table 1.

Assembly language programming is the ne plus ultra of serious computing and really the Mt. Everest of our hobby. You master it and you climb it because it is there. The fallout of having any assembly language program run 300 times faster than the same program in BASIC, and the extra plus of only using 1/10th as much memory as the same program in BASIC are really the topping/icing of the cake.

Learning to talk to your computer in its own language rather than through an interpreter (BASIC, Fortran, Pascal, or what-have-you), is probably one of the most satisfying and rewarding experiences you will ever have if you have the patience and fortitude to master it.

ADDENDUM:

The demonstration program illustrated in Figure 13 will easily perform many more functions than the short list covered in Table 1. Make a note to come back to this program after you have finished Chapter 4 and have become familiar with data movement and data conversion subroutines.

Most all of the arithmetic + - * / subroutines using integer, single precision, and double precision numbers may be used by judiciously storing one number in "CS", the CDBL Store. -CALL 2556 decimal = 09FCH moves data from the ACCUM to "CS". The next number is then input by loading "32000" into CONV ? and then entering this number in the ACCUM.

By keeping close track of the NT (number type) so you call the appropriate arithmetic/conversion subroutine, and using the data movement subroutines covered in the next chapter, it is quite easy for this demo program to calculate LOG to the base 10, manipulate trig functions as desired, etc. Though you will never write a real-time program such as that given in Figure 13, it nevertheless offers you an excellent opportunity to practice and become familiar with Chapter 4's data conversion and data movement subroutines. Besides, it is an intellectual challenge....and challenges are fun when you WIN.

note: number types 2 = integer 4 = single precision
8 = double precision

| FUNCTION | NUMBER TYPE | DECIMAL | HEXADECIMAL |
|------------------|-----------------|---------|-------------|
| ABS | 2-4-8 | 2423 | 0977 |
| ATN | 4-8 | 5565 | 15BD |
| BASIC | (RETURN L II) | 6681 | 1A19 |
| BASIC | (RETURN DISK) | 112 | 0075 |
| BREAK | (RST ADDRESS) | 16396 | 400C |
| CDBL | 2-4 | 2779 | 0ADB |
| CINT | 4-8 | 2687 | 0A7F |
| CLS | 2-4-8 | 457 | 01C9 |
| COS | 4-8 | 5441 | 1541 |
| CSNG | 2-8 | 2737 | 0AB1 |
| EXP | 4-8 | 5177 | 1439 |
| FIX | 2-4 | 2854 | 0B26 |
| INT | 2 | 2871 | 0B37 |
| INVERT SIGN | 2 | 3153 | 0C51 |
| INVERT SIGN | 4-8 | 2434 | 0982 |
| LOG | 4-8 | 2057 | 0809 |
| MEMORY | (DEFINE SIZE) | 181 | 00B5 |
| RANDOM | 2-4-8 | 467 | 01D3 |
| RETURN | (TO SUBROUTINE) | 32000 | 7D00 |
| RND (see limits) | 2-4-8 | 5321 | 14C9 |
| SGN | 2 | 2442 | 098A |
| SIN | 4-8 | 5447 | 1547 |
| SQR | 4-8 | 5095 | 13E7 |
| TAN | 4-8 | 5544 | 15A8 |

- TABLE 1 -

| | | | | |
|-------|--------|------|-----------|---------------------------------|
| 00100 | W4UCH | EQU | 7D00H | ;7D00H = 32000 DECIMAL -PAGE 27 |
| 00110 | | ORG | W4UCH | ;PROGRAM WILL START HERE |
| 00120 | | LD | A,4EH | ;4EH="N"=NUMBER DESIRED ? |
| 00130 | | CALL | 032AH | ;DISPLAY "N" ON VIDEO |
| 00140 | | CALL | 1BB3H | ;KYBD/VIDEO INPUT ROUTINE |
| 00150 | | RST | 10H | ;SCAN STRING - SET C FLAG |
| 00160 | | CALL | 0E6CH | ;ASCII-ACCUM RET MINIMUM |
| 00170 | RETURN | EX | AF,AF' | ;EXCHANGE REGISTERS- |
| 00180 | | EXX | | ;TO PRESERVE VALUES. |
| 00190 | | LD | DE,411DH | ;MOVE MEM ACCUM DATA FROM |
| 00200 | | LD | HL,STORE | ;TO TEMPORARY STASH. |
| 00210 | | LD | B,8 | ;NUMBER OF BYTES TO MOVE |
| 00220 | | CALL | 09D7H | ;MOVE IT - SUBROUTINE |
| 00230 | | LD | DE,4127H | ;MOVE CDBL DATA FROM- |
| 00240 | | LD | HL,CDBL | ;TO TEMPORARY STASH. |
| 00250 | | LD | B,8 | ;NUMBER OF BYTES TO MOVE |
| 00260 | | CALL | 09D7H | ;MOVE IT - SUBROUTINE |
| 00270 | | LD | A,(40AFH) | ;NUMBER TYPE MEM LOCATION |
| 00280 | | LD | (FLAG),A | ;MOVE TO TEMPORARY STASH |
| 00290 | | ADD | A,48 | ;CONVERT TO ASCII NUMBER |
| 00300 | | CALL | 032AH | ;DISPLAY NUMBER TYPE |
| 00310 | | LD | A,20H | ;20H = ASCII SPACE |
| 00320 | | CALL | 032AH | ;DISPLAY SPACE ON VIDEO |
| 00330 | | CALL | 0FBDH | ;CONV MEM ACCUM TO ASCII\$ |
| 00340 | | CALL | 28A7H | ;DISPLAY CONVERTED NUMBER |
| 00350 | | LD | A,0DH | ;0DH=SKIP A LINE/CARR RTN |
| 00360 | | CALL | 032H | ;DO IT - ON VIDEO DISPLAY |
| 00370 | | LD | A,43H | ; "C" = CONVERSION NUMBER? |
| 00380 | | CALL | 32AH | ;DISPLAY "C" ON VIDEO |
| 00390 | | CALL | 1BB3H | ;KYBD/VIDEO INPUT ROUTINE |
| 00400 | | RST | 10H | ;SCAN STRING - SET C FLAG |
| 00410 | | CALL | 0E6CH | ;ASCII-ACCUM RET MINIMUM |
| 00420 | | CALL | 0A7FH | ;CONVERT TO INTEGER |
| 00430 | | LD | (CONV),HL | ;STORE CONVERSION ADDRESS |
| 00440 | | LD | DE,CDBL | ;MOVE CDBL DATA FM STASH- |
| 00450 | | LD | HL,4127H | ;TO PERMANENT ADDRESS. |
| 00460 | | LD | B,8 | ;NUMBER OF BYTES TO MOVE |
| 00470 | | CALL | 09D7H | ;MOVE IT - SUBROUTINE |
| 00480 | | LD | DE,STORE | ;MOVE MEM ACCUM FM STASH- |
| 00490 | | LD | HL,411DH | ;TO PERMANENT ADDRESS. |
| 00500 | | LD | B,8 | ;NUMBER OF BYTES TO MOVE |
| 00510 | | CALL | 09D7H | ;MOVE IT - SUBROUTINE |
| 00520 | | LD | A,(FLAG) | ;NUMBER TYPE FROM STASH- |
| 00530 | | LD | (40AFH),A | ;TO PERMANENT ADDRESS. |
| 00540 | | LD | HL,RETURN | ;RETURN MEM LOCATION- |
| 00550 | | PUSH | HL | ;LOADED INTO STACK. |
| 00560 | | LD | HL,(CONV) | ;CONVERSION MEM LOCATION- |
| 00570 | | PUSH | HL | ;LOAD ON TOP OF STACK. |
| 00580 | | EX | AF,AF' | ;RESTORE REGISTERS- |
| 00590 | | EXX | | ;TO ORIGINAL VALUES. |
| 00600 | | RET | | ;SNEAKY CALL-TOP OF STACK |
| 00610 | FLAG | DEFS | 1 | ;NUMBER TYPE STASH |
| 00620 | CONV | DEFS | 2 | ;CONVERSION ADDRESS STASH |
| 00630 | CDBL | DEFS | 8 | ;CDBL DATA STASH |
| 00640 | STORE | DEFS | 8 | ;ACCUMULATOR STASH |
| 00650 | | END | W4UCH | ;AMATEUR RADIO CALL LTRS |

| | | | | |
|------|-------|--------|------|-----------|
| 7D00 | 00100 | W4UCH | EQU | 7D00H |
| 7D00 | 00110 | | ORG | W4UCH |
| 7D00 | 00120 | | LD | A,4EH |
| 7D02 | 00130 | | CALL | 032AH |
| 7D05 | 00140 | | CALL | 1BB3H |
| 7D08 | 00150 | | RST | 10H |
| 7D09 | 00160 | | CALL | 0E6CH |
| 7D0C | 00170 | RETURN | EX | AF,AF' |
| 7D0D | 00180 | | EXX | |
| 7D0E | 00190 | | LD | DE,411DH |
| 7D11 | 00200 | | LD | HL,STORE |
| 7D14 | 00210 | | LD | B,8 |
| 7D16 | 00220 | | CALL | 09D7H |
| 7D19 | 00230 | | LD | DE,4127H |
| 7D1C | 00240 | | LD | HL,CDBL |
| 7D1F | 00250 | | LD | B,8 |
| 7D21 | 00260 | | CALL | 09D7H |
| 7D24 | 00270 | | LD | A,(40AFH) |
| 7D27 | 00280 | | LD | (FLAG),A |
| 7D2A | 00290 | | ADD | A,48 |
| 7D2C | 00300 | | CALL | 032AH |
| 7D2F | 00310 | | LD | A,20H |
| 7D31 | 00320 | | CALL | 032AH |
| 7D34 | 00330 | | CALL | 0FBDH |
| 7D37 | 00340 | | CALL | 28A7H |
| 7D3A | 00350 | | LD | A,0DH |
| 7D3C | 00360 | | CALL | 032H |
| 7D3F | 00370 | | LD | A,43H |
| 7D41 | 00380 | | CALL | 32AH |
| 7D44 | 00390 | | CALL | 1BB3H |
| 7D47 | 00400 | | RST | 10H |
| 7D48 | 00410 | | CALL | 0E6CH |
| 7D4B | 00420 | | CALL | 0A7FH |
| 7D4E | 00430 | | LD | (CONV),HL |
| 7D51 | 00440 | | LD | DE,CDBL |
| 7D54 | 00450 | | LD | HL,4127H |
| 7D57 | 00460 | | LD | B,8 |
| 7D59 | 00470 | | CALL | 09D7H |
| 7D5C | 00480 | | LD | DE,STORE |
| 7D5F | 00490 | | LD | HL,411DH |
| 7D62 | 00500 | | LD | B,8 |
| 7D64 | 00510 | | CALL | 09D7H |
| 7D67 | 00520 | | LD | A,(FLAG) |
| 7D6A | 00530 | | LD | (40AFH),A |
| 7D6D | 00540 | | LD | HL,RETURN |
| 7D70 | 00550 | | PUSH | HL |
| 7D71 | 00560 | | LD | HL,(CONV) |
| 7D74 | 00570 | | PUSH | HL |
| 7D75 | 00580 | | EX | AF,AF' |
| 7D76 | 00590 | | EXX | |
| 7D77 | 00600 | | RET | |
| 0001 | 00610 | FLAG | DEFS | 1 |
| 0002 | 00620 | CONV | DEFS | 2 |
| 0008 | 00630 | CDBL | DEFS | 8 |
| 0008 | 00640 | STORE | DEFS | 8 |
| 7D00 | 00650 | | END | W4UCH |

- CHAPTER 4 -

ANCILLARY LEVEL II ROM SUBROUTINES

INTRODUCTION:

Chapters 2 and 3 used a number of Level II ROM ancillary subroutines that were not fully explained except for a few words in the source code comment column. Using Level II ROM BASIC functions' CALL subroutines efficiently requires a modest understanding of how to use other ancillary ROM subroutines that are there just waiting to be used. They include: KEYBOARD input, MOVE data, COMPARE data, CONVERT data, VIDEO output, and LINE PRINTER output amongst others. This chapter will present the CALL addresses and briefly explain the most useful ROM ancillary subroutines that will truly make shorthand assembly language programming a reality for you.

KEYBOARD REVIEW:

Every advanced assembly language programmer knows that the keyboard is simply nothing more than a key/switch matrix that "looks like" RAM memory to Level II ROM. The keyboard's eight MEM locations are shown below in decimal. UA = up arrow, DA = down arrow, LA = left arrow and RA = right arrow.

| | | | | | | | | | |
|--------------|---|-------|-----|-----|----|----|----|----|-----|
| PEEK (14337) | = | @ | A | B | C | D | E | F | G |
| PEEK (14338) | = | H | I | J | K | L | M | N | O |
| PEEK (14340) | = | P | Q | R | S | T | U | V | W |
| PEEK (14344) | = | X | Y | Z | | | | | |
| PEEK (14352) | = | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| PEEK (14368) | = | 8 | 9 | : | ; | , | - | . | / |
| PEEK (14400) | = | ENT | CLR | BRK | UA | DA | LA | RA | SPA |
| PEEK (14464) | = | SHIFT | | | | | | | |

| | | | | | | | | | |
|-------|---|---|---|---|---|----|----|----|-----|
| VALUE | = | 1 | 2 | 4 | 8 | 16 | 32 | 64 | 128 |
|-------|---|---|---|---|---|----|----|----|-----|

The keyboard/switch matrix will output the VALUES shown above when a single key is pressed at the corresponding MEM location. For multiple keys pressed simultaneously, add up the values for each key; i.e., "JKL" = 4 + 8 + 16 = 28 total at MEM location 14338 decimal. With these facts in hand it is easy to see how very simply NEWDOS+ includes the feature of line printing out the video display contents whenever "JKL" are pressed simultaneously. Now, go write a brief assembly language program that will do so with non-disk Level II. For the inveterate experimenter, try this little 1 line program and press any combination of keys in the PEEK(14338) row:

```
10 X=PEEK(14338):PRINT@478,X:GOTO10
```

The 3 most useful Level II ROM ancillary subroutines for the keyboard follow. CALL locations are in hex.

CALL 002B: This is the most fundamental keyboard subroutine that scans the entire key board and returns the ASCII character in the "A" register. A JR Z loop must be created to repeat the scan as shown below:

```

      KYBD          CALL      002BH
                      CP      00
                      JR      Z,KYBD

```

Whenever a key is pressed, the CP (compare) "A" register with 00H is NOT zero so the program falls through to the line following JR Z,KYBD. This was the most commonly used keyboard subroutine by early assembly language programmers who did not know any better. It is seldom used any longer.

CALL 0049: This is the ROM subroutine most similar to BASIC's INKEY\$ function. It automatically scans the keyboard UNTIL a key is pressed and then places the value in "A" register. No assembly language loop subroutine is required. A giant step forward from the 002BH fundamental keyboard CALL.

CALL 1BB3: This is the big bazoo keyboard subroutine you will be using most frequently. It first displays the "?" prompt. Then input via the keyboard is converted to string format and terminated with a zero (up to 240 bytes). This string is stored at 40A7H + string length. It is usually followed by an RST 10 which sets the "C" flag. See the programs in Chapters 2 and 3 which use this call. This call automatically outputs keyboard input to the device specified by the contents of MEM location (409CH): -1 = cassette, 0 = video display and +1 = line printer. ROM initializes (409CH)=0. This subroutine is surely one of the most time saving, valuable, and frequently used ROM subroutines you will be using henceforth. A single CALL 1BB3H will replace dozens of lines, if not pages, of assembly language programming for you.

DATA MOVEMENT:

Level II ROM ancillary subroutines exist for moving data in assembly language programs FROM - TO virtually any and all locations conceivable, often with only a single CALL. They are tremendous time and line savers and well worth becoming acquainted with on a first-hand basis.

One of the most useful data movement subroutines is that given in the data movement table's first line, CALL 09A4H. This CALL automatically transfers either an integer or single precision number from the ACCUM at MEM locations 411DH through 4124DH to the stack. POP BC and then POP DE will retrieve the number. NOTE: Add, CALL 1C90H to compare table next page (HL-DE NT=2).

If the number is single precision, registers BCDE will contain it. If an integer, register DE will hold the number.

Though ALL the data movement subroutines are very useful, those in lines "J" and "K" deserve special note. Each will MOVE up to 255 bytes from (DE) to (HL). The subroutine at "J" requires that the number of bytes to be moved be in the "A" register, and the subroutine at "K" requires that the number of bytes to be moved be in the "B" register.

NT = number type which is stored in MEM at 40AFH: 2 = integer, 4 = double precision, and 8 = double precision. CS=CDBL store.

- DATA MOVEMENT TABLE -

| NO. | FROM | TO | CALL | NT(40AFH) |
|-----|-------|-------|------------|-----------|
| A. | ACCUM | STACK | 09A4H/2468 | 2,4 |
| B. | (HL)+ | ACCUM | 09B1H/2481 | 4 |
| C. | BCDE | ACCUM | 09B4H/2484 | 4 |
| D. | ACCUM | BCDE | 09BFH/2495 | 4 |
| E. | (HL)+ | BCDE | 09C2H/2498 | 4 |
| F. | ACCUM | (HL)+ | 09CBH/2507 | 4 |
| G. | (DE)+ | (HL)+ | 09CEH/2510 | 4 |
| H. | (HL)+ | (DE)+ | 09D2H/2514 | 2,4,8 |
| I. | (DE)+ | (HL)+ | 09D3H/2515 | 2,4,8 |
| J. | (DE)+ | (HL)+ | 09D6H/2518 | A REG |
| K. | (DE)+ | (HL)+ | 09D7H/2519 | B REG |
| L. | "CS" | ACCUM | 09F4H/2548 | 2,4,8 |
| M. | ACCUM | "CS" | 09FCH/2556 | 2,4,8 |
| N. | HL | ACCUM | 0A9AH/2714 | 2 |
| O. | DE | HL | EX DE,HL | 2 |
| P. | HL | DE | EX DE,HL | 2 |
| Q. | BC | STACK | PUSH BC | 2,4 |
| R. | DE | STACK | PUSH DE | 2,4 |
| S. | HL | STACK | PUSH HL | 2 |
| T. | STACK | HL | POP HL | 2 |
| U. | STACK | DE | POP DE | 2,4 |
| V. | STACK | BC | POP BC | 2,4 |

NOTE: Lines "O" through "V" are just plain old Z-80 OPCODES, but are included to remind the programmer that when dealing with integers or single precision numbers they often are the simplest means of moving or temporarily storing data. See Chapter 2 where PUSH and POP are used to store both integer and single precision numbers while these registers are being used for other purposes.

DATA COMPARISONS:

Of equal to, less than, and greater than are some of the most frequently used functions in computer programming. Level II ROM very thoughtfully includes these functions that may be performed with a single CALL. The result is returned in the "A" register and = zero if the compare is equal, = +1 if the compare is >, and = 255 (OFFH) if the compare is <.

- COMPARE TABLE -

| NO. | ITEM #1 | SUBTRACT | ITEM #2 | CALL | NT(40AFH) |
|-----|---------|----------------|---------|-------|-----------|
| A. | ACCUM | - | BCDE | 0A0CH | 4 |
| B. | HL | - | DE | 0A39H | 2 |
| C. | ACCUM | - | "CS" | 0A4FH | 8 |
| D. | "CS" | - | ACCUM | 0A78H | 8 |
| E. | ACCUM | DETERMINE SIGN | | 0994H | 2,4,8 |

NOTE: No. E above is same as the BASIC SGN function, but returns to register "A": zero if ACCUM = 0, +1 if ACCUM greater than zero, and 255 (0FFH) if ACCUM is less than zero.

- DATA CONVERSIONS -

Are straightforward and very necessary in most all arithmetic operations as the NT (number type) must match-up with the CALL subroutine's function; i.e., integer, single precision or double precision + - * /. The most useful conversions are:

CALL 0A7FH: any ACCUM to integer ACCUM (CINT).
 CALL 0AB1H: any ACCUM to single precision ACCUM (CSNG).
 CALL 0ACCH: integer ACCUM to single precision ACCUM.
 CALL 0ACFH: integer HL to single precision ACCUM.
 CALL 0ADBH: any ACCUM to double precision ACCUM.
 CALL 0E65H: ASCII string to ACCUM in double precision format.
 CALL 0E6CH: ASCII string to ACCUM; NT will = minimum required.

- ARITHMETIC CALL SUMMARY -

| | INTEGER NO. | SINGLE PRECISION | DOUBLE PRECISION |
|----------|----------------------|--------------------------|--------------------------|
| ADDITION | 0BD2H/3026 DE+HL | 0716H/1814 BCDE+ACCUM | 0C77H/3191 ACCUM+"CS" |
| SUBTRACT | 0BC7H/3015 DE-HL | 0713H/1811 BCDE-ACCUM | 0C70H/3184 ACCUM-"CS" |
| MULITPLY | 0BF2H/3058 DE*HL | 0847H/2119 BCDE*ACCUM | 08A2H/2210 ACCUM*"CS" |
| DIVIDE | 2490H/10560 DE/HL | 08A2H/2210 BCDE/ACCUM | 0DE5H/3557 ACCUM/"CS" |

NOTE: NT (number type) at (40AFH) must agree with operation CALLED. NT: 2 = integer, 3 = string, 4 = single precision, and 8 = double precision.

* ACCUM at MEM locations 411DH through 4124H.

* "CS" = CDBL Store at MEM 4127H through 41.EH.

- VIDEO DISPLAY -

Most all TRS-80 video display subroutines have been well known to computer buffs the last 2 years, including the fundamental ROM video subroutine, CALL 033H which display the "A" register on video. CALL 032AH also displays the "A" register on video if MEM location 409CH contains a zero which is the value stored upon initialization. Most IMPORTANTLY, CALL 032AH does indeed store the video display LINE cursor position at MEM location 40A6H which is very useful and eliminates redundant programming on your part.

One of the most important subroutines for reflecting keyboard input on video is CALL 1BB3H which was covered earlier in this Chapter. This CALL displays the string beginning at (HL) and terminated with a zero on video if MEM location 409CH contains a zero. The video display control block, page D/1, Level II Manual in conjunction with the line cursor position at 40A6H allows you to modify and/or use the video display as you wish.

One of the more fascinating assembly language exercises using the video display, is to write a "tight" source code program that creates SPLIT-SCREEN video operation. The upper half of the video display serves as the RECEIVE sector for Morse code, radio teletype (ASCII now allowed), or even simple phone line MODEM communications, while the lower half of the video display would serve as the TRANSMIT segment. This segment allows the user either "look-ahead" or "type-ahead" FIFO (first-in-first-out) operation from RAM at whatever output baud rate desired. If you have the upper-case/lower-case modification recommended by Electric Pencil, it is a simple matter to have those characters that have already been transmitted in upper-case, and those characters yet to be transmitted in lower-case. Alternatively, a moving cursor or a moving CHR\$(170) figure may be used to indicate what data has been transmitted versus data yet to be transmitted in the TRANSMIT sector of the video display. Both halves of the video display operate entirely independently; i.e., from their own separate video MEMs in RAM with their own scrolling, etc. The transmit sector utilizes the Z-80's interrupt mode for "type-ahead" simplex operation. Remember, video memory is just plain old RAM and may be used for storage (as in FIFO) just like any other RAM memory segment.

- LINE PRINTER -

Much like the video display, there are few significant new surprises about line printer ROM subroutines. Again, the value stored in MEM location 409CH determines where the output from CALL 032AH & 1BB3H keyboard subroutines goes; i.e., if (409CH) contains +1, the output will go to the line printer. As shown on page D/1 of the Level II Manual, the line printer address is 37E8H and line printer control block from MEM locations 4025H to 402CH. MEM location 37E8H will contain the

value 63 decimal = ASCII ? when your line printer is ready to accept another character (handshake). A few cheap surplus printers do not have this handshake feature and should be avoided like the plague; caveat emptor, especially with old DATEL printers of ALL types and ALL varieties. Old DATEL printers, even those with the handshake feature do not even make good boat anchors for small dinghys. As soon as MEM location 37E8H receives the 63 handshake from your line printer it is ok (in most cases) to load the next character to be printed into (37E8H) via "A" register and the LD opcode. An exception to this rule is illustrated in Chapter 7's "Print All Zeros With A Slash Program," where an extra 20 millisecond delay was required to allow the vibration from a BACKSPACE to dampen/die out.

This slash/zero program has not been previously published and illustrates a few interesting points about line printer programming. It intercepts the NEXT character to be printed by modifying the line printer driver address at 4026H and 4027H to allow a moment's branching to this brief routine. It just so happens that the "C" register contains the NEXT character to be printed when using the LLIST command with non-disk Level II, DOS 2.1, DOS 2.2, and NEWDOS+, as well as the NEWDOS+ "JKL" feature that LPRINTS the contents of the video display. By simply testing the next character to be printed, a variety of options are made available to the programmer.

To illustrate a few points, let us assume that your line printer utilizes IBM's highest-quality heavy-duty Selectric mechanism like the Western I/O (IBM #2970) Printer Terminal for the TRS-80 that sells for \$1100. Only 8 years ago, these IBM #2970's sold new for over \$7000. each, so here is the industry's most cost-effective printer that is completely refurbished, on the market today. It is the ne plus ultra for those who demand IBM quality print out in both lower and upper case, in addition to the decided advantage of being able to use any or all of the myriad type faces offered in inexpensive IBM Selectric snap-in type spheres.

Even the excellent ASCII IBM type spheres do not include the zero with a slash across it as it looks mighty STRANGE indeed to non-computer types reading a business letter. In some program listings though, it is of considerable assistance to the reader to have the slash/zero printed as such, to avoid confusing zeros with capital "O". Chapter 7's short program prints all zeros with a slash and all lines with 64 characters. It may be modified to print all > = GT and all < = LT, etc., as desired. As it is a teaching program, it may be compacted considerably. Try cutting it down by 1/3rd.

* NOTE: the author, editor, and publisher have done their utmost to find and eliminate typographical errors, but would very much appreciate hearing from readers who find errors we have overlooked. With well over 1,000,000 bytes of data in this handbook, some have surely slipped by us.

CHAPTER 5

-SUMMARY OF LEVEL II ROM CALL ADDRESSES IN ALPHABETICAL ORDER-

This summary includes the coupling CALL addresses for DOS and Disk BASIC because they are called from Level II ROM. In addition, the link address for BREAK is included as it may be intercepted at 400CH before calling an RST and either rendered inoperative or used for whatever purpose the programmer wishes. One extra bonus for disk users under the heading "MASTER" is the master password "F3GUM," which will allow you to access ANY protected file in either DOS or Disk Basic when using DOS 2.1, DOS 2.2, or NEWDOS+. Thank you Manny Garcia. Every lock has a key and "F3GUM" will allow you to LOAD, KILL, transfer or do whatever you wish with any disk file/program whether SIP (system-invisible-protected) or otherwise.

| BASIC FUNCTION | HEX CALL ADDRESS | BASIC FUNCTION | HEX CALL ADDRESS |
|-------------------|---------------------|-------------------|---------------------|
| ABS | 0977 | &H | 4194 |
| ASC | 2A0F | ATN | 15BD |
| AUTO | 2008 | BREAK | 400C |
| CDBL | 0ADB | CHR\$ | 2A1F |
| CINT | 0A7F | CLEAR | 1E7A |
| CLOAD | 2C1F | CLOSE | 4185 |
| CLS | 01C9 | CMD | 4173 |
| CONT | 1DE4 | COS | 1541 |
| CSAVE | 2BF5 | CSNG | 0AB1 |
| CVD | 415E | CVI | 4152 |
| CVS | 4158 | DATA | 1F05 |
| DEF | 415B | DEFDBL | 1E09 |
| DEFINT | 1E03 | DEFSNG | 1E06 |
| DEFSTR | 1E00 | DELETE | 2BC6 |
| DIM | 2608 | EDIT | 2E60 |
| ELSE | 1F07 | END | 1DAE |
| EOF | 4161 | ERL | 24DD |
| ERR | 24CF | ERROR | 1FF4 |
| EXP | 1439 | FIELD | 417C |
| FIX | 0B26 | FOR | 1CA1 |
| FN | 4155 | FRE | 27D4 |
| GET | 417F | GOSUB | 1EB1 |
| GOTO | 1EC2 | IF | 2039 |
| INKEY\$ | 019D | INP | 2AEF |
| INPUT | 219A | INSTR | 419D |
| INT | 0B37 | KILL | 4191 |
| LEFT\$ | 2A61 | LEN | 2A03 |
| LET | 1F21 | LINE | 41A3 |
| LIST | 2B2E | LOAD | 4188 |

| BASIC FUNCTION | HEX CALL ADDRESS | BASIC FUNCTION | HEX CALL ADDRESS |
|-------------------|---------------------|-------------------|---------------------|
| LOC | 4164 | LOF | 4167 |
| LOG | 0809 | LLIST | 2B29 |
| LPRINT | 2067 | LSET | 4197 |
| MASTER | F3GUM | MEM | 27C9 |
| MERGE | 418B | MID\$ | 2A9A |
| MKD\$ | 4170 | MKI\$ | 416A |
| MKS\$ | 416D | NAME | 418E |
| NEW | 1B49 | NEXT | 22B6 |
| NOT | 25C4 | ON | 1F6C |
| OPEN | 4179 | OUT | 2AFB |
| PEEK | 2CAA | POINT | 0133 |
| POKE | 2CB1 | POS | 27F5 |
| PRINT | 206F | PUT | 4218 |
| RANDOM | 01D3 | READ | 21EF |
| REM | 1F07 | RESET | 0138 |
| RESTORE | 1D91 | RETURN | 1EDE |
| RESUME | 1FAF | RIGHT\$ | 2A91 |
| RND | 14C9 | RSET | 419A |
| RUN | 1EA3 | SAVE | 41A0 |
| SET | 0135 | SGN | 098A |
| SIN | 1547 | SQR | 13E7 |
| STOP | 1DA9 | STR\$ | 2836 |
| STRING\$ | 2A2F | SYSTEM | 02B2 |
| TAN | 15A8 | TIMES | 4176 |
| TROFF | 1DF8 | TRON | 1DF7 |
| USR | 27FE | VARPTR | 24EB |
| VAL | 2AC5 | | |

NOTE: If you are doing a considerable amount of assembly language programming, we suggest you Xerox these two pages and paste-up a single sheet with the entire CALL functions and addresses on it as they would not fit on a single typed page.

* footnote:

ELSE = 1F07 hex is questionable even though ROM points to this address. ROM also points to 1F07 for the REM function which appears correct. It may be only an improperly shadow-masked bit on this particular Level II ROM chip.

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|--------------------|
| 0000 | F3AF | C374 | 06C3 | 0040 | C300 | 40E1 | E9C3 | 9F06 |@...@..... |
| 0010 | C303 | 40C5 | 0601 | 182E | C306 | 40C5 | 0602 | 1826 | ..@.....@.....& |
| 0020 | C309 | 40C5 | 0604 | 181E | C30C | 4011 | 1540 | 18E3 | !..@.....@...@.. |
| 0030 | C30F | 4011 | 1D40 | 18E3 | C312 | 4011 | 2540 | 18DB | ..@...@.....@.8@.. |
| 0040 | C3D9 | 05C9 | 0000 | C3C2 | 03CD | 2B00 | B7C0 | 18F9 |+..... |
| 0050 | 0D0D | 1F1F | 0101 | 5B1B | 0A1A | 0818 | 0919 | 2020 | |
| 0060 | 0B78 | B120 | FBC9 | 3100 | 063A | EC37 | 3CFE | 02D2 |1...:7<... |
| 0070 | 0000 | C3CC | 0611 | 8040 | 21F7 | 1801 | 2700 | EDB0 |@!.....'... |
| 0080 | 21E5 | 4136 | 3A23 | 7023 | 362C | 2322 | A740 | 112D | !.A6:##.#6,##".@.- |
| 0090 | 0106 | 1C21 | 5241 | 36C3 | 2373 | 2372 | 2310 | F706 | ...!RA6.##.##... |
| 00A0 | 1536 | C923 | 2323 | 10F9 | 21E8 | 4270 | 31F8 | 41CD | .6.###...!.B.1.A. |
| 00B0 | 8F1B | CDC9 | 0121 | 0501 | CDA7 | 28CD | B31B | 38F5 |!.....(...8. |
| 00C0 | D7B7 | 2012 | 214C | 4323 | 7CB5 | 281B | 7E47 | 2F77 |!LC#..(..G/. |
| 00D0 | BE70 | 28F3 | 1811 | CD5A | 1EB7 | C297 | 19EB | 2B3E | ..(.....Z.....+> |
| 00E0 | 8F46 | 77BE | 7020 | CE2B | 1114 | 44DF | DA7A | 1911 | .F.....+..D..... |
| 00F0 | CEFF | 22B1 | 4019 | 22A0 | 40CD | 4D1B | 2111 | 01CD | ..".@."..@.M.!... |
| 0100 | A728 | C319 | 1A4D | 454D | 4F52 | 5920 | 5349 | 5A45 | .(...MEMORY.SIZE |
| 0110 | 0052 | 4144 | 494F | 2053 | 4841 | 434B | 204C | 4556 | .RADIO.SHACK.LEV |
| 0120 | 454C | 2049 | 4920 | 4241 | 5349 | 430D | 001E | 2CC3 | EL.II.BASIC...., |
| 0130 | A219 | D7AF | 013E | 8001 | 3E01 | F5CF | 28CD | 1C2B |>...>...(+ |
| 0140 | FE80 | D24A | 1EF5 | CF2C | CD1C | 2BFE | 30D2 | 4A1E | ...J....,+0.J. |
| 0150 | 16FF | 14D6 | 0330 | FBC6 | 034F | F187 | 5F06 | 027A |0...O..... |
| 0160 | 1F57 | 7B1F | 5F10 | F879 | 8F3C | 47AF | 378F | 10FD | .W.....<G.7... |
| 0170 | 4F7A | F63C | 571A | B7FA | 7C01 | 3E80 | 47F1 | B778 | O..<W.....>.G... |
| 0180 | 2810 | 12FA | 8F01 | 792F | 4F1A | A112 | CF29 | C9B1 | (...../O.....)... |
| 0190 | 18F9 | A1C6 | FF9F | E5CD | 8D09 | E118 | EFD7 | E53A | |
| 01A0 | 9940 | B720 | 06CD | 5803 | B728 | 11F5 | AF32 | 9940 | .@....X..(...2.@ |
| 01B0 | 3CCD | 5728 | F12A | D440 | 77C3 | 8428 | 2128 | 1922 | <.W(*.@...(!(" |
| 01C0 | 2141 | 3E03 | 32AF | 40E1 | C93E | 1CCD | 3A03 | 3E1F | !A>.2.@..>...>. |
| 01D0 | C33A | 43EF | 5F32 | A340 | C912 | 41FC | C021 | 4246 |2.@.!...!.. |
| 01E0 | 0B10 | FE21 | 02FC | CD21 | 0206 | 0B10 | FE21 | 00FC | ...!...!...!...! |
| 01F0 | CD21 | 0206 | 5C10 | FEC9 | E521 | 00FB | 181B | 7ED6 | ..!.....!..... |
| 0200 | 233E | 0020 | 0DCD | 012B | CF2C | 7BA2 | C602 | D24A | #>.....+.,.....J |
| 0210 | 1E3D | 32E4 | 37E5 | 2104 | FFCD | 2102 | E1C9 | 2100 | .=2.7.!...!...!.. |
| 0220 | FF3A | 3D40 | A4B5 | D3FF | 323D | 40C9 | 3A3F | 3CEE | .:=@....2=@.:?<. |
| 0230 | 0A32 | 3F3C | C9C5 | E506 | 08CD | 4102 | 10FB | E1C1 | .2?<.....A..... |
| 0240 | C9C5 | F5DB | FF17 | 30FB | 0641 | 10FE | CD1E | 0206 |0..A..... |
| 0250 | 7610 | FEDB | FF47 | F1CB | 1017 | F5CD | 1E02 | F1C1 |G..... |
| 0260 | C9CD | 6402 | E5C5 | D5F5 | 0E08 | 57CD | D901 | 7A07 |W..... |
| 0270 | 5730 | 0BCD | D901 | 0D20 | F2F1 | D1C1 | E1C9 | 0687 | W0..... |
| 0280 | 10FE | 18F2 | CDFE | 0106 | FFAF | CD64 | 0210 | FB3E |> |
| 0290 | A518 | D1CD | FE01 | E5AF | CD41 | 02FE | A520 | F93E |A.....> |
| 02A0 | 2A32 | 3E3C | 323F | 3CE1 | C9CD | 1403 | 22DF | 40CD | *2><2?<.....".@. |
| 02B0 | F801 | CDE2 | 4131 | 8842 | CDFE | 203E | 2ACD | 2A03 |A1.B....>*.~. |
| 02C0 | CDE3 | 1BDA | CC06 | D7CA | 9719 | FE2F | 284F | CD93 |/(O.. |
| 02D0 | 02CD | 3502 | FE55 | 20F9 | 0606 | 7EB7 | 2809 | CD35 | ..5..U.....(..5 |
| 02E0 | 02BE | 20ED | 2310 | F3CD | 2C02 | CD35 | 02FE | 7828 |#....,5....(|
| 02F0 | B8FE | 3C20 | F5CD | 3502 | 47CD | 1403 | 854F | CD35 | ..<...5.G....O.5 |

0300 0277 2381 4F10 F7CD 3502 B928 DA3E 4332 ..#.O...5...(.>C2
0310 3E3C 18D6 CD35 026F CD35 0267 C9EB 2ADF ><...5...5....*.
0320 40EB D7C4 5A1E 208A EBE9 C54F CDC1 413A @...Z.....O..A:
0330 9C40 B779 C1FA 6402 2062 D5CD 3300 F5CD .@.....3...
0340 4803 32A6 40F1 D1C9 3A3D 40E6 083A 2040 H.2.@...:=@...@
0350 2803 0FE6 1FE6 3FC9 CDC4 41D5 CD2B 00D1 (.....?...A..+..
0360 C9AF 3299 4032 A640 CDAF 41C5 2AA7 4006 ..2.@2.@..A.*.@.
0370 F0CD D905 F548 0600 0936 002A A740 F1C1H...6.*.@..
0380 2BD8 AFC9 CD58 03B7 C018 F9AF 329C 403A +....X.....2.@:
0390 9B40 B7C8 3E0D D5CD 9C03 D1C9 F5D5 C54F .@..>.....O
03A0 1E00 FE0C 2810 FE0A 2003 3E0D 4FFE 0D28(.....>.O..(
03B0 053A 9B40 3C5F 7B32 9B40 79CD 3B00 C1D1 ..@<...2.@...;
03C0 F1C9 E5DD E5D5 DDE1 D521 DD03 E54F 1AA0!....O..
03D0 B8C2 3340 FE02 DD6E 01DD 6602 E9D1 DDE1 ..3@.....
03E0 E1C1 C921 3640 0101 3816 000A 5FAE 73A3!6@..8.....
03F0 2008 142C CB01 F2EB 03C9 5F7A 0707 0757,.....W
0400 0E01 79A3 2005 14CB 0118 F73A 8038 477A:8G.
0410 C640 FE60 3013 CB08 3031 C620 573A 4038 .@..0...01..W:@8
0420 E610 2828 7AD6 6018 22D6 7030 10C6 40FE ..((.....".0..@.
0430 3C38 02EE 10CB 0830 12EE 1018 0E07 CB08 <8.....0.....
0440 3001 3C21 5000 4F06 0009 7E57 01AC 0DCD 0.<!P.O....W....
0450 6444 7AFE 01C0 EFC9 DD6E 03DD 6604 383A8:
0460 DD7E 05B7 2801 7779 FE20 DA06 05FE 8030(.....0
0470 35FE 4038 08D6 40FE 2038 02D6 20CD 4105 5.@8..@..8....A.
0480 7CE6 03F6 3C67 56DD 7E05 B728 05DD 7205<.V....(....
0490 365F DD75 03DD 7404 79C9 DD7E 05B7 C07E 6.....
04A0 C97D E6C0 6FC9 FEC0 38D3 D6C0 28D2 473E8...(G>
04B0 20CD 4105 10F9 18C8 7EDD 7705 C9AF 18F9 ..A.....
04C0 2100 3C3A 3D40 E6F7 323D 40D3 FFC9 2B3A !.<:=@..2=@...+:
04D0 3D40 E608 2801 2B36 20C9 3A3D 40E6 08C4 =@..(+6...:=@...
04E0 E204 7DE6 3F2B C011 4000 19C9 237D E63F?+..@...#...?
04F0 C011 C0FF 19C9 3A3D 40F6 0832 3D40 D3FF:=@..2=@..
0500 237D E6FE 6FC9 1180 04D5 FE08 28C0 FE0A #.....~.(...
0510 D8FE 0E38 4F28 A1FE 0F28 A2FE 1728 D7FE ...8O(...(....(
0520 1828 B7FE 1928 C5FE 1A28 BCFE 1B28 C2FE .(...(....(
0530 1C28 8DFE 1DCA A104 FE1E 2837 FE1F 283C .(.....(7..(<
0540 C977 233A 3D40 E608 2801 237C FE40 C011 ..#:=@..(.#...@..
0550 C0FF 19E5 1100 3C21 403C C501 C003 EDB0<!@<.....
0560 C1EB 1819 7DE6 C06F E511 4000 197C FE40@.....@
0570 28E2 D1E5 547D F63F 5F13 1804 E511 0040 (...T..?.....@
0580 3620 237C BA20 F97D BB20 F5E1 C979 B728 6.#.....(
0590 40FE 0B28 0AFE 0C20 1BAF DDB6 0328 15DD @..(.....(
05A0 7E03 DD96 0447 CDD1 0520 FB3E 0A32 E837G.....>.2.7
05B0 10F4 1818 F5CD D105 20FB F132 E837 FE0D2.7..
05C0 C0DD 3404 DD7E 04DD BE03 79C0 DD36 0400 ..4.....6..
05D0 C93A E837 E6F0 FE30 C9E5 3E0E CD33 0048 ...7...0..>..3.H
05E0 CD49 00FE 2030 25FE 0DCA 6206 FE1F 2829 .I...0%.....()
05F0 FE01 286D 11E0 05D5 FE08 2834 FE18 282B ..(.....(4..(+

```

0600 FE09 2842 FE19 2839 FE0A C0D1 7778 B728 ..(B..(9.....(
0610 CF7E 23CD 3300 0518 C7CD C901 41E1 E5C3 ..#.3.....A...
0620 E005 CD30 062B 7E23 FE0A C878 B920 F3C9 ...0.+.#.....
0630 78B9 C82B 7EFE 0A23 C82B 3E08 CD33 0004 ...+...#.+>..3..
0640 C93E 17C3 3300 CD48 03E6 072F 3CC6 085F .>..3..H.../<...
0650 78B7 C83E 2077 23D5 CD33 00D1 051D C818 ...>..#..3.....
0660 EF37 F53E 0D77 CD33 003E 0FCD 3300 7990 .7.>...3.>..3...
0670 47F1 E1C9 D3FF 21D2 0611 0040 0136 00ED G.....!.....@.6..
0680 B03D 3D20 F106 2712 1310 FC3A 4038 E604 .==...'.@8..
0690 C275 0031 7D40 3AFC 373C FE02 DA75 003E ...1.@:7<.....>
06A0 0132 E137 21EC 3711 EF37 3603 0100 00CD .2.7!.7..76.....
06B0 6000 CB46 20FC AF32 EE37 0100 423E 8C77 ...F...2.7..B>..
06C0 CB4E 28FC 1A02 0C20 F7C3 0042 0118 1AC3 .N(.....B.....
06D0 AE19 C396 1CC3 781D C390 1CC3 D925 C900 .....%...
06E0 00C9 FBC9 0001 E303 004B 4907 .....KI.
06F0 5804 003C 0044 4F06 8D05 4300 0050 52C3 X..<.DO...C..PR.
0700 0050 C700 003E 00C9 2180 13CD C209 1806 .P...>..!.....
0710 CDC2 09CD 8209 78B7 C83A 2441 B7CA B409 .....:SA....
0720 9030 0C2F 3CEB CDA4 09EB CDB4 09C1 D1FE .0./<.....
0730 19D0 F5CD DF09 67F1 CDD7 07B4 2121 41F2 .....!!A.
0740 5407 CDB7 07D2 9607 2334 CAB2 072E 01CD T.....#4.....
0750 EB07 1842 AF90 477E 9B5F 237E 9A57 237E ...B..G...#.W#.
0760 994F DCC3 0768 63AF 4779 B720 184A 5465 .O.....G....JT.
0770 6F78 D608 FEE0 20F0 AF32 2441 C905 297A .....2$A..).
0780 1757 798F 4FF2 7D07 785C 45B7 2808 2124 .W..O.....E.(.!$
0790 4186 7730 E3C8 7821 2441 B7FC A807 4623 A..0...!$A....F#
07A0 7EE6 80A9 4FC3 B409 1CC0 14C0 0CC0 0E80 ....O.....
07B0 34C0 1E0A C3A2 197E 835F 237E 8A57 237E 4.....#.W#.
07C0 894F C921 2541 7E2F 77AF 6F90 477D 9B5F .O.!$A./.....G...
07D0 7D9A 577D 994F C906 00D6 0838 0743 5A51 ..W..O.....8.CZQ
07E0 0E00 18F5 C609 6FAF 2DC8 791F 4F7A 1F57 .....-....O..W
07F0 7B1F 5F78 1F47 18EF 0000 0081 03AA 5619 .....G.....V.
0800 80F1 2276 8045 AA38 82CD 5509 B7EA 4A1E ..".E.8..U~..J.
0810 2124 417E 0135 8011 F304 90F5 70D5 C5CD !$A..5.....
0820 1607 C1D1 04CD A208 21F8 07CD 1007 21FC .....!.....!
0830 07CD 9A14 0180 8011 0000 CD16 07F1 CD89 .....
0840 0F01 3180 1118 72CD 5509 C82E 00CD 1409 ..1.....U.....
0850 7932 4F41 EB22 5041 0100 0050 5821 6507 .2OA."PA...PX!..
0860 E521 6908 E5E5 2121 417E 23B7 2824 E52E .!.....!!A.#.($..
0870 081F 6779 300B E52A 5041 19EB E13A 4F41 ....0..*PA...:OA
0880 891F 4F7A 1F57 7B1F 5F78 1F47 2D7C 20E1 ..O..W.....G-...
0890 E1C9 435A 514F C9CD A409 21D8 0DCD B109 ..CZQO.....!.....
08A0 C1D1 CD55 09CA 9A19 2EFF CD14 0934 342B ...U.....44+
08B0 7E32 8940 2B7E 3285 402B 7E32 8140 41EB .2.@+.2.@+.2.@A.
08C0 AF4F 575F 328C 40E5 C57D CD80 40DE 003F .OW.2.@.....@..?
08D0 3007 328C 40F1 F137 D2C1 E179 3C3D 1FFA 0.2.@..7....<=..
08E0 9707 177B 175F 7A17 5779 174F 2478 1747 .....W..O)..G
08F0 3A8C 4017 328C 4079 B2B3 40CB E521 2441 :.@.2.@.....!$A

```

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|--------------------|
| 0900 | 35E1 | 20C3 | C3B2 | 073E | FF2E | AF21 | 2D41 | 4E23 | 5.....>...!-AN# |
| 0910 | AE47 | 2E00 | 78B7 | 281F | 7D21 | 2441 | AE80 | 471F | .G....(!!\$A..G. |
| 0920 | A878 | F236 | 09C6 | 8077 | CA90 | 08CD | DF09 | 772B | ...6.....+. |
| 0930 | C9CD | 5509 | 2FE1 | B7E1 | F278 | 07C3 | B207 | CDBF | ..U./..... |
| 0940 | 0978 | B7C8 | C602 | DAB2 | 0747 | CD16 | 0721 | 2441 |G...!\$A |
| 0950 | 34C0 | C3B2 | 073A | 2441 | B7C8 | 3A23 | 41FE | 2F17 | 4.....\$A...#A./. |
| 0960 | 9FC0 | 3CC9 | 0688 | 1100 | 0021 | 2441 | 4F70 | 0600 | ..<.....!\$AO... |
| 0970 | 2336 | 8017 | C362 | 07CD | 9409 | F0E7 | FA5B | 0CCA | #6..... |
| 0980 | F60A | 2123 | 417E | EE80 | 77C9 | CD94 | 096F | 179F | ..!#A..... |
| 0990 | 67C3 | 9A0A | E7CA | F60A | F255 | 092A | 2141 | 7CB5 |U.*!A.. |
| 09A0 | C87C | 18BB | EB2A | 2141 | E3E5 | 2A23 | 41E3 | E5EB |*!A...*#A... |
| 09B0 | C9CD | C209 | EB22 | 2141 | 6069 | 2223 | 41EB | C921 |"!A..."#A..! |
| 09C0 | 2141 | 5E23 | 5623 | 4E23 | 4623 | C911 | 2141 | 0604 | !A.#V#N#F#...!A.. |
| 09D0 | 1805 | EB3A | AF40 | 471A | 7713 | 2305 | 20F9 | C921 |:G...#....! |
| 09E0 | 2341 | 7E07 | 371F | 773F | 1F23 | 2377 | 7907 | 371F | #A..7..?..##...7. |
| 09F0 | 4F1F | AEC9 | 2127 | 4111 | D209 | 1806 | 2127 | 4111 | O....!'A.....!'A. |
| 0A00 | D309 | D511 | 2141 | E7D3 | 111D | 41C9 | 78B7 | CA55 |!A....A....U |
| 0A10 | 0921 | 5E09 | E5CD | 5509 | 79C8 | 2123 | 41AE | 79F8 | .!....U...!#A... |
| 0A20 | CD26 | 0A1F | A9C9 | 2378 | BEC0 | 2B79 | BEC0 | 2B7A | .&....#...+...+. |
| 0A30 | BEC0 | 2B7B | 96C0 | E1E1 | C97A | AC7C | FA5F | 09BA | ..+.....~..... |
| 0A40 | C260 | 097D | 93C2 | 6009 | C921 | 2741 | CDD3 | 0911 |!'A.... |
| 0A50 | 2E41 | 1AB7 | CA55 | 0921 | 5E09 | E5CD | 5509 | 1B1A | .A...U...!....U... |
| 0A60 | 4FC8 | 2123 | 41AE | 79F8 | 1323 | 0608 | 1A96 | C223 | O..!#A....#.....# |
| 0A70 | 0A1B | 2B75 | 20F6 | C1C9 | CD4F | 0AC2 | 5E09 | C9E7 | ..+.....O..... |
| 0A80 | 2A21 | 41F8 | CAF6 | 0AD4 | B90A | 21B2 | 07E5 | 3A24 | *!A.....!....:\$ |
| 0A90 | 41FE | 9030 | 0ECD | FB0A | EBD1 | 2221 | 413E | 0232 | A..0....."!A>.2 |
| 0AA0 | AF40 | C901 | 8090 | 1100 | 00CD | 0C0A | C061 | 6A18 | .@..... |
| 0AB0 | E8E7 | E0FA | CC0A | CAF6 | 0ACD | BF09 | CDEF | 0A78 | |
| 0AC0 | B7C8 | CDDF | 0921 | 2041 | 46C3 | 9607 | 2A21 | 41CD |!AF...*!A. |
| 0AD0 | EF0A | 7C55 | 1E00 | 0690 | C369 | 09E7 | D0CA | F60A | ...U..... |
| 0AE0 | FCCC | 0A21 | 0000 | 221D | 4122 | 1F41 | 3E08 | 013E | ...!..."A".A>..> |
| 0AF0 | 04C3 | 9F0A | E7C8 | 1E18 | C3A2 | 1947 | 4F57 | 5FE7 |GOW.. |
| 0B00 | C8E5 | CDBF | 09CD | DF79 | AE67 | FC1F | 033E | 9890 |>.. |
| 0B10 | CDD7 | 077C | 17DC | A807 | 0600 | DCC3 | 07E1 | C91B | |
| 0B20 | 7AA3 | 3CC0 | 0BC9 | E7F8 | CD55 | 09F2 | 370B | CD82 | ..<.....U..7... |
| 0B30 | 09CD | 370B | C37B | 09E7 | F830 | 1E28 | B9CD | 8E0A | ..7.....0.(.... |
| 0B40 | 2124 | 417E | FE98 | 3A21 | 41D0 | 7ECD | FB0A | 3698 | !\$A....!A.....6. |
| 0B50 | 7BF5 | 7917 | CD62 | 07F1 | C921 | 2441 | 7EFE | 90DA |!\$A.... |
| 0B60 | 7F0A | 2014 | 4F2B | 7EEE | 8006 | 062B | B605 | 20FB |O+.....+.... |
| 0B70 | B721 | 0080 | CA9A | 0A79 | FEB8 | D0F5 | CDBF | 09CD | .!..... |
| 0B80 | DF09 | AE2E | 36B8 | F5FC | A00B | 2123 | 413E | B890 | ...+6.....!#A>.. |
| 0B90 | CD69 | 0DF1 | FC20 | 0DAF | 321C | 41F1 | D0C3 | D80C |2.A..... |
| 0BA0 | 211D | 417E | 35B7 | 2328 | FAC9 | E521 | 78B7 | 78B7 | !A.5.#(...!.... |
| 0BB0 | 2812 | 3E10 | 29DA | 3D27 | EB29 | EB30 | 0409 | DA3D | (.>.)='.)0...= |
| 0BC0 | 273D | 20F0 | EBE1 | C97C | 179F | 47CD | 510C | 7998 | '=.....G.Q.... |
| 0BD0 | 1803 | 7C17 | 9F47 | E57A | 179F | 1988 | 0FAC | F299 |G..... |
| 0BE0 | 0AC5 | EBCD | CF0A | F1E1 | CDA4 | 09EB | CD6B | 0CC3 | |
| 0BF0 | 8F0F | 7CB5 | CA9A | 0AE5 | D5CD | 450C | C544 | 4D21 |E..DM! |

| | | | | | | | | |
|------|----------|------|-----------------|----------|------|------|------|-------------------------|
| 0C00 | 444 3E10 | 2938 | 1FEB | 29EB | 3004 | 09DA | 260C | ..>.)8...).0...&. |
| 0C10 | 3D20 | F1C1 | D17C | B7FA | 1F0C | D178 | C34D | 0CEE =.....M.. |
| 0C20 | 80B5 | 2813 | EB01 | C1E1 | CDCF | 0AE1 | CDA4 | 09CD ..(..... |
| 0C30 | CF0A | C1D1 | C347 | 0878 | B7C1 | FA9A | 0AD5 | CDCFG..... |
| 0C40 | 0AD1 | C382 | 097C | AA47 | CD4C | 0CEB | 7CB7 | F29AG.L..... |
| 0C50 | 0AAF | 4F95 | 6F79 | 9C67 | C39A | 0A2A | 2141 | CD51 ..O.....*1A.Q |
| 0C60 | 0C7C | EE80 | B5C0 | EBCD | EF0A | AF06 | 98C3 | 6909 |
| 0C70 | 212D | 417E | EE80 | 7721 | 2E41 | 7EB7 | C847 | 2B4E !-A....!A...G+N |
| 0C80 | 1124 | 411A | B7CA | F409 | 9030 | 162F | 3CF5 | 0E08 . \$A.....0./<... |
| 0C90 | 23E5 | 1A46 | 7778 | 121B | 2B0D | 20F6 | E146 | 2B4E #..F.....+....F+N |
| 0CA0 | F1FE | 39D0 | F5CD | DF09 | 2336 | 0047 | F121 | 2D41 ..9.....#6.G.!-A |
| 0CB0 | CD69 | 0D3A | 2641 | 321C | 4178 | B7F2 | CF0C | CD33:&A2.A.....3 |
| 0CC0 | 0DD2 | 0E0D | EB34 | CAB2 | 07CD | 900D | C30E | 0DCD4..... |
| 0CD0 | 450D | 2125 | 41DC | 570D | AF47 | 3A23 | 41B7 | 201E E.!&A.W..G:#A... |
| 0CE0 | 211C | 410E | 0856 | 777A | 230D | 20F9 | 78D6 | 08FE !.A..V..#..... |
| 0CF0 | C020 | E6C3 | 7807 | 0521 | 1C41 | CD97 | 0DB7 | F2F6!A..... |
| 0D00 | 0C78 | B728 | 0921 | 2441 | 8677 | D278 | 07C8 | 3A1C ...(! \$A.....: |
| 0D10 | 41B7 | FC20 | 0D21 | 2541 | 7EE6 | 802B | 2BAE | 77C9 A.....!&A...++... |
| 0D20 | 211D | 4106 | 0734 | C023 | 0520 | FA34 | CAB2 | 072B !.A..4.#...4...+ |
| 0D30 | 3680 | C921 | 2741 | 111D | 410E | 07AF | 1A8E | 1213 6...!'A..A..... |
| 0D40 | 230D | 20F8 | C921 | 2741 | 111D | 410E | 07AF | 1A9E #.....!'A..A..... |
| 0D50 | 1213 | 230D | 20F8 | C97E | 2F77 | 211C | 4106 | 08AF ..#...../..!A... |
| 0D60 | 4F79 | 9E77 | 2305 | 20F9 | C971 | E5D6 | 0838 | 0EE1 O...#.....8.. |
| 0D70 | E511 | 0008 | 4E73 | 592B | 1520 | F918 | EEC6 | 0957N.Y+.....W |
| 0D80 | AFE1 | 15C8 | E51E | 087E | 1F77 | 2B1D | 20F9 | 18F0+..... |
| 0D90 | 2123 | 4116 | 0118 | ED0E | 087E | 1777 | 230D | 20F9 !#A.....#... |
| 0DA0 | C9CD | 5509 | C8CD | 0A09 | CD39 | 0E71 | 1306 | 071A ..U.....9..... |
| 0DB0 | 13B7 | D528 | 170E | 08C5 | 1F47 | DC33 | 0DCD | 900D ... (.....G.3.... |
| 0DC0 | 78C1 | 0D20 | F2D1 | 0520 | E6C3 | D80C | 2123 | 41CD!#A. |
| 0DD0 | 700D | 18F1 | 444 444 444 444 | 108 11D4 | 0D21 | | |! |
| 0DE0 | 2741 | CDD3 | 093A | 2E41 | B7CA | 9A19 | CD07 | 0934 'A.....A.....4 |
| 0DF0 | 34CD | 390E | 2151 | 4171 | 4111 | 4A41 | 2127 | 41CD 4.9.!QA.A.JA!'A. |
| 0E00 | 4B0D | 1A99 | 3F38 | 0B11 | 4A41 | 2127 | 41CD | 390D K...?8..JA!'A.9. |
| 0E10 | AFDA | 1204 | 3A23 | 413C | 3D1F | FA11 | 0D17 | 211D: #A<=.....! |
| 0E20 | 410E | 07CD | 990D | 214A | 41CD | 970D | 78B7 | 20C9 A.....!JA..... |
| 0E30 | 2124 | 4135 | 20C3 | C3B2 | 0779 | 322D | 412B | 1150 ! \$A5.....2-A+.P |
| 0E40 | 4101 | 0007 | 7E12 | 711B | 2B05 | 20F8 | C9CD | FC09 A.....+..... |
| 0E50 | EB2B | 7EB7 | C8C6 | 02DA | B207 | 77E5 | CD77 | 0CE1 .+..... |
| 0E60 | 34C0 | C3B2 | 07CD | 7807 | CDEC | 0AF6 | AFEB | 01FF 4..... |
| 0E70 | 0060 | 68CC | 9A0A | EB7E | FE2D | F5CA | 830E | FE2B-.....+ |
| 0E80 | 2801 | 2BD7 | DA29 | 0FFE | 2ECA | E40E | FE45 | 2814 (.+..).....E(. |
| 0E90 | FE25 | CAEE | 0EFE | 23CA | F50E | FE21 | CAF6 | 0EFE .&.....#.....!.... |
| 0EA0 | 4420 | 24B7 | CDFB | 0EE5 | 21BD | 0EE3 | D715 | FECE D.\$.....!..... |
| 0EB0 | C8FE | 2DC8 | 14FE | CDC8 | FE2B | C82B | F1D7 | DA94 ..-.....+.+..... |
| 0EC0 | 0F14 | 2003 | AF93 | 5FE5 | 7B90 | F40A | 0FFC | 180F |
| 0ED0 | 20F8 | E1F1 | E5CC | 7B09 | E1E7 | E8E5 | 2190 | 08E5!.... |
| 0EE0 | CDA3 | 0AC9 | E70C | 20DF | DCFB | 0EC3 | 830E | E7F2 |
| 0EF0 | 9719 | 2318 | D2B7 | CDFB | 0E18 | F7E5 | D5C5 | F5CC ..#..... |

| | | | | | | | | | |
|------|------|------|------|--------------|--------------|--------------|-------------|-------------|--------------------|
| 0F00 | B10A | F1C4 | DB0A | C1D1 | E1C9 | C8F5 | E7F5 | E43E |> |
| 0F10 | 09F1 | EC4D | 0EF1 | 3DC9 | D5E5 | F5E7 | F5E4 | 9708 | ...M..=..... |
| 0F20 | F1EC | DC0D | F1E1 | D13C | C9D5 | 7889 | 47C5 | E57E |<....G... |
| 0F30 | D630 | F5E7 | F25D | 0F2A | 2141 | 11CD | 0CDF | 3019 | .0.....*!A....0. |
| 0F40 | 545D | 2929 | 1929 | F14F | 097C | B7FA | 570F | 2221 | T.))..).O....W."! |
| 0F50 | 41E1 | C1D1 | C383 | 0E79 | F5CD | CC0A | 3730 | 1801 | A.....70.. |
| 0F60 | 7494 | 1100 | 24CD | 0C0A | F274 | 0FCD | 3E09 | F1CD |\$.>.... |
| 0F70 | 890F | 18DD | CDE3 | 0ACD | 4D0E | CDFC | 09F1 | CD64 |M..... |
| 0F80 | 09CD | E30A | CD77 | 0C18 | C8CD | A409 | CD64 | 09C1 | |
| 0F90 | D1C3 | 1607 | 7BFE | 0A30 | 0907 | 0783 | 0786 | D630 |0.....0 |
| 0FA0 | 5FFA | 1E32 | C3BD | 0EE5 | 2124 | 19CD | A728 | E1CD | ...2....!\$....(.. |
| 0FB0 | 9A0A | AFCD | 3410 | B6CD | D90F | C3A6 | 28AF | CD34 |4.....(..4 |
| 0FC0 | 10E6 | 0828 | 0236 | 2BEB | CD94 | 09EB | F2D9 | 0F36 | ...(.6+.....6 |
| 0FD0 | 2DC5 | E5CD | 7B09 | E1C1 | B423 | 3630 | 3AD8 | 4057 | -.....#60:..@W |
| 0FE0 | 173A | AF40 | DA9A | 10CA | 9210 | FE04 | D23D | 1001 | ...@.....=.. |
| 0FF0 | 0000 | CD2F | 1321 | 3041 | 460E | 203A | D840 | 5FE6 | .../.!0AF....@.. |
| 1000 | 2028 | 0778 | B90E | 2A20 | 0141 | 71D7 | 2814 | FE45 | .(....*..A..(..E |
| 1010 | 2810 | FE44 | 280C | FE30 | 28F0 | FE2C | 28EC | FE2E | (..D(..0(..,(... |
| 1020 | 2003 | 2B36 | 307B | E610 | 2803 | 2B36 | 247B | E604 | ..+60...(+6\$... |
| 1030 | C02B | 70C9 | 32D8 | 4021 | 3041 | 3620 | C9FE | 05E5 | +.2.@!0A6..... |
| 1040 | DE00 | 1757 | 14CD | <i>\$112</i> | <i>\$160</i> | <i>\$352</i> | <i>FA57</i> | <i>1414</i> | ...W.....W... |
| 1050 | BA30 | 043C | 473E | 02D6 | 02E1 | F5CD | 9112 | 3630 | .0.<G>.....60 |
| 1060 | CCC9 | 09CD | A412 | 2B7E | FE30 | 28FA | FE2E | C4C9 |+..0(..... |
| 1070 | 09F1 | 281F | F5E7 | 3E22 | 8F77 | 23F1 | 362B | F285 | ..(....>"...#.6+.. |
| 1080 | 1036 | 2D2F | 3C06 | 2F04 | D60A | 30FB | C63A | 2370 | .6-/<./...0...:##. |
| 1090 | 2377 | 2336 | 00EB | 2130 | 41C9 | 23C5 | FE04 | 7AD2 | ##6..!0A.##..... |
| 10A0 | 0911 | 1FDA | A311 | 0103 | 06CD | 8912 | D17A | D605 | |
| 10B0 | F469 | 12CD | 2F13 | 7BB7 | CC2F | 093D | F469 | 12E5 |/.../.=..... |
| 10C0 | CDF5 | 0FE1 | 2802 | 7023 | 3600 | 212F | 4123 | 3AF3 |(..#6.!/A#:.: |
| 10D0 | 4095 | 92C8 | 7EFE | 2028 | F4FE | 2A28 | F02B | E5F5 | @.....(.*(+.. |
| 10E0 | 01DF | 10C5 | D7FE | 2DC8 | FE2B | C8FE | 24C8 | C1FE |-..+..\$... |
| 10F0 | 3020 | 0F23 | D730 | 0B2B | 012B | 77F1 | 28FB | C1C3 | 0..#.0.+..+..(... |
| 1100 | CE10 | F128 | FDE1 | 3625 | C9E5 | 1FDA | AA11 | 2814 | ...(..6%...r....(. |
| 1110 | 1184 | 13CD | 490A | 1610 | FA32 | 11E1 | C1CD | BD0F |I....2..... |
| 1120 | 2B36 | 25C9 | 010E | B611 | CA1B | CD0C | 0AF2 | 1B11 | +6%..... |
| 1130 | 1606 | CD55 | 09C4 | 0112 | E1C1 | FA57 | 11C5 | 5F78 | ...U.....W.... |
| 1140 | 9293 | F469 | 12CD | 7D12 | CDA4 | 12B3 | C477 | 12B3 | |
| 1150 | C491 | 12D1 | C3B6 | 105F | 79B7 | C416 | 0F83 | FA62 | |
| 1160 | 11AF | C5F5 | FC18 | 0FFA | 6411 | C17B | 90C1 | 5F82 | |
| 1170 | 78FA | 7F11 | 9293 | F469 | 12C5 | CD7D | 1218 | 11CD | |
| 1180 | 6912 | 79CD | 9412 | 4FAF | 9293 | CD69 | 12C5 | 474F |O.....GO |
| 1190 | CDA4 | 12C1 | B120 | 032A | F340 | 833D | F469 | 1250 |*.@.=...P |
| 11A0 | C3BF | 10E5 | D5CD | CC0A | D1AF | CAB0 | 111E | 1001 | |
| 11B0 | 1E06 | CD55 | 0937 | C401 | 12E1 | C1F5 | 79B7 | F5C4 | ...U.7..... |
| 11C0 | 160F | 804F | 7AE6 | 04FE | 019F | 5781 | 4F93 | F5C5 | ...O.....W.O... |
| 11D0 | FC18 | 0FFA | D011 | C1F1 | C5F5 | FADE | 11AF | 2F3C |/< |
| 11E0 | 803C | 8247 | 0E00 | CDA4 | 12F1 | F471 | 12C1 | F1CC | .<.G..... |
| 11F0 | 2F09 | F138 | 0383 | 9092 | C5CD | 7410 | EBD1 | C3BF | /..8..... |

```

1200 10D5 AFF5 E7E2 2212 3A24 41FE 91D2 2212 .....":$A....".
1210 1164 1321 2741 CDD3 09CD A10D F1D6 0AF5 ....!'A.....
1220 18E6 CD4F 12E7 300B 0143 9111 F94F CD0C ...O..0..C...O..
1230 0A18 0611 6C13 CD49 0AF2 4B12 F1CD 0B0F .....I..K.....
1240 F518 E2F1 CD18 0FF5 CD4F 12F1 B7D1 C9E7 .....O.....
1250 EA5E 1201 7494 11F8 23CD 0C0A 1806 1174 .....#.....
1260 13CD 490A E1F2 4312 E9B7 C83D 3630 2318 ..I...C....=60#.
1270 F920 04C8 CD91 1236 3023 3D18 F67B 823C .....60#=....<
1280 473C D603 30FC C605 4F3A D840 E640 C04F G<..0...O:..@..@.O
1290 C905 2008 362E 22F3 4023 48C9 0DC0 362C .....6..".@#H....6,
12A0 230E 03C9 D5E7 E2EA 12C5 E5CD FC09 217C #.....!..
12B0 13CD F709 CD77 0CAF CD7B 0BE1 C111 8C13 .....
12C0 3E0A CD91 12C5 F5E5 D506 2F04 E1E5 CD48 >...../.....H
12D0 0D30 F8E1 CD36 0DEB E170 23F1 C13D 20E2 .0...6....#..=..
12E0 C5E5 211D 41CD B109 180C C5E5 CD08 073C ..!..A.....<
12F0 CDFB 0ACD B409 E1C1 AF11 D213 3FCD 9112 .....?...
1300 C5F5 E5D5 CDBF 09E1 062F 047B 965F 237A ...../.....#.
1310 9E57 2379 9E4F 2B2B 30F0 CDB7 0723 CDB4 .W#..O++0....#..
1320 09EB E170 23F1 C138 D313 133E 0418 06D5 ....#..8...>....
1330 11D8 133E 05CD 9112 C5F5 E5EB 4E23 46C5 ...>.....N#F.
1340 23E3 EB2A 2141 062F 047D 936F 7C9A 6730 #..*!A./.....0
1350 F719 2221 41D1 E170 23F1 C13D 20D7 CD91 .."!A...#..=....
1360 1277 D1C9 0000 0000 F902 15A2 FDFF 9F31 .....1
1370 A95F 63B2 FEFB 03BF C91B 0EB6 0000 0000 .....
1380 0000 0000 0000 0000 04BF C91B 0EB6 0080 C6A4 .....
1390 7E8D 0300 407A 10F3 5A00 00A0 724E 1809 ....@...Z....N..
13A0 0000 10A5 D4E8 0000 00E8 7648 1700 0000 .....H....
13B0 E40B 5402 0000 00CA 9A3B 0000 0000 E1F5 ..T.....;.....
13C0 0500 0000 8096 9800 0000 420F 0000 .....@B...
13D0 0000 A086 0110 2700 1027 E803 6400 0A00 .....!...!.....
13E0 0100 2182 09E3 E9CD A409 2180 13CD B109 ..!.....!.....
13F0 1803 CDB1 0AC1 D1CD 5509 7828 3CF2 0414 .....U..(<...
1400 B7CA 9A19 B7CA 7907 D5C5 79F6 7FCD BF09 .....:.....
1410 F221 14D5 C5CD 400B C1D1 F5CD 0C0A E17C .!....@.....
1420 1FE1 2223 41E1 2221 41DC E213 CC82 09D5 .."#A."!A.....
1430 C5CD 0908 C1D1 CD47 08CD A409 0138 8111 .....G.....8..
1440 3BAA CD47 083A 2441 FE88 D231 09CD 400B ;..G.:$A...1..@.
1450 C680 C602 DA31 09F5 21F8 07CD 0B07 CD41 .....1..!.....A
1460 08F1 C1D1 F5CD 1307 CD82 0921 7914 CDA9 .....!.....
1470 1411 0000 C14A C347 0808 402E 9474 704F .....J.G..@....O
1480 2E77 6E02 887A E6A0 2A7C 50AA AA7E FFFF .....*.P.....
1490 7F7F 0000 8081 0000 0081 CDA4 0911 320C .....2.
14A0 D5E5 CDBF 09CD 4708 E1CD A409 7E23 CDB1 .....G.....#..
14B0 0906 F1C1 D13D C8D5 C5F5 E5CD 4708 E1CD .....=.....G...
14C0 C209 E5CD 1607 E118 E9CD 7F0A 7CB7 FA4A .....J
14D0 1EB5 CAF0 14E5 CDF0 14CD BF09 EBE3 C5CD .....
14E0 CF0A C1D1 CD47 0821 F807 CD0B 07C3 400B .....G.!.....@.
14F0 2190 40E5 1100 004B 2603 2E08 EB29 EB79 !.@....K&.....)..

```

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|--------------------|
| 1500 | 174F | E37E | 0777 | E3D2 | 1615 | E52A | AA40 | 19EB | .O\$.....*..@.. |
| 1510 | 3AAC | 4089 | 4FE1 | 2DC2 | FC14 | E323 | E325 | C2FA | ::@.O.-.....#.%.. |
| 1520 | 14E1 | 2165 | B019 | 22AA | 40CD | EF0A | 3E05 | 8932 | ..!....".@...>..2 |
| 1530 | AC40 | EB06 | 8021 | 2541 | 702B | 704F | 0600 | C365 | .@....!%A.+..O.... |
| 1540 | 0721 | 8B15 | CD0B | 07CD | A409 | 0149 | 8311 | DB0F | .!.....I..... |
| 1550 | CDB4 | 09C1 | D1CD | A208 | CDA4 | 09CD | 400B | C1D1 |@.... |
| 1560 | CD13 | 0721 | 8F15 | CD10 | 07CD | 5509 | 37F2 | 7715 | ...!.....U.7... |
| 1570 | CD08 | 07CD | 5509 | B7F5 | F482 | 0921 | 8F15 | CD0B |U.....!.... |
| 1580 | 07F1 | D482 | 0921 | 9315 | C39A | 14DB | 0F49 | 8100 |!.....I.. |
| 1590 | 0000 | 7F05 | BAD7 | 1E86 | 6426 | 9987 | 5834 | 2387 |&...X4#. |
| 15A0 | E05D | A586 | DA0F | 4983 | CDA4 | 09CD | 4715 | C1E1 |I.....G... |
| 15B0 | CDA4 | 09EB | CDB4 | 09CD | 4115 | C3A0 | 08CD | 5509 |A.....U. |
| 15C0 | FCE2 | 13FC | 8209 | 3A24 | 41FE | 8138 | 0C01 | 0081 |:\$A...8.... |
| 15D0 | 5159 | CDA2 | 0821 | 1007 | E521 | E315 | CD9A | 1421 | QY...!...!.....! |
| 15E0 | 8B15 | C909 | 4AD7 | 3B78 | 026E | 847B | FEC1 | 2F7C |J.;...../. |
| 15F0 | 7431 | 9A7D | 843D | 5A7D | C87F | 917E | E4BB | 4C7E | .1...=Z.....L. |
| 1600 | 6CAA | AA7F | 4444 | 4444 | 8A09 | 370B | 7709 | D427 |7.....' |
| 1610 | EF2A | F527 | E713 | C914 | 0908 | 3914 | 4115 | 4715 | .*.'.....9.A.G. |
| 1620 | A815 | BD15 | AA2C | 5241 | 5841 | 5E41 | 6141 | 6441 |,RAXA.A.A.A |
| 1630 | 6741 | 6A41 | 6D41 | 7041 | 7F0A | B10A | DB0A | 260B | .A.A.A.A.....&. |
| 1640 | 032A | 3628 | C52A | 0F2A | 1F2A | 612A | 912A | 9A2A | .*6(.***.***.* |
| 1650 | C54E | 44C6 | 4F52 | D245 | 5345 | 54D3 | 4554 | C34C | .ND.OR.ESET.ET.L |
| 1660 | 53C3 | 4D44 | D241 | 4E44 | 4F4D | CE45 | 5854 | C441 | S.MD.ANDOM.EXT.A |
| 1670 | 5441 | C94E | 5055 | 54C4 | 494D | D245 | 4144 | CC45 | TA.NPUT.IM.EAD.E |
| 1680 | 54C7 | 4F54 | 4FD2 | 554E | C946 | D245 | 5354 | 4F52 | T.OTO.UN.F.ESTOR |
| 1690 | 45C7 | 4F53 | 5542 | D245 | 5455 | 524E | D245 | 4DD3 | E.OSUB.ETURN.EM. |
| 16A0 | 544F | 50C5 | 4C53 | 45D4 | 524F | 4ED4 | 524F | 4646 | TOP.LSE.RON.ROFF |
| 16B0 | C445 | 4653 | 5452 | C445 | 4649 | 4E54 | C445 | 4653 | .EFSTR.EFINT.EFS |
| 16C0 | 4E47 | C445 | 4644 | 424C | CC49 | 4E45 | C544 | 4954 | NG.EFDBL.INE.DIT |
| 16D0 | C552 | 524F | 52D2 | 4553 | 554D | 45CF | 5554 | CF4E | .RROR.ESUME.UT.N |
| 16E0 | CF50 | 454E | C649 | 454C | 44C7 | 4554 | D055 | 54C3 | .PEN.IELD.ET.UT. |
| 16F0 | 4C4F | 5345 | CC4F | 4144 | CD45 | 5247 | 45CE | 414D | LOSE.OAD.ERGE.AM |
| 1700 | 45CB | 494C | 4CCC | 5345 | 54D2 | 5345 | 54D3 | 4156 | E.ILL.SET.SET.AV |
| 1710 | 45D3 | 5953 | 5445 | 4DCC | 5052 | 494E | 54C4 | 4546 | E.YSTEM.PRINT.EF |
| 1720 | D04F | 4B45 | D052 | 494E | 54C3 | 4F4E | 54CC | 4953 | .OKE.RINT.ONT.IS |
| 1730 | 54CC | 4C49 | 5354 | C445 | 4C45 | 5445 | C155 | 544F | T.LIST.ELETE.UTO |
| 1740 | C34C | 4541 | 52C3 | 4C4F | 4144 | C353 | 4156 | 45CE | .LEAR.LOAD.SAVE. |
| 1750 | 4557 | D441 | 4228 | D44F | C64E | D553 | 494E | 47D6 | EW.AB(.O.N.SING. |
| 1760 | 4152 | 5054 | 52D5 | 5352 | C552 | 4CC5 | 5252 | D354 | ARPTR.SR.RL.RR.T |
| 1770 | 5249 | 4E47 | 24C9 | 4E53 | 5452 | D04F | 494E | 54D4 | RING\$.NSTR.OINT. |
| 1780 | 494D | 4524 | CD45 | 4DC9 | 4E4B | 4559 | 24D4 | 4845 | IME\$.EM.NKEY\$.HE |
| 1790 | 4ECE | 4F54 | D354 | 4550 | ABAD | AAAF | DBC1 | 4E44 | N.OT.TEP.....ND |
| 17A0 | CF52 | BEBD | BCD3 | 474E | C94E | 54C1 | 4253 | C652 | .R....GN.NT.BS.R |
| 17B0 | 45C9 | 4E50 | D04F | 53D3 | 5152 | D24E | 44CC | 4F47 | E.NP.OS.QR.ND.OG |
| 17C0 | C558 | 50C3 | 4F53 | D349 | 4ED4 | 414E | C154 | 4ED0 | .XP.OS.IN.AN.TN. |
| 17D0 | 4545 | 4BC3 | 5649 | C356 | 53C3 | 5644 | C54F | 46CC | EEK.VI.VS.VD.OF. |
| 17E0 | 4F43 | CC4F | 46CD | 4B49 | 24CD | 4B53 | 24CD | 4B44 | OC.OF.KI\$.KS\$.KD |
| 17F0 | 24C3 | 494E | 54C3 | 534E | 47C3 | 4442 | 4CC6 | 4958 | \$.INT.SNG.DBL.IX |

```

1800 CC45 4ED3 5452 24D6 414C C153 43C3 4852 .EN.TR$.AL.SC.HR
1810 24CC 4546 5424 D249 4743 5424 CD49 4424 $.EFT$.IGHT$.ID$
1820 A780 AE1D A11C 3801 3501 C901 7341 D301 .....8.5....A..
1830 B622 051F 9A21 0826 EF21 211F C21E A31E ."....!.&.!.....
1840 3920 91mD B11E DE1E 071F A91D 071F F71D 9.....
1850 F81D 001E 031E 061E 091E A341 602E F41F .....A.....
1860 AF1F FB2A 6C1F 7941 7C41 7F41 8241 8541 ...*...A.A.A.A.A
1870 8841 8B41 8E41 9141 9741 9A41 A041 B202 .A.A.A.A.A.A.A..
1880 6720 5B41 B12C 6F20 E41D 2E2B 292B C62B ...A.,.....+)+.+
1890 0820 7A1E 1F2C F52B 491B 7979 7C7C 7F50 .....,+I.....P
18A0 46DB 4A44 447F 0AF4 0AB1 0A77 0C70 0CA1 F.....
18B0 0DE5 0D78 0A16 0713 0747 08A2 080C 0AD2 .....G.....
18C0 0BC7 0BF2 0B90 2439 0A4E 4653 4E52 474F .....$9.NFSNRGO
18D0 4446 434F 564F 4D55 4C42 5344 442F 3049 DFCOVOMULBSDD/OI
18E0 4454 4D4F 534C 5353 5443 4E4E 5252 5755 DTMOSSLSTCNNRRWU
18F0 454D 4F46 444C 33D6 006F 7CDE 0067 78DE EMOFDL3.....
1900 0047 3E00 C94A 1E40 E64D DB00 C9D3 00C9 .G>..J.@.M.....
1910 0047 3E00 C94A 1E40 E64D DB00 C9D3 00C9 .G>..J.@.M.....
1920 726F 7200 2069 6E20 0052 4541 4459 0D00 .....READY..
1930 4272 6561 6B00 2104 0039 7E23 FE81 C04E B.....!.9.#...N
1940 2346 23E5 6960 7AB3 EB28 02EB DF01 0E00 #F#.....(.....
1950 E1C8 0918 E5CD 6C19 C5E3 C1DF 7E02 C80B .....
1960 2B18 F8E5 2AFD 4006 0009 093E E53E C695 +...*.@.....>.>..
1970 6F3E FF9C 3804 6739 E1D8 1E0C 1824 2AA2 .>..8..9.....$*.
1980 407C A53C 2808 3AF2 40B7 1E22 2014 C3C1 @..<(:.@..".....
1990 1D2A DA40 22A2 401E 0201 1E14 011E 0001 .*.@"@.....
19A0 1E24 2AA2 4022 EA40 22EC 4001 B419 2AE8 .$.@"@".@...*.
19B0 40C3 9A1B C17B 4B32 9A40 2AE6 4022 EE40 @.....K2.@*@"@
19C0 EB2A EA40 7CA5 3C28 0722 F540 EB22 F740 .*.@..<("@"@
19D0 2AF0 407C B5EB 21F2 4028 08A6 2005 35EB *.@...!.@(...5.
19E0 C336 1DAF 7759 CDF9 2021 C918 CDA6 4157 .6...Y...!.AW
19F0 3E3F CD2A 0319 7ECD 2A03 D7CD 2A03 211D >?.*...*...*!.
1A00 19E5 2AEA 40E3 CDA7 28E1 11FE FFDF CA74 ..*.@... (.....
1A10 067C A53C C4A7 0F3E C1CD 8B03 CDAC 41CD ...<...>...~...A.
1A20 F801 CDF9 2021 2919 CDA7 283A 9A40 D602 .....!)...(:@..
1A30 CC53 2E21 FFFF 22A2 403A E140 B728 372A .S.!..."@:..@.(7*
1A40 E240 E5CD AF0F D1D5 CD2C 1B3E 2A38 023E .@.....,>*8.>
1A50 20CD 2A03 CD61 03D1 3006 AF32 E140 18B9 ..*.....0..2.@..
1A60 2AE4 4019 38F4 D511 F9FF DFD1 30EC 22E2 *.@.8.....0.".
1A70 40F6 FFC3 EB2F 3E3E CD2A 03CD 6103 DA33 @...../>>.*.....3
1A80 1AD7 3C3D CA33 1AF5 CD5A 1E2B 7EFE 2028 ..<=.3...Z.+... (
1A90 FA23 7EFE 20CC C909 D5CD C01B D1F1 22E6 .#.....".
1AA0 40CD B241 D25A 1DD5 C5AF 32DD 40D7 B7F5 @..A.Z....2.@...
1AB0 EB22 EC40 EBCD 2C1B C5DC E42B D1F1 D528 .".@.,.....+... (
1AC0 27D1 2AF9 40E3 C109 E5CD 5519 E122 F940 '.*.@.....U..".@
1AD0 EB74 D1E5 2323 7323 7223 EB2A A740 EB1B ....###.###*..@..
1AE0 1B1A 7723 13B7 20F9 D1CD FC1A CDB5 41CD ...#.....A.
1AF0 5D1B CDB8 41C3 331A 2AA4 40EB 626B 7E23 ....A.3.*..@....#

```

| | | | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|----------|--------------|---------|
| 1B00 | B6C8 | 2323 | 23AF | BE23 | 20FC | EB73 | 2372 | 18EC | ... | ###... | ...#... |
| 1B10 | 1185 | 74D5 | 2809 | D1CD | 4F1E | D528 | 0BCF | CE11 | | (...O... | (.... |
| 1B20 | FAFF | C44F | 1EC2 | 9719 | EBD1 | E3E5 | 2AA4 | 4044 | ...O... |* | @D |
| 1B30 | 4D7E | 23B6 | 2BC8 | 2323 | 7E23 | 666F | DF60 | 697E | M.#.+. | ###.# | |
| 1B40 | 2366 | 6F3F | C83F | D018 | E6C0 | CDC9 | 012A | A440 | #...? | ?.....* | @ |
| 1B50 | CDF8 | 1D32 | E140 | 7723 | 7723 | 22F9 | 402A | A440 | ...2. | @.#.#" | @*.@ |
| 1B60 | 2B22 | DF40 | 061A | 2101 | 4136 | 0423 | 10FB | AF32 | +".@... | !..A6.# | ...2 |
| 1B70 | F240 | 6F67 | 22F0 | 4022 | F740 | 2AB1 | 4022 | D640 | ..@..." | @".@*."@ | ..@ |
| 1B80 | CD91 | 1D2A | F940 | 22FB | 4022 | FD40 | CDBB | 41C1 | ...* | @".@".@ | ...A. |
| 1B90 | 2AA0 | 402B | 2B22 | E840 | 2323 | F921 | B540 | 22B3 | *. @++" | @##.!.@" | .. |
| 1BA0 | 40CD | 8B03 | CD69 | 21AF | 676F | 32DC | 40E5 | C52A | @.....! | ...2.@ | ...* |
| 1BB0 | DF40 | C93E | 3FCD | 2A03 | 3E20 | CD2A | 03C3 | 6103 | ..@.>? | *.>...* | |
| 1BC0 | AF32 | B040 | 4FEB | 2AA7 | 402B | 2BEB | 7EFE | 20CA | .2.@O. | *.@++ | |
| 1BD0 | 5B1C | 47FE | 22CA | 771C | B7CA | 7D1C | 3AB0 | 40B7 | ..G." |: | @. |
| 1BE0 | 7EC2 | 5B1C | FE3F | 3EB2 | CA5B | 1C7E | FE30 | 38s5 |? | >..... | 08. |
| 1BF0 | FE3C | DA5B | 1CD5 | 114F | 16C5 | 013D | 1CC5 | 067F | .<..... | O....= | |
| 1C00 | 7EFE | 6138 | 07FE | 7B30 | 03E6 | 5F77 | 4EEB | 23B6 | ...8.... | 0....N. | #. |
| 1C10 | F20E | 1C04 | 7EE6 | 7FC8 | B920 | F3EB | E513 | 1AB7 | | | |
| 1C20 | FA39 | 1C4F | 78FE | 8D20 | 02D7 | 2B23 | 7EFE | 6138 | .9.O.... | ...+## | ...8 |
| 1C30 | 02E6 | 5FE9 | 28E7 | E118 | D348 | F1EB | C9EB | 79C1 | | (....H.... | |
| 1C40 | D1EB | FE95 | 363A | 2002 | 0C23 | FEFB | 200C | 363A |6: | ...#.... | 6: |
| 1C50 | 2306 | 9370 | 23EB | 0C0C | 181D | EB23 | 1213 | 0CD6 | #...# |# | |
| 1C60 | 3A28 | 04FE | 4E20 | 0332 | B040 | D659 | C2CC | 1B47 | :(..N.. | 2.@.Y... | G |
| 1C70 | 7EB7 | 2809 | B828 | E423 | 120C | 1318 | F321 | 0500 | ..(.. | (.#.....! | .. |
| 1C80 | 4409 | 444D | 2AA7 | 402B | 2B2B | 1213 | 1213 | 12C9 | D.DM* | @+++ | |
| 1C90 | 7C92 | C07D | 93C9 | 7EE3 | BE23 | E3CA | 781D | C397 | |# | |
| 1CA0 | 193E | 6432 | DC40 | CD21 | 1FE3 | CD36 | 19D1 | 2005 | ..>.2. | @.!.6.... | |
| 1CB0 | 09F9 | 22E8 | 40EB | 0E08 | CD63 | 19E5 | CD05 | 1FE3 | ..".@ | | |
| 1CC0 | E52A | A240 | E3CF | BDE7 | CAF6 | 0AD2 | F60A | F5CD | .*.@ | | |
| 1CD0 | 3723 | F1E5 | F2EC | 1CCD | 7F0A | E311 | 6144 | 7E7E | 7# | | |
| 1CE0 | CCCC | 012B | D5E5 | EBCD | 9E09 | 1822 | CDB1 | 0ACD | ...+ |" | |
| 1CF0 | BF09 | E1C5 | D501 | 0081 | 515A | 7EFE | CC3E | 0120 | | QZ....> | .. |
| 1D00 | 0ECD | 3823 | E5CD | B10A | CDBF | 09CD | 5509 | E1C5 | ..8# |U... | |
| 1D10 | D54F | E747 | C5E5 | 2ADF | 40E3 | 0681 | C53v | CD58 | .O.G..* | @...3.X | |
| 1D20 | 03B7 | C4A0 | 1D22 | E640 | ED73 | E840 | 7EFE | 3A28 |" | @...@... | (|
| 1D30 | 29B7 | C297 | 1923 | 7E23 | B6CA | 7E19 | 235E | 2356 |)..... | #.#....#.#V | |
| 1D40 | EB22 | A240 | 3A1B | 41B7 | 280F | D53E | 3CCD | 2A03 | ..".@: | A.(..><.* | .. |
| 1D50 | CDAF | 0F3E | 3ECD | 2A03 | D1EB | D711 | 1E1D | D5C8 | ...>>. | *..... | |
| 1D60 | D680 | DA21 | 1FFE | 3CD2 | E72A | 074F | 0600 | EB21 | ...!.. | <...*.O...! | |
| 1D70 | 2218 | 094E | 2346 | C5EB | 237E | FE3A | D0FE | 20CA | "..N#F. | #..... | |
| 1D80 | 781D | FE0B | 3005 | FE09 | D278 | 1DFE | 303F | 3C3D |0 |0?<= | |
| 1D90 | C9EB | 2AA4 | 402B | 22FF | 40EB | C9CD | 5803 | B7C8 | ..*.@+ | "@...X... | |
| 1DA0 | FE60 | CC84 | 0332 | 9940 | 3DC0 | 3CC3 | B41D | C0F5 |2. | @=.<..... | |
| 1DB0 | CCBB | 41F1 | 22E6 | 4021 | B540 | 22B3 | 4021 | F6FF | ..A." | @!.@".@! | .. |
| 1DC0 | C12A | A240 | E5F5 | 7DA4 | 3C28 | 0922 | F540 | 2AE6 | .*.@ |<(".* | .. |
| 1DD0 | 4022 | F740 | CD8B | 03CD | F920 | F121 | 3019 | C206 | @".@ |!0... | |
| 1DE0 | 1AC3 | 181A | 2AF7 | 407C | B51E | 20CA | A219 | EB2A |* | @.....* | |
| 1DF0 | F540 | 22A2 | 40EB | C93E | AF32 | 1B41 | C9F1 | E1C9 | ..@".@ | ...>.2.A.... | |

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|----------------------|
| 1E00 | 1E03 | 011E | 0201 | 1E04 | 011E | 08CD | 3D1E | 0197 |=... |
| 1E10 | 19C5 | D8D6 | 414F | 47D7 | FECE | 2009 | D7CD | 3D1E |AOG.....=. |
| 1E20 | D8D6 | 4147 | D778 | 91D8 | 3CE3 | 2101 | 4106 | 0009 | ..AG....<!.A... |
| 1E30 | 7323 | 3D20 | FBE1 | 7EFE | 2CC0 | D718 | CE7E | FE41 | .#=.....,.....A |
| 1E40 | D8FE | 5B3F | C9D7 | CD02 | 2BF0 | 1E08 | C3A2 | 197E | ...?.....+..... |
| 1E50 | FE2E | EB2A | EC40 | EBCA | 781D | 2B11 | 0000 | D7D0 | ...*.@.....+..... |
| 1E60 | E5F5 | 2198 | 19DF | DA97 | 1962 | 6B19 | 2919 | 29F1 | ..!......).). |
| 1E70 | D630 | 5F16 | 0019 | EBE1 | 18E4 | CA61 | 1BCD | 461E | .0.....F. |
| 1E80 | 2BD7 | C0E5 | 2AB1 | 407D | 935F | 7C9A | 57DA | 7A19 | +...*.@.....W... |
| 1E90 | 2AF9 | 4001 | 2844 | 01D7 | D27A | 19EB | 22A0 | 40E1 | *.@.(.....".@. |
| 1EA0 | C361 | 1BCA | 5D1B | CDC7 | 41CD | 611B | 011E | 1D18 |A..... |
| 1EB0 | 100E | 03CD | 6319 | C1E5 | E52A | A240 | E33E | 91F5 |*.@.>.. |
| 1EC0 | 33C5 | CD5A | 1ECD | 071F | E52A | A240 | DFE1 | 23DC | 3..Z.....*.@.#. |
| 1ED0 | 2F1B | D42C | 1B60 | 692B | D81E | 0EC3 | A219 | C016 | /.....+..... |
| 1EE0 | FFCD | 3619 | F922 | E840 | FE91 | 1E04 | C2A2 | 19E1 | ..6..".@..... |
| 1EF0 | 22A2 | 4023 | 7CB5 | 2007 | 3ADD | 40B7 | C218 | 1A21 | ".@#.....: @.....! |
| 1F00 | 1E1D | E33E | E101 | 5144 | 0746 | 4474 | 4847 | 7EB7 | ...>.....HG.. |
| 1F10 | C8B8 | C823 | FE22 | 28F3 | D68F | 20F2 | B88A | 5718 | ...#.."(.....W. |
| 1F20 | EDCD | 0D26 | CFD5 | EB22 | DF40 | EBD5 | E7F5 | CD37 | ...&....".@.....7 |
| 1F30 | 23F1 | E3C6 | 03CD | 1928 | CD03 | 0AE5 | 2028 | 2A21 | #.....(.....(*! |
| 1F40 | 41E5 | 235E | 2356 | 2AA4 | 40DF | 300E | 2AA0 | 40DF | A.#.#V*.@.0.*.@. |
| 1F50 | D130 | 0F2A | F940 | DF30 | 093E | D1CD | F529 | EBCD | .0.*.@.0.>....).. |
| 1F60 | 4328 | CDF5 | 29E3 | CDD3 | 09D1 | E1C9 | FE9E | 2025 | C(..).....% |
| 1F70 | D7CF | 8DCD | 5A1E | 7AB3 | 2809 | CD2A | 1B50 | 59E1 |Z...(.*.PY. |
| 1F80 | D2D9 | 1EEB | 22F0 | 40EB | D83A | F240 | B7C8 | 3A9A |".@.....@..... |
| 1F90 | 405F | C3AB | 19CD | 1C2B | 7E47 | FE91 | 2803 | CF8D | @.....+..G..(.. |
| 1FA0 | 2B4B | 0D78 | CA60 | 1DCD | 5B1E | FE2C | C018 | F311 | +K.....,..... |
| 1FB0 | F240 | 1AB7 | CAA0 | 193C | 329A | 4012 | 7EFE | 8728 | .@.....<2.@.....(|
| 1FC0 | 0CCD | 5A1E | C07A | B3C2 | C51E | 3C18 | 02D7 | C02A | ..Z.....<.....* |
| 1FD0 | EE40 | EB2A | EA40 | 22A2 | 40EB | C07E | B720 | 0423 | .@.*.@".@.....# |
| 1FE0 | 2323 | 2323 | 7AA3 | 3CC2 | 051F | 3ADD | 403D | CABE | ###.#.<.....: @=.. |
| 1FF0 | 1DC3 | 051F | CD1C | 2BC0 | B7CA | 4A1E | 3D87 | 5FFE |+....J.=... |
| 2000 | 2D38 | 021E | 26C3 | A219 | 110A | 44D5 | 2817 | CD4F | -8...&.....(..O |
| 2010 | 1EEB | E328 | 11EB | CF2C | EB2A | E440 | EB28 | 06CD | ...((...,*.@.(.. |
| 2020 | 5A1E | C297 | 19EB | 7CB5 | CA4A | 1E22 | E440 | 32E1 | Z.....J.".@2. |
| 2030 | 40E1 | 22E2 | 40C1 | C333 | 1ACD | 3723 | 7EFE | 2CCC | @.".@..3..7#...,, |
| 2040 | 781D | FECA | CC78 | 1D2B | E5CD | 9409 | E128 | 07D7 |+.....(.. |
| 2050 | DAC2 | 1EC3 | 5F1D | 1601 | CD05 | 1FB7 | C8D7 | FE95 | |
| 2060 | 20F6 | 1520 | F318 | E83E | 0132 | 9C40 | C39B | 20CD |>.2.@..... |
| 2070 | CA41 | FE40 | 2019 | CD01 | 2BFE | 04D2 | 4A1E | E521 | .A.@.....+...J..! |
| 2080 | 003C | 1922 | 2040 | 7BE6 | 3F32 | A640 | E1CF | 2CFE | .<.".@..?2.@...,, |
| 2090 | 2320 | 08CD | 8402 | 3E80 | 329C | 402B | D7CC | FE20 | #.....>.2.@+.... |
| 20A0 | CA69 | 21FE | BFCA | BD2C | FEBC | CA37 | 21E5 | FE2C | ..!......,....7!..., |
| 20B0 | CA08 | 21FE | 3BCA | 6421 | C1CD | 3723 | E5E7 | 2832 | ..!.;...!.7#..(2 |
| 20C0 | CDBD | 0FCD | 6528 | CDCD | 412A | 2141 | 3A9C | 40B7 |(..A*!A:..@. |
| 20D0 | FAE9 | 2028 | 083A | 9B40 | 86FE | 8418 | 093A | 9D40 | ...(:.@.....: @ |
| 20E0 | 473A | A640 | 86B8 | D4FE | 20CD | AA28 | 3E20 | CD2A | G:..@.....(>...* |
| 20F0 | 03B7 | CCAA | 28E1 | C39B | 203A | A640 | B7C8 | 3E0D |(.....: @...>. |

| | | | | | | | | | |
|------|------|------|------|-------|------|------|------|------|--------------------|
| 2100 | CD2A | 03CD | D041 | AFC9 | CDD3 | 413A | 9C40 | B7F2 | .*...A...A...@... |
| 2110 | 1921 | 3E2C | CD2A | 0318 | 4B28 | 083A | 9B40 | FE70 | .!>,.*.K(...@... |
| 2120 | C32B | 213A | 9E40 | 473A | A640 | B8D4 | FE20 | 3034 | .+!:.@G::@....04 |
| 2130 | D610 | 30FC | 2F18 | 23CD | 1B2B | E63F | 5FCF | 292B | ..0./.#...+?.)+ |
| 2140 | E5CD | D341 | 3A9C | 4037 | FA4A | 1ECA | 5321 | 3A9B | ...A::@..J..S!: |
| 2150 | 4018 | 033A | A640 | 2F83 | 300A | 3C47 | 3E20 | CD2A | @...: @/.0.<G>..* |
| 2160 | 0305 | 20FA | E1D7 | C3A0 | 203A | 9C40 | B7FC | F801 |: @.... |
| 2170 | AF32 | 9C40 | CDBE | 41C9 | 3F52 | 4544 | 4F0D | 003A | .2.@..A.?REDO...: |
| 2180 | DE40 | B7C2 | 9119 | 3AA9 | 40B7 | 1E2A | CAA2 | 19C1 | .@.....: @.*.... |
| 2190 | 2178 | 21CD | A728 | 2AE6 | 40C9 | CD28 | 287E | CDD6 | !.!..(*.@..((... |
| 21A0 | 41D6 | 2332 | A940 | 7E20 | 20CD | 9302 | E506 | FA2A | A.#2.@.....* |
| 21B0 | A740 | CD35 | 0277 | 23FE | 0D28 | 0210 | F52B | 3600 | .@.5...#..(...+6. |
| 21C0 | CDF8 | 012A | A740 | 2B18 | 2201 | DB21 | C5FE | 22C0 | ...*.@+."..1..". |
| 21D0 | CD66 | 28CF | 3BE5 | CDA A | 28E1 | C9E5 | CDB3 | 1BC1 | ..(;...(...... |
| 21E0 | DABE | 1D23 | 7EB7 | 2BC5 | CA04 | 1F36 | 2C18 | 05E5 | ...#...+....6,... |
| 21F0 | 2AFF | 40F6 | AF32 | DE40 | E318 | 02CF | 2CCD | 0D26 | *.@..2.@.....,& |
| 2200 | E3D5 | 7EFE | 2C28 | 263A | DE40 | B7C2 | 9622 | 3AA9 |,(&:.@....":. |
| 2210 | 40B7 | 1E06 | CAA2 | 193E | 3FCD | 2A03 | CDB3 | 1BD1 | @.....>?.*..... |
| 2220 | C1DA | BE1D | 237E | B72B | C5CA | 041F | D5CD | DC41 |#...+.....A |
| 2230 | E7F5 | 2019 | D757 | 47FE | 2228 | 0516 | 3A06 | 2C2B |WG."(...:.,+ |
| 2240 | CD69 | 28F1 | EB21 | 5A22 | E3D5 | C333 | 1FD7 | F1F5 | ..(..!Z"...3.... |
| 2250 | 0143 | 22C5 | DA6C | 0ED2 | 650E | 2BD7 | 2805 | FE2C | .C"........+.(., |
| 2260 | C27F | 21E3 | 2BD7 | C2FB | 21D1 | 4037 | 4037 | 4037 | ..!.+...!.....: |
| 2270 | DE40 | B7EB | C296 | 1DD5 | CDDF | 41B6 | 2186 | 22C4 | .@.....A.!..". |
| 2280 | A728 | E1C3 | 6921 | 3F45 | 7874 | 7261 | 2069 | 676E | .(....! ?E..... |
| 2290 | 6F72 | 6564 | 0D00 | CD05 | 1FB7 | 2012 | 237E | 23B6 |#.#. |
| 22A0 | 1E06 | CAA2 | 1923 | 5E23 | 56EB | 22DA | 40EB | D7FE |#.#V.".@... |
| 22B0 | 8820 | E3C3 | 2D22 | 1144 | 4037 | 0D26 | 22DF | 40CD |-"......&".@. |
| 22C0 | 3619 | C29D | 19F9 | 22E8 | 40D5 | 7E23 | F5D5 | 7E23 | 6.....".@..#...# |
| 22D0 | B7FA | EA22 | CDB1 | 09E3 | E5CD | 0B07 | E1CD | CB09 | ..."..... |
| 22E0 | E1CD | C209 | E5CD | 0C0A | 1829 | 2323 | 2323 | 4E23 |)###N# |
| 22F0 | 4623 | E35E | 2356 | E569 | 60CD | D20B | 3AAF | 40FE | F#...#V.....: @. |
| 2300 | 04CA | B207 | EBE1 | 722B | 73E1 | D55E | 2356 | 23E3 |+.....#V# |
| 2310 | CD39 | 0AE1 | C190 | CDC2 | 0928 | 09EB | 22A2 | 4069 | .9.....(.."@. |
| 2320 | 60C3 | 1A1D | F922 | E840 | 2ADF | 407E | FE2C | C21E |".@*.@...., |
| 2330 | 1DD7 | CDB9 | 22CF | 282B | 1600 | D50E | 01CD | 6319 |".(+..... |
| 2340 | CD9F | 2422 | F340 | 2AF3 | 40C1 | 7E16 | 00D6 | D438 | ..\$" .@*.@.....8 |
| 2350 | 13FE | 0330 | 0FFE | 0117 | AABA | 57DA | 9719 | 22D8 | ...0.....W....". |
| 2360 | 40D7 | 18E9 | 7AB7 | C2EC | 237E | 22D8 | 40D6 | CDD8 | @.....#..".@... |
| 2370 | FE07 | D05F | 3AAF | 40D6 | 03B3 | CA8F | 2921 | 9A18 |: @.....) !.. |
| 2380 | 1978 | 56BA | D0C5 | 0146 | 23C5 | 7AFE | 7FCA | D423 | ..V....F#.....# |
| 2390 | FE51 | DAE1 | 2321 | 2141 | B73A | AF40 | 3D3D | 3DCA | .Q..#!!A...: @===. |
| 23A0 | F60A | 4E23 | 46C5 | FAC5 | 2323 | 4E23 | 46C5 | F5B7 | ..N#F...##N#F... |
| 23B0 | E2C4 | 23F1 | 2338 | 0321 | 1D41 | 4E23 | 4623 | C54E | ..#.#8.!AN#F#.N |
| 23C0 | 2346 | C506 | F1C6 | 034B | 47C5 | 01 | | | |

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|--------------------|
| 2400 | E501 | 8C25 | 18C7 | C179 | 32B0 | 4078 | FE08 | 2828 | ...%...2.@...((|
| 2410 | 3AAF | 40FE | 08CA | 6024 | 5778 | FE04 | CA72 | 247A | :@...\$W...\$. |
| 2420 | FE03 | CAF6 | 0AD2 | 7C24 | 21BF | 1806 | 0009 | 094E | ...\$!...N |
| 2430 | 2346 | D12A | 2141 | C5C9 | CDD8 | 0ACD | FC09 | E122 | #F.*!A....." |
| 2440 | 1F41 | E122 | 1D41 | C1D1 | CDB4 | 09CD | DB0A | 21AB | .A."A.....!. |
| 2450 | 183A | B040 | 07C5 | 4F06 | 44C | C17E | 2366 | 6FE9 | ...@..O.....#... |
| 2460 | C5CD | FC09 | F132 | AF40 | FE04 | 28DA | E122 | 2141 |2.@...(!"!A |
| 2470 | 18D9 | CDB1 | 0AC1 | D121 | B518 | 18D5 | E1CD | A409 |!..... |
| 2480 | CDCD | 0ACD | BF09 | E122 | 2341 | E122 | 2141 | 18E7 |"#A."!A.. |
| 2490 | E5EB | CDCD | 0AE1 | CDA4 | 09CD | CF0A | C3A0 | 08D7 | |
| 24A0 | 1E28 | CAA2 | 19DA | 6C0E | CD3D | 1ED2 | 4025 | FECB | .(.....=..@%.. |
| 24B0 | 28ED | FE2E | CA6C | 0EFF | CECA | 3225 | FE22 | CA66 | (.....2%.".. |
| 24C0 | 28FE | CBCA | C425 | FE26 | CA94 | 41FE | C320 | 0AD7 | (.....%&..A..... |
| 24D0 | 3A9A | 40E5 | CD66 | 27E1 | C9FE | C220 | 0AD7 | E52A | :@...!.....* |
| 24E0 | EA40 | CD66 | 0CE1 | C9FE | C020 | 14D7 | CF28 | CD0D | .@.....(.. |
| 24F0 | 26CF | 29E5 | EB7C | B5CA | 4A1E | CD9A | 0AE1 | C9FE | &.).....J..... |
| 2500 | C1CA | FE27 | FEC5 | CA9D | 41FE | C8CA | C927 | FEC7 | ...!.....A.....' |
| 2510 | CA76 | 41FE | C6CA | 3201 | FEC9 | CA9D | 01FE | C4CA | ..A...2..... |
| 2520 | 2F2A | FEBE | CA55 | 41D6 | D7D2 | 4E25 | CD35 | 23CF | /*...UA...N%.5#. |
| 2530 | 29C9 | 167D | CD3A | 232A | F340 | E5CD | 7B09 | E1C9 |).....:.*.@..... |
| 2540 | CD0D | 26E5 | EB22 | 2141 | E7C4 | F709 | E1C9 | 0600 | ..&..."!A..... |
| 2550 | 074F | C5D7 | 79FE | 4138 | 16CD | 3523 | CF2C | CD64 | .O....A8..5#.,.. |
| 2560 | 0AEB | 2A21 | 41E3 | E5EB | CD1C | 2BEB | E318 | 14CD | ..*!A.....+..... |
| 2570 | 2C25 | E37D | FE0C | 3807 | FE1B | E5DC | B10A | E111 | ,%.....8..... |
| 2580 | 3E25 | D501 | 0816 | 094E | 2366 | 69E9 | CDD7 | 297E | >%.....N#.....). |
| 2590 | 234E | 2346 | D1C5 | F5CD | DE29 | D15E | 234E | 2346 | #N#F.....).#N#F |
| 25A0 | E17B | B2C8 | 7AD6 | 01D8 | AFBB | 3CD0 | 151D | 0ABE |<..... |
| 25B0 | 2303 | 28ED | 3FC3 | 6009 | 3C8F | C1A0 | C6FF | 9FCD | #.(?...<..... |
| 25C0 | 8D09 | 1812 | 165A | CD3A | 23CD | 7F0A | 7D2F | 6F7C |Z.:#...../.. |
| 25D0 | 2F67 | 2221 | 41C1 | C346 | 233A | AF40 | FE08 | 3005 | /."!A..F#:@..0. |
| 25E0 | D603 | B737 | C9D6 | 03B7 | C9C5 | CD7F | 0AF1 | D101 | ...7..... |
| 25F0 | FA27 | C5FE | 4620 | 067B | B56F | 7CB2 | C97B | A56F | .'..F..... |
| 2600 | 7CA2 | C92B | D7C8 | CF2C | 0103 | 26C5 | F6AF | 32AE | ...+...&...2. |
| 2610 | 4046 | CD3D | 1EDA | 9719 | AF4F | D738 | 05CD | 3D1E | @F.=.....O.8..=. |
| 2620 | 3809 | 4FD7 | 38FD | CD3D | 1E30 | F811 | 5226 | D516 | 8.O.8..=.0..R&.. |
| 2630 | 02FE | 25C8 | 14FE | 24C8 | 14FE | 21C8 | 1608 | FE23 | ..%...\$...!...# |
| 2640 | C878 | D641 | E67F | 5F16 | 00E5 | 2101 | 4119 | 56E1 | ...A.....!..A.V. |
| 2650 | 2BC9 | 7A32 | AF40 | D73A | DC40 | B7C2 | 6426 | 7ED6 | +..2.@...@...&.. |
| 2660 | 28CA | E926 | AF32 | DC40 | E5D5 | 2AF9 | 40EB | 2AFB | (..&2.@...*.@.*. |
| 2670 | 40DF | E128 | 191A | 6FBC | 1320 | 0B1A | B920 | 0713 | @..(..... |
| 2680 | 1AB8 | CACC | 263E | 1313 | E524 | 9419 | 18DF | 7CE1 |&>...&..... |
| 2690 | E3F5 | D511 | F124 | DF28 | 3611 | 4325 | DFD1 | 2835 |\$. (6.C%..(5 |
| 26A0 | F1E3 | E5C5 | 4F06 | 00C5 | 0303 | 032A | FD40 | E509 |O.....*.@.. |
| 26B0 | C1E5 | CD55 | 19E1 | 22FD | 4060 | 6922 | FB40 | 2B36 | ...U..."@..."@+6 |
| 26C0 | 00DF | 20FA | D173 | 23D1 | 7323 | 72EB | 13E1 | C957 |#.....W |
| 26D0 | 5FF1 | F1E3 | C932 | 2441 | C167 | 6F22 | 2141 | E720 |2\$A..."!A.. |
| 26E0 | 0621 | 2819 | 2221 | 41E1 | C9E5 | 2AAE | 40E3 | 57D5 | .!(".!A...*.@.W. |
| 26F0 | C5CD | 451E | C1F1 | EBE3 | E5EB | 3C57 | 7EFE | 2C28 | ..E.....<W...,(|

```

2700 EECF 2922 F340 E122 AE40 D52A FB40 3E19 ..)".@."@.*.@>.
2710 EB2A FD40 EBDF 3AAF 4028 27BE 2320 087E .*@...@('.#...
2720 B923 2004 7EB8 3E23 235E 2356 2320 E03A .#...>##.#V#...
2730 AE40 B71E 12C2 A219 F196 CA95 271E 10C3 .@.....'...
2740 A219 7723 5F16 00F1 7123 7023 4FCD 6319 ...#.....#.#O...
2750 2323 22D8 4071 233A AE40 1779 010B 0030 ##".@.#:..@.....0
2760 02C1 0371 2370 23F5 CDAA 0BF1 3D20 EDF5 ....#.#.....=...
2770 424B EB19 38C7 CD6C 1922 FD40 2B36 00DF BK..8.....".@+6..
2780 20FA 03'7 2AD8 405E EB29 09EB 2B2B 7323 ...W*.@..)..++.#
2790 7223 F138 3047 4F7E 2316 E15E 2356 23E3 .#.80GO.#...#V#.
27A0 F5DF D23D 27CD AA0B 19F1 3D44 4D20 EB3A ...='.....=DM...
27B0 AF40 444D 29D6 0438 0429 2806 29B7 E2C2 .@DM)..8.)(..)...
27C0 2709 C109 EB2A F340 C9AF E532 AF40 CDD4 '.....*.@...2.@..
27D0 27E1 D7C9 2AFD 40EB 2144 4437 E723 40C4 '....*.@.!..9....
27E0 DA29 CDE6 282A A040 EB2A D640 7D93 6F7C .)..<(*.@.*.@....
27F0 9A67 C366 0C3A A640 6FAF 67C3 9A0A CDA9 .....:@.....
2800 41D7 CD2C 25E5 2190 08E5 3AAF 40F5 FE03 A.,%,!.....:@....
2810 CCDA 29F1 EB2A 8E40 E9E5 E607 21A1 184F ..)..*.@.....!..O
2820 0600 09CD 8625 E1C9 E52A A240 237C B5E1 .....%....*.@#...
2830 C01E 16C3 A219 CDBD 0FCD 6528 CDDA 2901 .....(.....).
2840 2B2A C57E 23E5 CDBF 28E1 4E23 46CD 5A28 +*..#....(.N#F.Z(
2850 E56F CDCE 29D1 C9CD BF28 21D3 40E5 7723 .....). ....(!.@..#
2860 7323 72E1 C92B 0622 50E5 0EFF 237E 0CB7 .#...+."P...#...
2870 2806 BA28 03B8 20F4 FE22 CC78 1DE3 23EB (...(. ....". ....#.
2880 79CD 5A28 11D3 403E D52A B340 2221 413E ..Z(..@>.*.@"!A>
2890 0332 AF40 CDD3 0911 D640 DF22 B340 E17E .2.@.....@."@..
28A0 C01E 1EC3 A219 23CD 6528 CDDA 29CD C409 .....#...(.). ...
28B0 1415 C80A CD2A 03FE 0DCC 0321 0318 F2B7 .....*.....!.....
28C0 0EF1 F52A A040 EB2A D640 2F4F 06FF 0923 ...*.@.*.@/O...#
28D0 DF38 0722 D640 23EB F1C9 F11E 1ACA A219 .8."@#.....
28E0 BFF5 01C1 28C5 2AB1 4022 D640 2144 04E5 .....(*.@".@!...
28F0 2AA0 40E5 21B5 40EB 2AB3 40EB DF01 F728 *.@.!.@.*.@....(
2900 C24A 292A F940 EB2A FB40 EBDF 2813 7E23 .J)*.@.*.@..(..#
2910 2323 FE03 2004 CD4B 29AF 5F16 0019 18E6 ##.....K)..~.....
2920 C1EB 2AFD 40EB DFCA 6B29 7E23 CDC2 09E5 ..*.@.....).#.....
2930 09FE 0320 EB22 D840 E14E 0600 0909 23EB .....".@.N....#.
2940 2AD8 40EB DF28 DA01 3F29 C5AF B623 5E23 *.@..(..?)...#.#
2950 5623 C844 4D2A D640 DF60 69D8 E1E3 DFE3 V#.DM*.@.....
2960 E560 69D0 C1F1 F1E5 D5C5 C9D1 E17D B4C8 .....
2970 2B46 2B4E E52B 6E26 0009 5059 2B44 4D2A +F+N+.&..PY+DM*
2980 D640 CD58 19E1 7123 7069 602B C3E9 28C5 .@.X...#...+..(.
2990 E52A 2141 E3CD 9F24 E3CD F40A 7EE5 2A21 .*!A...$.....*!
29A0 41E5 861E 1CDA A219 CD57 28D1 CDDE 29E3 A.....W(...).
29B0 CDDD 29E5 2AD4 40EB CDC6 29CD C629 2149 ..).*.@.....)!I
29C0 23E3 E5C3 8428 E1E3 7E23 4E23 466F 2C2D #.....(....#N#F.,-
29D0 C80A 1203 1318 F8CD F40A 2A21 41EB CDF5 .....*!A...
29E0 29EB C0D5 5059 1B4E 2AD6 40DF 2005 4709 )...PY.N*.@....G.
29F0 22D6 40E1 C92A B340 2B46 2B4E 2BDF C022 ".@...*.@+F+N+..".

```

| | | | | | | | | | |
|------|------|------|-----------|------|------|------|------|------|---------------------|
| 2A00 | B340 | C901 | F827 | C5CD | D729 | AF57 | 7EB7 | C901 | .@....'....).W.... |
| 2A10 | F827 | C5CD | 072A | CA4A | 1E23 | 5E23 | 561A | C93E | .'....*.J.#.#V...> |
| 2A20 | 01CD | 5728 | CD1F | 2B2A | D440 | 73C1 | C384 | 28D7 | ..W(...+*.@....(. |
| 2A30 | CF28 | CD1C | 2BD5 | CF2C | CD37 | 23CF | 29E3 | E5E7 | .(...+...,.7#.)... |
| 2A40 | 2805 | CD1F | 2B18 | 03CD | 132A | D1F5 | F57B | CD57 | (...+....*.....W |
| 2A50 | 285F | F11C | 1D28 | D42A | D440 | 7723 | 1D20 | FB18 | (....(*.@.#..... |
| 2A60 | CACD | DF2A | AFE3 | 4F3E | E5E5 | 7EB8 | 3802 | 7811 | ...*.O>.....8... |
| 2A70 | 0E00 | C5CD | BF28 | C1E1 | E523 | 4623 | 6668 | 0600 |(....#F#..... |
| 2A80 | 0944 | 4DCD | 5A28 | 6FCD | CE29 | D1CD | DE29 | C384 | .DM.Z(...).)...). |
| 2A90 | 28CD | DF2A | D1D5 | 1A90 | 18CB | EB7E | CDE2 | 2A04 | (..*.....*. |
| 2AA0 | 05CA | 4A1E | C51E | FFFE | 2928 | 05CF | 2CCD | 1C2B | ..J.....)(...+. |
| 2AB0 | CF29 | F1E3 | 0169 | 2AC5 | 3DBE | 064F | 7E91 | | .).....*=.....O.. |
| 2AC0 | BB47 | D843 | C9CD | 072A | CAF8 | 275F | 237E | 2366 | .G.C....*...'.#.#. |
| 2AD0 | 6FE5 | 1946 | 72E3 | C57E | CD65 | 0EC1 | E170 | C9EB | ...F..... |
| 2AE0 | CF29 | C1D1 | C543 | C9FE | 7AC2 | 9719 | C3D9 | 41CD | .)...C.....A. |
| 2AF0 | 1F2B | 3294 | 40CD | 9340 | C3F8 | 27CD | 0E2B | C396 | ..+2.@..@...'.+.. |
| 2B00 | 40D7 | CD37 | 23E5 | CD7F | 0AEB | E17A | B7C9 | CD1C | @..7#..... |
| 2B10 | 2B32 | 9440 | 3297 | 40CF | 2C18 | 01D7 | CD37 | 23CD | +2.@2.@...,.7#. |
| 2B20 | 052B | C24A | 1E2B | D77B | C93E | 0132 | 9C40 | C1CD | ..+J.+...>.2.@.. |
| 2B30 | 101B | C521 | FFFF | 22A2 | 40E1 | D14E | 2346 | 2378 | ...!..."@..N#F#. |
| 2B40 | B1CA | 191A | CDDF | 41CD | 9B1D | C54E | 2346 | 23C5 |A....N#F#. |
| 2B50 | E3EB | DFC1 | DA18 | 1AE3 | E5C5 | EB22 | EC40 | CDAF |".@.. |
| 2B60 | 0F3E | 20E1 | CD2A | 03CD | 7E2B | 2AA7 | 40CD | 752B | ..>....*...+*.@...+ |
| 2B70 | CDFE | 2018 | BE7E | B7C8 | CD2A | 0323 | 18F7 | E52A |*.#....* |
| 2B80 | A740 | 444D | E116 | FF18 | 0303 | 15C8 | 7EB7 | 2302 | ..@DM.....#. |
| 2B90 | C8F2 | 892B | FEFB | 2008 | 0B0B | 0B0B | 1414 | 1414 | ...+..... |
| 2BA0 | FE95 | CC24 | 0BD6 | 7FE5 | 5F21 | 5016 | 7EB7 | 23F2 | ...\$.!P...#. |
| 2BB0 | AC2B | 1D20 | F7E6 | 7F02 | 0315 | CAD8 | 287E | 23B7 | ..+.....(.#. |
| 2BC0 | F2B7 | 2BE1 | 18C6 | CD10 | 1BD1 | C5C5 | CD2C | 1B30 | ..+.....,0 |
| 2BD0 | 0554 | 5DE3 | E5DF | D24A | 1E21 | 2919 | CDA7 | 28C1 | .T.....J.!)...(. |
| 2BE0 | 21E8 | 1AE3 | EB2A | F940 | 1A02 | 0313 | DF20 | F960 | !.....*.@..... |
| 2BF0 | 6922 | F940 | C9CD | 8402 | CD37 | 23E5 | CD13 | 2A3E | ..".@.....7#...*> |
| 2C00 | D3CD | 6402 | CD61 | 021A | CD64 | 022A | A440 | EB2A |~*.@.* |
| 2C10 | F940 | 1A13 | CD64 | 02DF | 20F8 | CD68 | 01E1 | C9CD | ..@..... |
| 2C20 | 9302 | 7ED6 | B228 | 02AF | 012F | 23F5 | 2BD7 | 3E00 |(..../#.+.>. |
| 2C30 | 2807 | CD37 | 23CD | 132A | 1A6F | F1B7 | 6722 | 2141 | (..7#...*....."!A |
| 2C40 | CC4D | 1B2A | 2141 | EB06 | 03CD | 3502 | D6D3 | 20F7 | .M.*!A....5..... |
| 2C50 | 10F7 | CD35 | 021C | 1D28 | 03BB | 2037 | 2AA4 | 4006 | ...5....(....7*.@. |
| 2C60 | 03CD | 3502 | 5F96 | A220 | 2173 | CD6C | 197E | B723 | ..5.....!.....# |
| 2C70 | 20ED | CD2C | 0210 | EA22 | F940 | 2129 | 19CD | A728 | ...,. "...@!)... (|
| 2C80 | CD68 | 012A | A440 | E5C3 | E81A | 21A5 | 2CCD | A728 | ...*.@.....!.,.. (|
| 2C90 | C318 | 1A32 | 3E3C | 0603 | CD35 | 02B7 | 20F8 | 10F8 | ...2><...5..... |
| 2CA0 | CD96 | 0218 | A242 4144 | CD7F | 0A7E | C3F8 | | |BAD..... |
| 2CB0 | 27CD | 022B | D5CF | 2CCD | 1C2B | D112 | C9CD | 3823 | '..+...,.+.....8# |
| 2CC0 | CD64 | 0ACF | 3BEB | 2A21 | 4118 | 083A | DE40 | B728 |;.*!A....@.(|
| 2CD0 | 0CD1 | EBE5 | AF32 | DE40 | BAF5 | D546 | B0CA | 4A1E |2.@...F..J. |
| 2CE0 | 234E | 2366 | 6918 | 1C58 | E50E | 027E | 23FE | 25CA | #N#.....X.....#.#. |
| 2CF0 | 172E | FE20 | 2003 | 0C10 | F2E1 | 433E | 25CD | 492E |C>\$.I. |

| | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|----------------------------------|
| 2D00 | CD2A | 03AF | 5F57 | CD49 | 2E57 | 7E23 | FE21 | CA14 | . * . . . W . I . W . # . ! . . |
| 2D10 | 2EFE | 2328 | 3705 | CAFE | 2DFE | 2B3E | 0828 | E72B | .. # (7 . . . - . + > . (. + |
| 2D20 | 7E23 | FE2E | 2840 | FE25 | 28BD | BE20 | D0FE | 2428 | . # . . (@ . 8 (. . . . \$ (|
| 2D30 | 14FE | 2A20 | C878 | FE02 | 2338 | 037E | FE24 | 3E20 | .. * # 8 . . . \$ > . |
| 2D40 | 2007 | 051C | FEAF | C610 | 231C | 8257 | 1C0E | 0005 | # . . W |
| 2D50 | 2847 | 7E23 | FE2E | 2818 | FE23 | 28F0 | FE2C | 201A | (G . # . . (. . # (. . , . . |
| 2D60 | 7AF6 | 4057 | 18E6 | 7EFE | 233E | 2E20 | 900E | 0123 | .. @ W # > # |
| 2D70 | 0C05 | 2825 | 7E23 | FE23 | 28F6 | D511 | 972D | D554 | .. (8 . # . # (. . . . - . T |
| 2D80 | 5DFE | 5BC0 | BEC0 | 23BE | C023 | BEC0 | 2378 | D604 | # . . # . . # . . . |
| 2D90 | D8D1 | D147 | 1423 | CAEB | D17A | 2B1C | E608 | 2015 | .. . G . # + |
| 2DA0 | 1D78 | B728 | 107E | D62D | 2806 | FEFE | 2007 | 3E08 | .. . (. . . - (. . . . > . |
| 2DB0 | C604 | 8257 | 05E1 | F128 | 5C05 | D5CD | 3723 | D1C1 | .. . W . . . (P . . . 7 # . . |
| 2DC0 | C5E5 | 4378 | 81FE | 19D2 | 4A1E | 7AF6 | 80CD | BE0F | .. C J |
| 2DD0 | CDA7 | 28E1 | 2BD7 | 3728 | 0D32 | DE40 | FE3B | 2805 | .. (. + . 7 (. 2 . @ . ; (. |
| 2DE0 | FE2C | C297 | 19D7 | C1EB | E1E5 | F5D5 | 7E90 | 234E | .. , # N |
| 2DF0 | 2366 | 6916 | 005F | 1978 | B7C2 | 032D | 1806 | CD49 | # - . . I |
| 2E00 | 2ECD | 2A03 | E1F1 | C2CB | 2CDC | FE20 | E3CD | DD29 | .. * ,) |
| 2E10 | E1C3 | 6921 | 0E01 | 3EF1 | 05CD | 492E | E1F1 | 28E9 | .. ! . ! . > . . . I . . (. |
| 2E20 | C5CD | 3723 | CDF4 | 0AC1 | C5E5 | 2A21 | 4141 | 0E00 | .. 7 # * ! A A . . |
| 2E30 | C5CD | 682A | CDAA | 282A | 2141 | F196 | 473E | 2004 | .. . * . . (* ! A . G > . . |
| 2E40 | 05CA | D32D | CD2A | 0318 | F7F5 | 7AB7 | 3E2B | C42A | .. . - . * > + . * |
| 2E50 | 03F1 | C932 | 9A40 | 2AEA | 40B4 | A53C | EEC8 | 1804 | .. . 2 . @ * . @ . < |
| 2E60 | CD4F | 1EC0 | E1EB | 22EC | 40EB | CD2C | 1BD2 | D91E | .. O " . @ . , |
| 2E70 | 6069 | 2323 | 4E23 | 4623 | C5CD | 7E2B | E1E5 | CDAF | .. # V N # F # + |
| 2E80 | 0F3E | 20CD | 2A03 | 2AA7 | 403E | 0ECD | 2A03 | E50E | .. > . . * . * . @ > . . * . . |
| 2E90 | FF0C | 7EB7 | 2320 | FAE1 | 4716 | 00CD | 8403 | D630 | # . . . G 0 |
| 2EA0 | 380E | FE0A | 300A | 5F7A | 0707 | 8207 | 8357 | 18EB | 8 . . . 0 W . . |
| 2EB0 | E521 | 992E | E315 | 14C2 | BB2E | 14FE | D8CA | D22F | .. ! / |
| 2EC0 | FEDD | CAE0 | 2FFE | F028 | 41FE | 3138 | 02D6 | 20FE | / . . (A . 18 |
| 2ED0 | 21CA | F62F | FE1C | CA40 | 2FFE | 2328 | 3FFE | 19CA | ! . . / . . . @ / . # (? . . . |
| 2EE0 | 7D2F | FE14 | CA4A | 2FFE | 13CA | 652F | FE15 | CAE3 | .. / . . . J / / |
| 2EF0 | 2FFE | 28CA | 782F | FE1B | 281C | FE18 | CA75 | 2FFE | / . (. . / . . (. . . . / . |
| 2F00 | 11C0 | C1D1 | CDFE | 20C3 | 652E | 7EB7 | C804 | CD2A | * |
| 2F10 | 0323 | 1520 | F5C9 | E521 | 5F2F | E337 | F5CD | 8403 | .. # ! . / . 7 |
| 2F20 | 5FF1 | F5DC | 5F2F | 7EB7 | CA3E | 2FCD | 2A03 | F1F5 | / . . . > / . * . . . |
| 2F30 | DCA1 | 2F38 | 0223 | 047E | BB20 | EB15 | 20E8 | F1C9 | .. / 8 . # |
| 2F40 | CD75 | 2BCD | FE20 | C1C3 | 7C2E | 7EB7 | C83E | 21CD | .. + > ! . |
| 2F50 | 2A03 | 7EB7 | 2809 | CD2A | 03CD | A12F | 1520 | F33E | * . . . (. . * . . . / . . . > |
| 2F60 | 21CD | 2A03 | C97E | B7C8 | CD84 | 0377 | CD2A | 0323 | ! . * * . # |
| 2F70 | 0415 | 20F1 | C93C | 4443 | 16FF | CD0A | 2FCD | 8403 | 6 . H / |
| 2F80 | B7CA | 7D2F | FE08 | 280A | FE0D | CAE0 | 2FFE | 1BC8 | .. . / . . (. / |
| 2F90 | 201E | 3E08 | 0504 | 281F | CD2A | 032B | 0511 | 7D2F | .. > . . . (. . * . + . . . / |
| 2FA0 | D5E5 | 0D7E | B737 | CA90 | 0823 | 7E2B | 7723 | 18F3 | 7 . . . # . + . # . . |
| 2FB0 | F579 | FEFF | 3803 | F118 | C490 | 0C04 | C5EB | 6F26 | 8 & |
| 2FC0 | 0019 | 444D | 23CD | 5819 | C1F1 | 77CD | 2A03 | 23C3 | .. DM # . X * . # . |
| 2FD0 | 7D2F | 78B7 | C805 | 2B3E | 08CD | 2A03 | 1520 | F3C9 | .. / + > . . * |
| 2FE0 | CD75 | 2BCD | FE20 | C1D1 | 7AA3 | 3C2A | A740 | 2BC8 | .. + < * . @ + . |
| 2FF0 | 3723 | F5C3 | 981A | C1D1 | C319 | 1ADE | C3C3 | 4462 | 7 # D . |
| 3000 | FFFF | FFFF | FFFF | FFFF | FFFF | FFFF | FFFF | FFFF | |

```

500 CLS: CLEAR200
510 CMD" T"
520 PRINT
530 ON ERROR GOTO 540
540 RESUME 550
550 PRINT" W 4 U C H   N U M B E R   C O N V E R S I O N   P R O
    G R A M"
560 PRINT
570 PRINT"           - DECIMAL TO BINARY ENTER D"
580 PRINT"           - BINARY TO DECIMAL ENTER B"
590 PRINT"           - HEXADECIMAL TO BINARY ENTER HB"
600 PRINT"           - DECIMAL TO HEXADECIMAL ENTER DH":
610 PRINT"           - HEXADECIMAL TO DECIMAL ENTER HD"
620 PRINT"           - SPLIT DECIMAL TO DECIMAL ENTER SP"
630 PRINT"           - DECIMAL TO SPLIT HEXADECIMAL ENTER DS"
640 PRINT"           - SPLIT HEXADECIMAL TO DECIMAL ENTER SD ";
650 INPUT AA$: CLS
660 IF AA$ = "HB" GOTO 1550
670 IF AA$ = "DH" THEN QB$ = ""
680 IF AA$ = "DS" THEN AA$ = "DH": QB$ = "DS"
690 IF AA$ = "SD" GOTO 1500
700 IF AA$ = "HD" GOTO 1550
710 IF AA$ = "B" GOTO 860
720 REM DECIMAL TO BINARY CONVERSION
730 CLS: INPUT" DECIMAL NO. "; X: IF X > 65535 GOTO 730
740 A = INT(X/2): AA = X - 2*A: B = INT(A/2): BB = A - 2*B: C = INT(B/2): CC = B - 2*C
750 D = INT(C/2): DD = C - 2*D: E = INT(D/2): EE = D - 2*E: F = INT(E/2): FF = E - 2*F
760 G = INT(F/2): GG = F - 2*G: H = INT(G/2): HH = G - 2*H: I = INT(H/2): II = H - 2*I
770 J = INT(I/2): JJ = I - 2*J: K = INT(J/2): KK = J - 2*K: L = INT(K/2): LL = K - 2*L
780 M = INT(L/2): MM = L - 2*M: N = INT(M/2): NN = M - 2*N: O = INT(N/2): OO = N - 2*O
790 PP = O - 2*INT(O/2)
800 Y$ = STR$(PP) + STR$(OO) + STR$(NN) + STR$(MM) + STR$(LL) + STR$(KK) + STR$(JJ) + STR$(II) + STR$(HH) + STR$(GG) + STR$(FF) + STR$(EE) + STR$(DD) + STR$(CC) + STR$(BB) + STR$(AA)
810 IF AA$ = "SP" THEN NO = NO + 1: QB$ = "DS": GOTO 1200
820 IF AA$ = "DH" AND QB$ = "" THEN PRINT: PRINT" HEXADECIMAL ";: GOTO 1200
830 IF QB$ = "DS" GOTO 1200
840 PRINT" BINARY # "Y$: INPUT R: GOTO 730
850 REM BINARY TO DECIMAL CONVERSION
860 CLS: INPUT" 16, 8, OR 4 DIGIT BINARY NO. "; AA
870 CLS: PRINT AA; "DIGIT BINARY NO. ";: INPUT X$
880 IF LEN(X$) <> A GOTO 870
890 FOR Z = 1 TO AA: X = VAL(MID$(X$, Z, 1)): IF Z = 1 THEN A = X
900 IF Z = 2 THEN B = X
910 IF Z = 3 THEN C = X
920 IF Z = 4 THEN D = X
930 IF AA = 8 GOTO 970 ELSE IF AA = 16 GOTO 970
940 NEXT
950 Y = A*8 + B*4 + C*2 + D*1
960 PRINT"          DECIMAL "Y: INPUT R: GOTO 870
970 IF Z = 5 THEN E = X
980 IF Z = 6 THEN F = X
990 IF Z = 7 THEN G = X
1000 IF Z = 8 THEN H = X

```

```
1010 IFAA=16GOTO1050
1020 NEXT
1030 Y=A*128+B*64+C*32+D*16+E*8+F*4+G*2+H*1
1040 PRINT"          DECIMAL"Y:INPUTR:GOTO870
1050 IFZ=9THENI=X
1060 IFZ=10THENJ=X
1070 IFZ=11THENK=X
1080 IFZ=12THENL=X
1090 IFZ=13THENM=X
1100 IFZ=14THENN=X
1110 IFZ=15THENO=X
1120 IFZ=16THENP=X
1130 NEXT
1140 Y=A*32768+B*16384+C*8192+D*4096+E*2048+F*1024+G*512+H*256+I
*128+J*64+K*32+L*16+M*8+N*4+O*2+P*1
1150 PRINT:PRINT"          DECIMAL";Y:INPUTR
1160 IFAA$="SP"GOTO730
1170 IFAA$="B"GOTO870
1180 IFAA$="HD"GOTO1540
1190 IFAA$="SD"GOTO1500
1200 DH$=MID$(Y$,1,8):GOSUB1250
1210 DH$=MID$(Y$,9,8):GOSUB1250
1220 DH$=MID$(Y$,17,8):GOSUB1250
1230 DH$=MID$(Y$,25,8):GOSUB1250
1240 PRINT"          ";:INPUTR:GOTO730
1250 DH=VAL(DH$):IFDH=0THENDH$="0"
1260 IFDH=1THENDH$="1"
1270 IFDH=10THENDH$="2"
1280 IFDH=11THENDH$="3"
1290 IFDH=100THENDH$="4"
1300 IFDH=101THENDH$="5"
1310 IFDH=110THENDH$="6"
1320 IFDH=111THENDH$="7"
1330 IFDH=1000THENDH$="8"
1340 IFDH=1001THENDH$="9"
1350 IFDH=1010THENDH$="A"
1360 IFDH=1011THENDH$="B"
1370 IFDH=1100THENDH$="C"
1380 IFDH=1101THENDH$="D"
1390 IFDH=1110THENDH$="E"
1400 IFDH=1111THENDH$="F"
1410 IFQB$="DS"THENQQ=QQ+1
1420 IFQQ=1THENRR$=DH$:RETURN
1430 IFQQ=2THENS$=DH$:RETURN
1440 IFQQ=3THENTT$=DH$:RETURN
1450 IFQQ=4THENUU$=DH$
1460 IFQB$="DS"ANDAA$="DH"THENPRINT:PRINT" SPLIT HEX      ";TT$;UU$
;RR$;S$:QQ=0:INPUTR:GOTO730
1470 IFQB$="DS"ANDAA$="SP"ANDNO=1THENFF$=TT$+UU$:QQ=0:GOTO730
1480 IFQB$="DS"ANDAA$="SP"ANDNO=2THENS$=TT$+UU$:X$=S$+FF$:NO=0
:QQ=0:PRINT" HEXADECIMAL ";X$:GOTO1560
1490 PRINTDH$;:RETURN
1500 'SPLIT HEX TO DECIMAL CONVERSION
1510 CLS:INPUT"SPLIT HEX NO.      ";SH$
1520 SI$=LEFT$(SH$,2):SJ$=RIGHT$(SH$,2)
```

```
1530 X$="":X$=SJ$+SI$:GOTO1560
1540 REM HEX TO DECIMAL AND HEX TO BINARY CONVERSION
1550 CLS:X$="":INPUT"HEXADECIMAL NO. ";X$
1560 IFLEN(X$)<>4GOTO1550
1570 FOR XX=1TO4:A$=MID$(X$,XX,1)
1580 IFA$="0"THENNA$="0000"
1590 IFA$="1"THENNA$="0001"
1600 IFA$="2"THENNA$="0010"
1610 IFA$="3"THENNA$="0011"
1620 IFA$="4"THENNA$="0100"
1630 IFA$="5"THENNA$="0101"
1640 IFA$="6"THENNA$="0110"
1650 IFA$="7"THENNA$="0111"
1660 IFA$="8"THENNA$="1000"
1670 IFA$="9"THENNA$="1001"
1680 IFA$="A"THENNA$="1010"
1690 IFA$="B"THENNA$="1011"
1700 IFA$="C"THENNA$="1100"
1710 IFA$="D"THENNA$="1101"
1720 IFA$="E"THENNA$="1110"
1730 IFA$="F"THENNA$="1111"
1740 NN=NN+1
1750 IFNN=1GOTO1760ELSEIFNN=2GOTO1770ELSEIFNN=3GOTO1780ELSEIFNN=
4GOTO1790
1760 BB$=A$:          NEXTXX:GOTO1570
1770 CC$=A$:          NEXTXX:GOTO1570
1780 DD$=A$:          NEXTXX:GOTO1570
1790 EE$=A$:
1800 X$=BB$+CC$+DD$+EE$:NN=0
1810 IFAA$="HB"THENPRINTX$;" BINARY ";:INPUTR:CLS:GOTO1550
1820 AA=16:GOTO890
1830 END
1840 '
1850 ' NOTE: PROGRAM UTILIZES 3919 BYTES OF MEM
```

```

00100 ; SOURCE CODE PROGRAM TO PRINT ALL ZEROS WITH A SLASH
00110
00120 ; WITH AUTO CARRIAGE RETURN @ 64 CHARACTERS WHEN LLIST
00130
00140      ORG      7F15H      ;=32533 DECIMAL ORIGIN
00150 COUNT      EQU      7F15H      ;MEM LOCATION FOR CHAR. COUNTER
00160      DEFW      COUNT      ;ASSEMBLER SAVES 2 BYTES @ 7F15H
00170 START      PUSH      AF      ;SAVE REGISTERS IN STACK MEMORY
00180      PUSH      BC
00190      PUSH      DE
00200      PUSH      HL
00210      LD      A,C      ;NEXT CHARACTER TO PRINT IN C REG
00220      CP      0DH      ;IS IT A CARRIAGE RETURN?
00230      JR      Z,NOINC ;EXIT W/O INCREMENTING COUNTER
00240      LD      A,(COUNT)      ;COUNTER VALUE FROM MEM
00250      CP      040H      ;IS IT 64 DECIMAL = END OF LINE?
00260      JR      Z,CARRET      ;IF SO, GOTO CARR. RETURN
00270 FINIS      LD      A,(COUNT)      ;IF RETURN FM CARRET
00280      INC      A      ;ADD +1 CHARACTER ON LINE
00290      LD      (COUNT),A      ;NEW COUNT NUMBER TO MEM
00300      LD      A,C      ;NEXT CHARACTER TO PRINT IN C REG
00310      CP      30H      ;30H=ASCII ZERO. IS IT A ZERO?
00320      CALL     Z,ZERO      ;IF SO, GOTO ZERO SUBROUTINE
00330 ELFIN      POP      HL      ;RESTORE REGISTERS TO ORIG. CONDX
00340      POP      DE
00350      POP      BC
00360      POP      AF
00370      JP      058DH      ;GOTO ROM STD. PRINTER ROUTINE
00380 NOINC      LD      A,00H      ;RESET CHARACTER COUNTER-
00390      LD      (COUNT),A      ;IN MEMORY
00400      JR      ELFIN      ;QUICK DEPARTURE
00410 RESET      LD      A,00H      ;RESET CHARACTER-
00420      LD      (COUNT),A      ;COUNTER IN MEMORY.
00430      JR      FINIS      ;ALL DONE
00440 CARRET      CALL     TEST      ;TEST IF PRINTER READY?
00450      LD      A,0DH      ;0DH = ASCII CARRIAGE RETURN
00460      LD      (37E8H),A      ;DO CARRIAGE RETURN
00470      JR      RESET      ;GOTO RESET CHARACTER COUNTER
00480 TEST      LD      A,(37E8H)      ;PRINTER MEM LOCATION
00490      BIT      7,A      ;PRINTER READY HANDSHAKE?
00500      JR      NZ,TEST      ;LOOP TILL HANDSHAKE
00510      RET      ;RETURN TO LINE AFTER CALL
00520 ZERO      CALL     TEST      ;IS PRINTER READY?
00530      LD      A,2FH      ;2FH=ASCII SLASH
00540      LD      (37E8H),A      ;PRINT '/' SLASH
00550      CALL     TEST      ;IS PRINTER READY?
00560      CALL     DELAY      ;20 MILLISECOND DELAY
00570      LD      A,08H      ;08H = ASCII BACKSPACE
00580      LD      (37E8H),A      ;DO BACKSPACE
00590 DELAY      LD      C,0AH      ;INITIALIZE DELAY-
00600 DELAY1      LD      B,0H      ;LOOPS TO ALLOW SELECTRIC-
00610 DELAY2      DJNZ     DELAY2      ;PRINT HEAD TIME TO SETTLE DOWN-
00620      DEC      C      ;FROM BACKSPACE VIBRATION AND-
00630      JP      NZ,DELAY1      ;FOR TRACK TO LOCK.
00640      RET      ;RETURN TO LINE AFTER CALL DELAY.
00650      ORG      4026H      ;PUT ADDRESS OF START IN PRINTER-
00660      DEFW      START      ;DRIVER ADDRESS AT 4026H MEMORY.
00670      ORG      COUNT      ;CHARACTER COUNTER MEM ADDRESS-
00680      DEFB      00H      ;INITIALIZE AT ZERO.
00690      END      COUNT      ;FIRST LINE OF SUBROUTINE

```


OBJECT CODE: LPRINT ALL ZEROS WITH SLASH

| | | | |
|-------------|--------------|------|-----------|
| 7F15 | 00140 | ORG | 7F15H |
| 7F15 | 00150 COUNT | EQU | 7F15H |
| 7F15 157F | 00160 | DEFW | COUNT |
| 7F17 F5 | 00170 START | PUSH | AF |
| 7F18 C5 | 00180 | PUSH | BC |
| 7F19 D5 | 00190 | PUSH | DE |
| 7F1A E5 | 00200 | PUSH | HL |
| 7F1B 79 | 00210 | LD | A,C |
| 7F1C FE0D | 00220 | CP | 0DH |
| 7F1E 281B | 00230 | JR | Z,NOINC |
| 7F20 3A157F | 00240 | LD | A,(COUNT) |
| 7F23 FE40 | 00250 | CP | 040H |
| 7F25 2822 | 00260 | JR | Z,CARRET |
| 7F27 3A157F | 00270 FINIS | LD | A,(COUNT) |
| 7F2A 3C | 00280 | INC | A |
| 7F2B 32157F | 00290 | LD | (COUNT),A |
| 7F2E 79 | 00300 | LD | A,C |
| 7F2F FE30 | 00310 | CP | 30H |
| 7F31 CC5B7F | 00320 | CALL | Z,ZERO |
| 7F34 E1 | 00330 ELFIN | POP | HL |
| 7F35 D1 | 00340 | POP | DE |
| 7F36 C1 | 00350 | POP | BC |
| 7F37 F1 | 00360 | POP | AF |
| 7F38 C38D05 | 00370 | JP | 058DH |
| 7F3B 3E00 | 00380 NOINC | LD | A,00H |
| 7F3D 32157F | 00390 | LD | (COUNT),A |
| 7F40 18F2 | 00400 | JR | ELFIN |
| 7F42 3E00 | 00410 RESET | LD | A,00H |
| 7F44 32157F | 00420 | LD | (COUNT),A |
| 7F47 18DE | 00430 | JR | FINIS |
| 7F49 CD537F | 00440 CARRET | CALL | TEST |
| 7F4C 3E0D | 00450 | LD | A,0DH |
| 7F4E 32E837 | 00460 | LD | (37E8H),A |
| 7F51 18EF | 00470 | JR | RESET |
| 7F53 3AE837 | 00480 TEST | LD | A,(37E8H) |
| 7F56 CB7F | 00490 | BIT | 7,A |
| 7F58 20F9 | 00500 | JR | NZ,TEST |
| 7F5A C9 | 00510 | RET | |
| 7F5B CD537F | 00520 ZERO | CALL | TEST |
| 7F5E 3E2F | 00530 | LD | A,2FH |
| 7F60 32E837 | 00540 | LD | (37E8H),A |
| 7F63 CD537F | 00550 | CALL | TEST |
| 7F66 CD6E7F | 00560 | CALL | DELAY |
| 7F69 3E08 | 00570 | LD | A,08H |
| 7F6B 32E837 | 00580 | LD | (37E8H),A |
| 7F6E 0E0A | 00590 DELAY | LD | C,0AH |
| 7F70 0600 | 00600 DELAY1 | LD | B,0H |
| 7F72 10FE | 00610 DELAY2 | DJNZ | DELAY2 |
| 7F74 0D | 00620 | DEC | C |
| 7F75 C2707F | 00630 | JP | NZ,DELAY1 |
| 7F78 C9 | 00640 | RET | |
| 4026 | 00650 | ORG | 4026H |
| 4026 177F | 00660 | DEFW | START |
| 7F15 | 00670 | ORG | COUNT |
| 7F15 00 | 00680 | DEFB | 00H |
| 7F15 | 00690 | END | COUNT |

CHAPTER 9
- SELF-TEST QUESTIONS -

The following pages of self-test questions cover a number of important points in the preceeding Chapters and demonstration programs. If you understand the logic, program flow, and rationale of each Chapter/program's contents, you should have little difficulty in answering the questions. If a question's answer is not clear, re-read/study the appropriate Chapter and/or demonstration program till osmosis occurs, as in time it will indeed permeate. If all else fails, try putting this handbook under your pillow and sleeping on it. (Ed.)

SELF-TEST QUESTIONS FOR CHAPTER 1:

1. What is meant by masking the most significant bit (MSB)?

2. What are the decimal and hexadecimal locations in ROM for the Level II functions' NAMES?

From _____ / _____ to _____ / _____.

3. Why are disk BASIC's functions' names and coupling addresses in non-disk Level II BASIC ROM?

4. How would you mask the MSB of any MEM location in a simple program written in BASIC?.

5. How many MEM groups (seperate address segments) do the BASIC functions' CALL addresses occupy? Beginning locations?

A. _____ B. _____ C. _____ D. _____

6. Name the 2 geniuses at Microsoft who wrote Level II and disk BASIC (luckily they did not write DOS 2.1 or 2.2).

A _____ G _____

7. Why are the BASIC functions' CALL addresses in Level II ROM expressed LSB first and MSB second?

8. What are the decimal values of PEEK 5666 & 5667? What Level II function's CALL address do they represent?

A. _____ / _____ B. _____

9. What are the MEM locations in decimal and hex of the following PEEK values? A. 194-30 B. 15-42 C. 255-255 D. 0-255

A. _____ / _____ B. _____ / _____ C. _____ / _____ D. _____ / _____

SELF-TEST QUESTIONS - CHAPTER 2:

1. On the average, how much faster will efficiently written assembly language programs run than BASIC ? MEM required?

A. _____ B. _____

2. What do we call the 2 RAM arithmetic storage locations?

A. _____ B. _____

3. What is the NT (number type) for the following numbers?

A. 10000 _____ B. 33000 _____ C. 1.011 _____ D. 1.1111111 _____

4. Where is the NT (number type) stored in RAM memory? _____

5. What type of numbers are represented by NT (number type) =?

A. 2 _____ B. 3 _____ C. 4 _____ D. 8 _____

6. In Figure 7, what is accomplished by line 310?

7. In Figure 7, what is accomplished by line 320?

8. In Figure 9, what is accomplished by lines 340/350?

9. In Figure 11, what is accomplished by line 310?

10. How many significant digits in a CDBL argument?

NOTES:

SELF-TEST QUESTIONS - CHAPTER 3:

1. Does Level II ROM ever use the the Z-80 alternate register pairs AF' - BC' - DE' - HL' ?

2. Where is the ROM CALL location to move "B" register bytes from MEM location XXXX to MEM location YYYY?

3. How many MEM locations in the ACCUM and CDBL store? Where?

4. How is the NT (number type converted to ASCII?

5. What CALL converts the ACCUM to an ASCII string?

6. What function does Figure 13's line 420 perform? Why?

7. What is the difference between RANDOM and RND?

8. What is the difference between CINT and INT?

9. How is the conversion MEM location CALled in Figure 13?

10. How is the RETURN MEM location CALled in Figure 13?

NOTE: Pages 17, 19, & 21 add a zero Operand AFTER "DEFB".
See pages 18, 20, & 22 for correct placement.

SELF-TEST QUESTIONS - CHAPTER 4:

1. What is the value of PEEK (14464) if one shift key is pressed? If both shift keys are pressed?

2. What is the value of PEEK (14338) if H, I, J, K, L, M, N, and O keys are pressed simultaneously?

3. What is the major difference between CALL 002BH and 0049H?

4. What data is stored at MEM location 409CH?

5. What is the simplest way to store an integer and single precision number in RAM (not counting the ACCUM & CDBL store).

6. Where are data comparison results stored? What values?

7. What is the value of the "A" register if CALL 0994H is used and the ACCUM contains -1.9999999999?

8. What CALL is used to change any value to an integer? To a single precision number? To a double precision number?

9. What is the value of NT RAM storage for a string?

10. What value will MEM location 37E8H contain when the line printer is ready (handshake)? What MEM location is loaded with the NEXT character to be printed?

11. Write a brief assembly language program to output to the video display a message of ANY length using the CALL 28A7H subroutine.

NOTE: This subroutine will output a string of up to 63 characters with non-disk Level II. By concatenating the strings with additional DEFM OPCODES, the message length is only limited by available memory.

SELF-TEST QUESTIONS - CHAPTER 5:

Fill in decimal CALL locations for these Level II functions using Chapter 7's Multi-Base Conversion Program:

| BASIC FUNCTION | CALL ADDRESS | BASIC FUNCTION | CALL ADDRESS |
|-------------------|-----------------|-------------------|-----------------|
| ABS | _____ | ASC | _____ |
| ATN | _____ | AUTO | _____ |
| CDBL | _____ | CHR\$ | _____ |
| CINT | _____ | CLEAR | _____ |
| CLOAD | _____ | CLS | _____ |
| CONT | _____ | COS | _____ |
| CSAVE | _____ | CSNG | _____ |
| DATA | _____ | DEFDBL | _____ |
| DEFINT | _____ | DEFSNG | _____ |
| DEFSTR | _____ | DELETE | _____ |
| DIM | _____ | EDIT | _____ |
| ELSE | _____ | END | _____ |
| ERR | _____ | ERL | _____ |
| ERROR | _____ | EXP | _____ |
| FIX | _____ | FOR | _____ |
| FRE | _____ | GOSUB | _____ |
| GOTO | _____ | IF | _____ |
| INKEY\$ | _____ | INP | _____ |
| INPUT | _____ | INSTR | _____ |
| INT | _____ | LEFT\$ | _____ |
| LEN | _____ | LIST | _____ |
| LOG | _____ | LLIST | _____ |
| LPRINT | _____ | MEM | _____ |
| MID\$ | _____ | NEW | _____ |
| NEXT | _____ | NOT | _____ |
| ON | _____ | OUT | _____ |
| PEEK | _____ | POINT | _____ |
| POKE | _____ | POS | _____ |
| PRINT | _____ | RANDOM | _____ |
| READ | _____ | REM | _____ |
| RESET | _____ | RESTORE | _____ |
| RESUME | _____ | RIGHT\$ | _____ |
| RND | _____ | RUN | _____ |
| SET | _____ | SGN | _____ |
| SIN | _____ | SQR | _____ |
| STOP | _____ | STR\$ | _____ |
| STRING\$ | _____ | SYSTEM | _____ |
| TAN | _____ | TROFF | _____ |
| TRON | _____ | USR | _____ |
| VARPTR | _____ | VAL | _____ |

SELF-TEST QUESTIONS - CHAPTERS 6, 7 & 8:

1. A. Each MEM location on page 37 holds how many hex bytes?
B. Each Line? C. Total page?
-

2. A. On page 37, location 011FH contain hex? B. = ASCII?
-

3. On page 37, just above line 0000, fill-in LSB of each hexadecimal memory location, zero through F.
-

4. A. In Chapter 7's "Number Conversion Program," is line 510 only for disk BASIC? B. Should it be deleted for non-disk?
-

5. How many fundamental number conversions are performed by Chapter 7's "Number Conversion Program"?
-

6. How is the "SPLIT DECIMAL TO DECIMAL" conversion performed?
-

7. In Chapter 8's program, rewrite lines 170-200 and 330-360 to use EX AF,AF' & EXX OPCODES instead of the stack for storage. Be VERY careful.
-

8. A. In line 490, rewrite this line to use the CP (compare) OPCODE instead of BIT 7,A. B. What is the difference?
-

9. Why are lines 590-630 necessary with IBM Selectric printers?
-

10. If you had a line printer with 130 characters per line capability (most IBM Selectric Printer Terminals have it) how would you modify this program to use all 130 positions?

CHAPTER 10

- BIBLIOGRAPHY AND ANSWERS TO SELF-TEST QUESTIONS -

BIBLIOGRAPHY and BOOKS AVAILABLE:

Using the consumers' scale of: BEST buy, GOOD buy, FAIR buy, POOR buy, and utterly WRETCHED, there is nothing on the market today for the TRS-80 assembly programmer that rates much higher than FAIR in this reviewers opinion, with two exceptions. They are both for the advanced assembly language programmer and are:

BEST: Andrew Hildebrand's "Software Technical Manual", @ \$40.
Houston Micro Computer Technologies
5313 Bissonnet Street
Bellaire, Texas 77401

GOOD: Lance Leventhal's "Z-80 Assembly Language Pgmng", @ \$15.
Adam Osborne & Associates
630 Bancroft Way
Berkeley, California 94710

Both of the above books assume that the reader has at least a few years of experience of 8080A assembly language programming experience before jumping into the Z-80, in our opinion.

There is really nothing truly worthwhile available for the beginning assembly language programmer. This includes Radio Shack's "TRS-80 Assembly language Programming," at \$3.95. Even at \$3.95 it is grossly OVER PRICED and in our kindest moments deserves our WRETCHED rating. Since there is nothing else for the beginner but garbage, garbage is the only ENTRE available and if one is truly hungry enough and holds one's nose, garbage is better than starving to death.

The following books have received our FAIR consumers' rating because of considerable generosity on our reviewer's part.

FAIR: "Z-80 Programming For Logic Design"
great for typewriter mechanics

FAIR: "The Z-80 Microcomputer Handbook"
the cover should be a clue to the buyer

FAIR: "Z-80 Software Gourmet Guide & Cookbook"
cooked tripe is still tripe

What the 200,000+ TRS-80 owners above the 5th grade level are awaiting is W6OVP's new book on the subject of assembly language programming. W6OVP is Dr. David Lien, Dean of San Diego University, a professional educator of the first water.

Dave Lien wrote the "User's Manual for Level 1," which is certainly the finest tutorial for beginning BASIC programmers from age 12 to 80 ever published, and followed it up fall '79 with "Learning Level II," which also deserves an excellent rating. If and when Dave publishes tutorials on disk BASIC and assembly language programming, they will indeed be on the best-seller list.

- ANSWERS TO QUESTIONS ON CHAPTERS' 1 TO 8 -

NOTE:

Advanced assembly language programmers' will undoubtedly think many of the questions naive to the point of ridiculousness. Indeed, many questions are absurdly simple to DRIVE HOME points to those readers who may NOT be as advanced as others. It is a difficult balancing act, so we ask for your patience and understanding.

ANSWERS TO CHAPTER 1:

1. Assume that PEEK(5712) = 197 decimal. 5712 is MEM location 1650H. Now, 197 decimal = 11000101 binary. The left most bit is a 1 which is masked (eliminated). It now = 1000101 binary = 69 decimal = ASCII "E". Since 10000000 binary = 128 decimal this same bit may be masked by simply subtracting 128 from the PEEK decimal value.
2. From 5712 decimal/1650H to 6172 decimal/181CH.
3. They are all CALLED by non-disk Level II ROM. If no disk is present or operating = L3/ERROR.
4. Subtract 128 from the PEEK value.
5. Two.
6. From 6178 decimal/1822H to 6297 decimal/1899H, and from 5642 decimal/160AH to 5711 decimal/164FH.
7. Convenience + allowing modest upward compatability between the earlier 8080 microprocessor and the newer Z-80, both invented/designed by Dr. Federico Faggin (President of Zilog).
8. 189 and 21 decimal.
9. ATN = arc tangent with output value in radians.
10. A. 7874 decimal/1EC2H B. 10767 decimal/2A0FH
C. 65535 decimal/FFFFH D. 65280 decimal/FF00H

ANSWERS TO QUESTIONS ON CHAPTER 2:

1. A. 300 to 350+ times faster. B. 1/10th as much memory.
2. ACCUM and CDBL Store; ("CS" abbreviation).
3. A. = 2 B. = 4 (>32767) C. = 4 D. = 8 NOTE: 3 = string
4. NT MEM location at 40AFH.
5. A. 2 = integer B. 4 = single precision C. 8 = double prec.
6. CALL 0E6CH changes an arithmetic string to minumum NT and stores it in the ACCUM in the appropriate format, plus storing the NT in MEM location 40AFH.
7. CALL 0A7FH = CINT which changes ANY number in the range of +32767 to -32768 to an integer.
8. Uses stack MEM in RAM to store the single precision value of registers BCDE while BCDE are used in following CALLs.
9. See answer to question 6, above. CALL 0E65H is similar, but stores the number in the ACCUM in double precision format and sets the NT in MEM location 40AFH to 8.
10. THIS MAY SURPRISE YOU. Answer: only as many digits as contained in the argument. Up to 17 digits maximum. If the argument contains 10 significant digits, the last 7 digits will be meaningless. See Radio Shack's "Microcomputer News-Letter," October '79, page 2 for an excellent explanation.

ANSWERS TO QUESTIONS ON CHAPTER 3:

1. NO, they are never used in Level II ROM as this Microsoft BASIC is sort of the son of an earlier 8080 BASIC and the 8080 has neither OPCODE. This allows YOU to use it whenever desired and save 4+ bytes compared with PUSH and POP.
2. CALL 09D7H/2519 decimal.
3. Eight in each one.
4. ADD A,48 ;converts to ASCII.
5. CALL 0FBDBH converts ACCUM to a string (address in HL), and NT in MEM location 40AFH = 3.
6. A. Converts any number in CINT range in ACCUM to integer.
B. All ROM CALL locations are integers, so acts as a trap for erroneous input.

7. RANDOM re-initializes the Z-80 random number generator. RND with NT = 2 = integer, generates a pseudo-random number between 1 and the integer value in the ACCUM. RND with NT = 4 = a single precision number, generates a pseudo random single precision number between zero and the number in the ACCUM which must = or < 1.

8. INT returns a round number (no decimal points) for ANY number. CINT changes any number with up to 7 digits to an integer within the range of +32767 and -32768.

9. Line 600's OPCODE is a RET which effectively POPS the top number off the stack, thus CALLing the CONV MEM location.

10. Since each listed CONVersion subroutine ends with a RET, this effects a POP the top number off of the stack, which is the RETURN address. This is a very useful ploy at times.

1. A. 1 B. 1 2. 255 decimal

3. CALL 002BH scans the keyboard ONCE. CALL 0049H scans the keyboard till NOT zero (till any key is pressed). Virtually the same as INKEY\$ in BASIC.

4. MEM location 409CH stores "output" directions for CALL 1BB3H (amongst others). Initialized at Zero = video display, +1 = line printe, and -1 = cassette.

5. A. PUSH DE or PUSH HL B. PUSH BC and PUSH DE C. Move 8 bytes from ACCUM to MEM via CALL 09D6H or 09D7H (A OR B reg).

6. A. In the "A" register. B. Zero C. +1 D. 255 (0FFH)

7. 255 decimal - 11111111 binary - 0FFH hex

8. A. CALL 0B37H/2871 decimal = INT; CINT's range is limited.
B. CALL 0AB1H/2737 decimal = CSNG C. CALL 0ADBH/2779 decimal = CDBL.

9. 3 decimal

10. A. 63 decimal = ASCII ? (what next?). B. 37E8H

```

11.  W4UCH      EQU      7D00H           ;MESSAGE PROGRAM
      ORG       W4UCH      ;7D00H = 32000 DECIMAL
      LD        HL,STRING  ;STRING MEM ADDRESS
      CALL      28A7H      ;DISPLAY $ SUBROUTINE
STRING DEFM      'USING LEVEL II ROM SUBROUTINES'
      DEFB      0          ;END OF MESSAGE DELIMITER
      END       W4UCH      ;CONCATENATE ANY LENGTH
;NOTE-you may concatenate up to 240 bytes per CALL 28A7H.

```

ANSWERS TO SELF-TEST QUESTIONS

- CHAPTER 5 -

LEVEL II BASIC FUNCTION CALL ADDRESSES IN DECIMAL

| BASIC FUNCTION | CALL ADDRESS | BASIC FUNCTION | CALL ADDRESS |
|-------------------|-----------------|-------------------|-----------------|
| ABS | 2423 | ASC | 10767 |
| ATN | 5565 | AUTO | 8200 |
| CDBL | 2779 | CHR\$ | 10783 |
| CINT | 2687 | CLEAR | 7802 |
| CLOAD | 11295 | CLS | 457 |
| CONT | 7652 | COS | 5441 |
| CSAVE | 11253 | CSNG | 2737 |
| DATA | 7941 | DEFDBL | 7689 |
| DEFINT | 7683 | DEFSNG | 7686 |
| DEFSTR | 7680 | DELETE | 11206 |
| DIM | 9736 | EDIT | 11872 |
| ELSE | 7943 | END | 7598 |
| ERL | 9437 | ERR | 9423 |
| ERROR | 8180 | EXP | 5177 |
| FIX | 2854 | FOR | 7329 |
| FRE | 10196 | GOSUB | 7857 |
| GOTO | 7874 | IF | 8249 |
| INKEY\$ | 413 | INP | 10991 |
| INPUT | 8602 | INSTR | 16787 |
| INT | 2871 | LEFT\$ | 10849 |
| LEN | 10755 | LIST | 11054 |
| LOG | 2057 | LLIST | 11049 |
| LPRINT | 8295 | MEM | 10185 |
| MID\$ | 10906 | NEW | 6985 |
| NEXT | 8886 | NOT | 9668 |
| ON | 8044 | OUT | 11003 |
| PEEK | 11434 | POINT | 307 |
| POKE | 11441 | POS | 10229 |
| PRINT | 8303 | RANDOM | 467 |
| READ | 8687 | REM | 7943 |
| RESET | 312 | RESTORE | 7569 |
| RESUME | 8111 | RIGHT\$ | 10897 |
| RND | 5321 | RUN | 7843 |
| SET | 309 | SGN | 2442 |
| SIN | 5447 | SQR | 5095 |
| STOP | 7593 | STR\$ | 10294 |
| STRING\$ | 10799 | SYSTEM | 690 |
| TAN | 5544 | TROFF | 7672 |
| TRON | 7671 | USR | 10238 |
| VARPTR | 9461 | VAL | 10949 |

ANSWERS TO SELF-TEST QUESTIONS CHAPTERS 6, 7, 8:

1. A. One B. 16 bytes per line C. 48 lines X 16/line = 768
2. A. 56H = 86 decimal B. = ASCII "V"
3. 0 1 2 3 4 5 6 7 8 9 A B C D E F 0123456789ABCDEF
0000 F3AF C374 06C3 0040 C300 40E1 E9C3 9F06@...@.....
4. A. YES: to speed-up disk a bit B. YES: remove from non-disk
5. A. To round-off division by 2 to an integer = a short-cut
in the decimal to binary conversion equation.
B. 4 fundamental conversions - rest are only massages.
- decimal to binary : lines 740 - 840
- binary to decimal : lines 860 - 1150
- binary to hexadecimal : lines 1200 - 1490
- hexadecimal to binary : lines 1550 - 1810
6. The first decimal number is converted to hex and stored in FF\$ in line 1470. The second decimal number is then converted to hex and stored in SS\$ in line 1480. FF\$ and SS\$ are then reversed and made = to X\$ in line 1480. The correct hex number which is X\$ is then displayed on video in line 1480. This hex number, X\$, is then converted to binary, and next converted to decimal, and then displayed on video. Though very SLOW when written in BASIC, it still beats a Hewlett-Packard calculator.
7. 00170 START EX AF,AF' ;EXCHANGE ALTERNATE REGS.
00180 LD A,C ;NEXT CHAR. TO "A" REGISTER
00190 EXX ;EXCHANGE BC DE HL ALT. REG
delete lines 00200 and 00210
NOTE: Since the NEXT character to be printed is in the "C" register, we MUST load it into "A" BEFORE exchange.
00330 ELFIN EX AF,AF' ;EXCHANGE ALTERNATE REGS.
00340 EXX ;EXCHANGE BD DE HL ALT. REG
delete lines 00350 and 00360
NOTE: This little exercise deleted 4 lines and 4+ bytes.
A very decided improvement & good technique.
8. 00490 CP 3FH ;is it ASCII ? = 63 decimal
9. Backspace vibrates most IBM Selectric printers quite severely. Try your printer without these lines. Use only if necessary.
10. Change line 250 to read:
00250 CP 082H ;is it 130 decimal = end of line?

FINAL REQUEST:

Please send ANY errors you find to:

RICHCRAFT ENGINEERING LTD
DRAWER 1065
CHAUTAUQUA, NY 14722

Commands

| Commands | Definition |
|----------|--|
| A | Displays alteration possibilities. |
| A.A | Alters Account names. |
| A.C | Alters Category names. |
| A.D | Alters data. |
| A.N | Alters Notepad names. |
| A.T | Alters data diskette title. |
| A.Y | (Month Level only) Alters data diskette year. |
| B | Sets or clears buzzer. If clock is turned on. |
| C | Selects from display of categories or category. |
| D | (Day Level only) Deletes entry. |
| D.D | (Month Level only) Deletes all non-permanent entries. |
| F | Displays flag possibilities. |
| F.F | Feed Flag. Turns automatic carriage return line feed off and on. |
| F.L | Lower Case Flag. Displays lower case letters. |
| F.Q | Quiet Flag. Causes tone to sound, or remain quiet, when days are changed at either the Month or Day Level. |

| Commands | Definition |
|----------|---|
| F.B | Recover Flag. Uses flags from data diskette, not those currently selected. |
| F.W | Write Flag. Records flags currently selected onto data diskette. |
| F.X | Expert Flag. Causes Time Manager to not display error messages unless requested by [X] key. Typing [X] again will cause program to display error messages normally. |
| I | Calculates and displays interval from marked day to selected date. |
| K | Selects or cancels keyword. |
| L | Selects prioritise for display. |
| M | (Day Level only) Displays move possibilities. |
| M.D | Moves entry to [D] day. |
| M.C | Move/Clear. Clears move buffer. |
| M.G | Move/Get. Extracts entry from move buffer. |
| M.S | Move/Save. Stores entry in move buffer. |
| N | Displays Notepad Directory. |
| N.A | Displays Notepad A through H. |
| P | Prints entries. |

| Commands | Definition |
|----------|--|
| Q | Displays status of flags, number of entries, buffer contents, number of entries on data diskette. Keyword or Category Selection, and Priority Selection. |
| R | (Day Level only) Repeats entry in move buffer. |
| S | (Day Level only) Scans for entry. |
| T | Displays account sums and totals. |
| T.C | Clears individual accounts sums to zero. |
| T.S | Calculates account sums. |
| T.M | Sets account multipliers. |
| T.O | Turns off running account sums. |
| T.R | Turns on running account sums. |
| T.S | Sets account sums. |
| W | (Day Level only) Writes new entries on data diskette before adding other entries or performing other tasks. |
| X | (Month Level only) Copies data to new diskette. |
| Y | (Month Level only) Moves calendar to indicated year. |
| Z | (Month Level only) Creates new data diskette. |

Account Descriptions

| Account Number | Symbol | Record Your Descriptions |
|----------------|--------|--------------------------|
| 1 | 1 | |
| 2 | 2 | |
| 3 | 3 | |
| 4 | 4 | |
| 5 | 5 | |
| 6 | 6 | |
| 7 | 7 | |
| 8 | 8 | |
| 9 | 9 | |